



WERSI

Brand Owner and Development
MUSIC STORE
professional

SONIC

OAX1 - OAX500 - OAX600 - OAX700
OAX800 - OAX900 - PERGAMON OAX1000



Sound List - Style List
Total Presets - Music Archive
Drumsets – Effects
and other Factory Settings

Impressum

Sounds - Styles – Music Archive – Total Presets – Drumsets – Effects – Factory Settings for

Keyboard **OAX1**
Organ **OAX500LS**
 OAX600, OAX600LS
 OAX700, OAX700LS
 OAX800LS
 OAX900
 PERGAMON OAX1000

Software version on release:

3.0

Date: 23. June 2025
OAX Ideas and Design: Ulrich Wildhack
OAX Programming: Dennis Noppeney , Ulrich Wildhack

Copyright © 2025 by

MUSIC STORE professional GmbH
Istanbulstraße 22-26
51103 Cologne
Germany

E-Mail: info@wersi.net
Website: www.wersi.net

All rights reserved.

We reserve the right to make technical changes to the hardware and software of the OAX instruments without prior notice. We do not guarantee that all the properties described in this manual will be consistent with those of an OAX instrument currently delivered.

Reproduction, translation, microfilming as well as storage and processing in electronic systems is not permitted without our express consent and violates the copyright law.

User Content

1	Sound List.....	4
1.1	Explanation of the sound list.....	4
1.2	Drawbars Live.....	5
1.3	Drawbars Presets.....	11
1.4	Accordion	14
1.5	Brass	17
1.6	Vocals.....	25
1.7	Church/Theatre	27
1.8	Guitars	30
1.9	Percussion.....	36
1.10	Piano.....	38
1.11	Strings	42
1.12	Synthesizer	45
1.13	Drums	56
1.14	ACC Specials	61
2	Style List.....	65
2.1	List of factory style by music genre.....	65
2.2	List the factory styles after the control panel buttons	75
3	Music Archive.....	80
3.1	Music Archive sorted by German and World.....	80
3.2	Musik Archiv sorted by A - Z.....	90
4	Total Presets	100
5	List Factory sheets	111
6	Wersi Chord	112
6.1	List WERSI Chord Types.....	112
6.2	List WERSI Chord Presets.....	113
7	WERSI Vision	114
7.1	List of WERSI Vision presets	114
7.2	List of WERSI Vision Pattern	115
8	List of effect programs for reverb, chorus and echo.....	120
9	List of the foot switch functions.....	121
10	List of functions and presets "Assign drawbars"	123
10.1	Possible functions.....	123
10.2	Factory Presets OAX1 – OAX500 – OAX600 – OAX700	126
10.3	Factory Presets OAX800	128
10.4	Factory Presets PERGAMON.....	130
11	List of effect-sounds	132
12	Harmony Types for Accompaniment	135
12.1	The following harmony types are recognized.....	135
12.2	Different chord modes	136
13	Effects for Input Mixer.....	140
14	Drum kits	144

1 Sound List

1.1 Explanation of the sound list

On the following pages you will see a list of all the sounds that are available in the OAX system.

Note: The sounds of the software version 3.0 and the LOWREY Live Organ are part of the respective expansion package. The sounds are labelled accordingly.

For each sound you can also see the necessary LSB, MSB and PRG change if you want to control the timbre via MIDI.

The list is structured like the list in your instrument itself.

So by Main groups -> Instruments and -> Subgroups.



The screenshot shows the 'Sound List' window with the following structure:

- Main Groups:** All, Live Organ, Organ Presets, Church Organ, Accordion, User Sounds, Mallet & Bells, Vocals, Strings, Guitars, Pianos, Brass, Synthe, Drums.
- Instruments:** All, Acoustic, Electro, Bass.
- Subgroups:** All, Clean, WahWah, Overdr., Other, Split, Layer, Expansion, User.
- Sound List:**

Sound	PRG ▾
Acc 60s Vintage Slap	085-000-036
Acc Overdrive Guitar	085-000-037
Acc Distortion Guitar	085-000-038
GM027 Jazz Guitar	089-000-026
GM028 Electric Guitar	089-000-027
GM029 Muted Guitar	089-000-028
GM030 Overdr. Guitar	089-000-029
GM031 Distor. Guitar	089-000-030
GM032 Harm. Guita	089-000-031
Jazz Guitar 1	090-000-005
Hawaiin Guitar	090-000-046
E-Guitar Stratocaster	090-000-078

Buttons at the bottom include: Search, Fast Search, Filter, Import, and Load.

ACC Specials

In the ACC Specials section, you can see timbres that have been specially programmed for use in automatic accompaniment.

These timbres can only be played to a limited extent on the manuals.

So when you register one of these tones on a manual, don't be surprised if the tone doesn't do what you want it to.

1.2 Drawbars Live

Sound Group	User Panel	Bank	Soundname
Drawbars	Live Organ	OX7	OX7II B-Typ OX7II H-Typ B-Typ Straight Rotor B-Typ Open Rotor B-Typ Open Rot-Vib B-Typ oft Rot-Vib B-Typ Tutti Rotor H-Typ Straight Rot. B-Typ Rotor LM 1 B-Typ Rotor LM 2 B-Typ Rotor LM 3 B-Typ Rotor Pedal 1 B-Typ Rotor Pedal 2 B-Typ Straight Vib. B-Typ Dark Cel. B-Typ Dark Chor. B-Typ Open Cel. B-Typ Medium Norm B-Typ Vibrato UM 1 B-Typ Vibrato UM 2 B-Typ Vibrato UM 3 B-Typ Vibrato Pedal 1 B-Typ Vibrato Pedal 2 B-Typ Jazz 2nd Rotor B-Typ Jazz 2nd Cel. B-Typ 3rd Rotor B-Typ Guitar Cele. B-Typ 2nd Chorus B-Typ 2nd Vib/Rot Helios Straight Rotor Helios Open Rotor Helios Open Ro/Vi Helios Tutti Rot. Helios Rotor LM 1 Helios Rotor LM 2 Helios Rotor LM 3 Helios Rotor Pedal 1 Helios Rotor Pedal 2 Helios Straight Vib. Helios Dark Cel. Helios Dark Chor. Helios OpenCel. Helios Medium Norm Helios Vibrato LM 1 Helios Vibrato LM 2 Helios Vibrato LM 3 Helios Vibrato Pedal 1 Helios Vibrato Pedal 2 Helios Perc. User Helios Perc. Guitar Helios 2nd Rotor Helios 3rd Vib Helios 2nd Chorus

Sound Group	User Panel	Bank	Soundname
Drawbars	Live Organ	OX7	Spectra Straight Ro.
			Spectra Open Rot.
			Spectra Open R&V
			Spectra Tutti Rot.
			Spectra Rotor LM 1
			Spectra Rotor LM 2
			Spectra Rotor LM 3
			Spectra Rotor Pedal 1
			Spectra Rotor Pedal 2
			Spectra Strai. Vib
			Spectra Dark. Cel
			Spectra Dark. Cho.
			Spectra Open Cel.
			Spectra Medium Vib.
			Spectra Vib. LM 1
			Spectra Vib. LM 2
			Spectra Vib. LM 3
			Spectra Vib. Ped 1
			Spectra Vib. Ped 2
			Spectra 2nd Perc
			Spectra Perc. User
			Spectra Perc. Guitar
			Spectra 2nd Rotor
			Spectra 3rd Vib
			OX7II Spectra
			OX7II Helios
		VB3	VB3 Drawbars Standard
			VB3 Drawbars Smooth
			VB3 Drawbars Bright
			VB3 Drawbars Rotor wide
			VB3 Vibrato C-3 & Perc3rd
			VB3 Rotor Bright
			VB3 Rotor & Perc 2nd
			VB3 Rotor Rock
			VB3 Rotor Straight
			VB3 Alone in town
			VB3 Funky
			VB3 Dark Solo
			VB3 Bright Solo
			VB3 Ballad
			VB3 Rotor & Perc 3rd
			VB3 Vibrato V-3
			VB3 5th trick
			VB3 Bridge
			VB3 Square wave
			VB3 Slow tunes
			VB3 Sweet
			VB3 Flutes
			VB3 Pick the sound
			VB3 Rotor open
			VB3 Vibrato C-3
			VB3 Rotor wide
			VB3 Invention

Sound Group	User Panel	Bank	Soundname
Drawbars	Live Organ	VB3	VB3 Bright comping VB3 Dark comping VB3 Reeds VB3 Strings VB3 Italian Transistor VB3 Dist. Organ 1 VB3 Dist. Organ VB3 Farfisa VB3 Gospel Organ 1 VB3 Gospel Organ 2 VB3 Gospel Organ 3 VB3 Jimmy 1 VB3 Jimmy 2 VB3 Jimmy 3 VB3 Jimmy 4 VB3 Old B3 VB3 Rock Organ 1 VB3 Rock Organ 2 VB3 The B3 VB3 Vox Organ VB3 Std. Preset VB3 Smooth Preset VB3 Dist. Preset VB3 Rotor<->Preset VB3 Rotor 8"+4" VB3 Rotor 8"+4"+2 2/3" VB3 Rotor 8"+4"+2" VB3 Vib C-1 8"+4" VB3 Vib C-2 8"+4" VB3 Vib V-1 8"+4" VB3 Vib V-3 8"+4" VB3 Standard Upper VB3 Standard Lower
Drawbars	Live Organ	Farfisa	Farfisa Multi Farfisa Multi Booster Farfisa Chorus Farfisa Echo Farfisa Amp Farfisa Rotor Farfisa Scanner Farfisa Rock 1 Farfisa Rock 2 Farfisa Psycho Farfisa Sustain Farfisa All Booster Farfisa Slow Sustain Farfisa Effect Mix 1 Farfisa Effect Mix 2

Sound Group	User Panel	Bank	Soundname
Drawbars	Zugriegel Live	Lowrey	LW Full Chorus
			LW 16-8-4 Chorus
			LW 16-8-2 Chorus
			LW 16-1 Chorus
			LW Mix Chorus 1
			LW Mix Chorus 2
			LW Mix Chorus 3
			LW Mix Chorus Perc 1
			LW Mix Chorus Perc 2
			LW 8-4 Chorus Lower
			LW 8-4-2 Chorus Lower
			LW Full Chorus Lower
			LW 16-4 Chorus Sustain
			LW 16-1 Chorus Sustain
			LW Mix 1 Chorus Sustain
			LW Mix 2 Chorus Sustain
			LW Mix 3 Chorus Sustain
			LW Mix 4 Chorus Sustain
			LW Full Straight Celeste
			LW 16-8-4 Celeste
			LW 16-8-2 Celeste
			LW 16-1 Celeste
			LW Mix Celeste 1
			LW Mix Celeste 2
			LW Mix Celeste 3
			LW Mix Celeste Perc 1
			LW Mix Celeste Perc 2
			LW 8-4 Celeste Lower
			LW 8-4-2 Celeste Lower
			LW Full Celeste Lower
			LW 16-4 Celeste Sustain
			LW 16-1 Celeste Sustain
			LW Mix 1 Celeste Sustain
			LW Mix 2 Celeste Sustain
			LW Mix 3 Celeste Sustain
			LW Mix 4 Celeste Sustain
			LW Full Straight Rotor
			LW 16-8-4 Rotor
			LW 16-4-2 Rotor
			LW 16-1 Rotor
			LW Mix Rotor 1
			LW Mix Rotor 2
			LW Mix Rotor 3
			LW Mix Rotor Perc 1
			LW Mix Rotor Perc 2
			LW 8-4 Rotor Lower
			LW 8-4-2 Rotor Lower
			LW Full Rotor Lower
			LW 16-4 Rotor Sustain
			LW 16-1 Rotor Sustain
			LW Mix Rotor Sustain

Sound Group	User Panel	Bank	Soundname
Drawbars	Zugriegel Live	Lowrey	LW Mix 1 Rotor Sustain LW Mix 2 Rotor Sustain LW Mix 3 Rotor Sustain LW Full Rotor Chorus LW Full Rotor Celeste LW 16 Bass Sustain LW 16-8 Bass Sustain LW 16 Bass LW Theater Full LW Theater Full Tremolo LW Theater Tibia 16-4 LW Theater Tibia 16-4 Tremolo LW Theater Tibia 8 LW Theater Tibia 8-4 LW Theater Tibia 8-4 Reed 16-8 LW Theater Tibia 8-4 Vox 16-8 LW Theater Vox 16-8 Dias 8-4 LW Theater Vox 16-8 Dias 8 LW Theater Dias 8 LW Theater Dias 8-4 LW Theater Dias 8-4 Tremolo LW Theater Tib Vox Dia Mix 1 LW Theater Tib Vox Dia Mix 2 LW Theater Tib LM LW Theater Tib Read LM LW Theater Tib Viole LM LW Theater Reed 16-8 LW Theater Reed 8 LW Theater Reed 16-8 Tremolo LW Theater Viole 16-8 LW Theater Viole 8 LW Theater Viole 16-8 Tremolo LW Theater Viole 16-8 Sustain LW Theater Vox Celeste 16-8 LW Theater Vox Celeste 8 LW Theater Vox Celeste 16-8 Tremolo LW Theater Vox Celeste 16-8 Celeste LW Theater Post Horn 16 LW Theater Post Horn Kinura LW Theater Mix 1 LW Theater Mix 2 LW Theater Mix 3 LW Theater Mix 4 LW Theater Mix 5 Sustain LW Theater Mix 6 Tremolo LW Ens Vocal 16 LW Ens Vocal 16 Sustain LW Ens Vocal 16 Sustain Ensemble LW Ens Vocal 8 Sustain LW Ens Vocal 8 4 Sus Ensemble

Sound Group	User Panel	Bank	Soundname
Drawbars	Zugriegel Live	Lowrey	LW Strings 16
			LW Strings 16-8
			LW Strings 16-8 Sustain
			LW Strings 16-8 Ensemble
			LW Strings Vocal 16-8 Sustain
			LW Strings Vocal 8 Sustain
			LW Big Sound Mix
			LW Big Sound Brass Mix
			LW Big Sound String Mix
			LW Big Sound Horn Mix
			LW Combi LM Mix 1
			LW Combi LM Mix 2
			LW Combi LM Mix 2 Sustain
			LW Combi LM Mix 3
			LW Combi LM Mix 4 Horn
			LW Organ Tibia Upper Chorus
			LW Organ Tibia Lower Chorus
			LW Organ String Upper Celeste
			LW Organ String Lower Celeste
			LW Organ Diapason Upper Celeste
			LW Organ Diapason Lower Celeste
			LW Organ Jazz Upper Rotor
			LW Organ Jazz Lower Rotor
			LW Organ Std. Upper Rotor
			LW Organ Std. Lower Rotor
			LW Organ Std. Upper Celeste
			LW Organ Std. Lower Celeste

1.3 Drawbars Presets

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Drawbars	Drawbars Presets	CD-DX	CD-Jazzorgan	0	91	2
			CD-Jazzorgan Stereo	0	91	3
			The Chorus	0	6	1
		Helios	Sinus Galaxy	0	6	7
			Refrain Sinus	0	6	17
			Fresh Latin Sinus	0	6	21
			Bright Drawbars	0	6	41
			Megasinus	0	6	43
			Choir & Sinus	0	6	44
			Full Chorus	0	6	57
			Drawbars Combi 1	0	6	76
			Drawbars Combi 2	0	6	77
			GM017 Organ	0	89	17
			Helios-DB Celesta	0	7	5
			Helios-DB Percussion	0	7	22
			Helios-DB Lower	0	7	29
			KW Helios DB Lead 1	0	12	45
			KW Helios DB Lead 2	0	12	46
			KW Helios Tico DB LM	0	12	47
			KW Helios MellowMiller DB	0	12	48
			KW Helios MillerClarinet	0	12	49
			KW Helios Miller DB	0	12	50
			KW Helios Miller Full DB	0	12	51
			KW Helios	0	12	52
			KW Helios Percussion	0	12	53
			KW Helios DB BellsChorus	0	12	54
			KW Helios Tico Wah	0	12	55
			KW Helios Tico WahWah	0	12	56
			KW Helios Brass Tico	0	12	57
			KW Helios MillerHorn	0	12	58
			KW Helios MillerSax	0	12	59
			KW Helios MillerReeds	0	12	60
			KW Helios Strings ft8	0	12	61
			KW Helios StringsBlaster	0	12	62
			KW Helios Dry Strings	0	12	63
			KW Helios Str-Harpsichord	0	12	64
			KW Helios Miller MtTrumpet	0	12	65
			KW Helios DB Bells	0	12	66
			KW Helios Bass	0	12	67
			KW Helios ACC Guitar	0	12	68
			KW Helios Brass Miller DB	0	12	69
			KW Helios Piano Strings	0	12	70
			KW Helios Honky Tonk	0	12	71
			KW Helios Moon Grand	0	12	72
			KW Helios Sweet Miller DB	0	12	73
			KW Helios Moonlight Miller	0	12	74
			KW Helios Miller Trombone DB	0	12	75
		B3	The Real Wersi	0	6	20
			Percussive Lead	0	6	74
			Percussion Solo	0	6	82
			GM018 Perc. Organ	0	89	18
			GM019 Rock Organ	0	89	19
			Perk. Organ Universal	0	93	46

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG	
Drawbars	Drawbars Presets	CD-DX	CD-Jazzorgan	0	91	2	
			CD-Jazzorgan Stereo	0	91	3	
			The Chorus	0	6	1	
			Sinus Galaxy	0	6	7	
			Refrain Sinus	0	6	17	
			Fresh Latin Sinus	0	6	21	
			Bright Drawbars	0	6	41	
			Megasinus	0	6	43	
			Choir & Sinus	0	6	44	
			Full Chorus	0	6	57	
			Drawbars Combi 1	0	6	76	
			Drawbars Combi 2	0	6	77	
			GM017 Organ	0	89	17	
			Helios	Helios-DB Celesta	0	7	5
			Helios-DB Percussion	0	7	22	
Helios	Helios	Helios	Helios-DB Lower	0	7	29	
			KW Helios DB Lead 1	0	12	45	
			KW Helios DB Lead 2	0	12	46	
			KW Helios Tico DB LM	0	12	47	
			KW Helios MellowMiller DB	0	12	48	
			KW Helios MillerClarinet	0	12	49	
			KW Helios Miller DB	0	12	50	
			KW Helios Miller Full DB	0	12	51	
			KW Helios	0	12	52	
			KW Helios Percussion	0	12	53	
			KW Helios DB BellsChorus	0	12	54	
			KW Helios Tico Wah	0	12	55	
			KW Helios Tico WahWah	0	12	56	
			KW Helios Brass Tico	0	12	57	
			KW Helios MillerHorn	0	12	58	
			KW Helios MillerSax	0	12	59	
			KW Helios MillerReeds	0	12	60	
			KW Helios Strings ft8	0	12	61	
			KW Helios StringsBlaster	0	12	62	
			KW Helios Dry Strings	0	12	63	
			KW Helios Str-Harpsichord	0	12	64	
			KW Helios Miller MtTrumpet	0	12	65	
			KW Helios DB Bells	0	12	66	
			KW Helios Bass	0	12	67	
			KW Helios ACC Guitar	0	12	68	
			KW Helios Brass Miller DB	0	12	69	
			KW Helios Piano Strings	0	12	70	
			KW Helios Honky Tonk	0	12	71	
			KW Helios Moon Grand	0	12	72	
			KW Helios Sweet Miller DB	0	12	73	
			KW Helios Moonlight Miller	0	12	74	
			KW Helios Miller Trombone DB	0	12	75	
B3	B3	B3	The Real Wersi	0	6	20	
			Percussive Lead	0	6	74	
			Percussion Solo	0	6	82	
			GM018 Perc. Organ	0	89	18	
			GM019 Rock Organ	0	89	19	
			Perk. Organ Universal	0	93	46	

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Drawbars	Drawbars Presets	B3	Rock Organ Universal	0	93	47
			DB Full 1	0	93	67
			DB Full 2	0	93	68
			DB 16+8+4+2	0	93	69
			DB 16+8+4+2+1	0	93	70
			DB 16+1-1/3+1	0	93	71
			DB Blues 1	0	93	72
			DB Blues 2	0	93	73
			DB Blues1+Perc.	0	93	74
			DB Blues2+Perc.	0	93	75
			DB Lower 1	0	93	76
			DB Lower 2	0	93	77

1.4 Accordion

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Accordion	Accordion Live	Normal	Supita Live	0	100	1
			Morino V. Live	0	100	13
			Mengascini Live	0	100	69
		Musette	Musette Live	0	100	33
			Musette 2Voix Live	0	100	45
			Musette 3Voix Live	0	100	57
	Accordion Presets	Alps	Alpina Live	0	100	27
		Normal	Supita 1	0	100	2
			Supita 2	0	100	3
			Supita 3	0	100	4
			Supita 4	0	100	5
			Supita 5	0	100	6
			Supita 6	0	100	7
			Supita 7	0	100	8
			Supita 8	0	100	9
			Supita 9	0	100	10
			Supita 10	0	100	11
			Supita 11	0	100	12
			Morino Bassoon	0	100	14
			Morino V. Cello	0	100	15
			Morino Bandoneon	0	100	16
			Morino Harmon	0	100	17
			Morino Organ	0	100	18
			Morino Violin	0	100	19
			Morino Master	0	100	20
			Morino Accord	0	100	21
			Morino Musette	0	100	22
			Morino Celeste	0	100	23
			Morino Oboe	0	100	24
			Morino Clarin	0	100	25
			Morino Jazz Special	0	100	26
			Mengascini 1	0	100	70
			Mengascini 2	0	100	71
			Mengascini 3	0	100	72
			Mengascini 4	0	100	73
			Mengascini 5	0	100	74
			Mengascini 6	0	100	75
			Mengascini 7	0	100	76
			Mengascini 8	0	100	77
			Mengascini 9	0	100	78
			Mengascini 10	0	100	79
			Mengascini 11	0	100	80

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Accordion	Accordion Presets	Musette	Musette American 1	0	100	34
			Musette American 2	0	100	35
			Musette American 3	0	100	36
			Musette American 4	0	100	37
			Musette American 5	0	100	38
			Musette American 6	0	100	39
			Musette American 7	0	100	40
			Musette American 8	0	100	41
			Musette American 9	0	100	42
			Musette American 10	0	100	43
			Musette American 11	0	100	44
			Musette 2Voix 1	0	100	46
			Musette 2Voix 2	0	100	47
			Musette 2Voix 3	0	100	48
			Musette 2Voix 4	0	100	49
			Musette 2Voix 5	0	100	50
			Musette 2Voix 6	0	100	51
			Musette 2Voix 7	0	100	52
			Musette 2Voix 8	0	100	53
			Musette 2Voix 9	0	100	54
			Musette 2Voix 10	0	100	55
			Musette 2Voix 11	0	100	56
			Musette 3Voix 1	0	100	58
			Musette 3Voix 2	0	100	59
			Musette 3Voix 3	0	100	60
			Musette 3Voix 4	0	100	61
			Musette 3Voix 5	0	100	62
			Musette 3Voix 6	0	100	63
			Musette 3Voix 7	0	100	64
			Musette 3Voix 8	0	100	65
			Musette 3Voix 9	0	100	66
			Musette 3Voix 10	0	100	67
			Musette 3Voix 11	0	100	68
			Akkordeon Musette 1	0	90	24
			Akkordeon Musette 2	0	90	65
			Akkordeon Musette 3	0	82	60
			Akkordeon Musette 4	0	82	61
		Alps	Alpina Bassoon	0	100	28
			Alpina Bandon	0	100	29
			Alpina Master	0	100	30
			Alpina Musette	0	100	31
			Alpina Clarinet	0	100	32
			Diatonic Accordion 1	0	90	22
			Diatonic Accordion 2	0	90	63
			Diatonic Accordion 3	0	93	24
			Diatonic Chorus	0	93	25
			Diatonic Echo	0	93	30
			Diatonic Mixed	0	93	31
			Swiss Örgli	0	100	81

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Accordion	Accordion Presets	Other	Accordion 3Ch	0	90	23
			Accordion 2x8Ch	0	90	39
			Accordion Mixed 1	0	90	38
			Accordion Mixed 2	0	93	26
			Accordion 8"	0	90	59
			Accordion 16"	0	90	60
			CD-Accordion	0	91	8
			CD-Accordion St	0	91	9
			Accordion Bass	0	82	57
			Accordion Russian	0	82	58
			Accordion Tango 1	0	90	54
			Accordion Tango 2	0	82	59
			Bandoneon 1	0	90	25
			Bandoneon 2	0	90	61
			Bandoneon 3	0	90	62
			Dwarfs March	0	6	35
			KW Accordion	0	12	2
			KW Franz. Accordion	0	12	3
			Reed Organ	0	90	118
			Biscaya Accordion JL	0	103	10
			Biscaya Accordion JL	0	103	37
			GM022 Accordion	0	89	22
			GM024 Tango Accordion	0	89	24
			GM021 Reed Organ	0	89	21
		Layer	Accordion & Trumpet	0	93	27
			Accordion & Zither	0	93	28
			Accordion & Clarinet	0	93	29
			Diatonisch & Bandoneon	0	93	32
		Harp	Harp	0	90	27
			Stevie's Harp	0	6	15
			Blues Harp Distorted	0	82	62
			Harp Blues	0	93	79
			GM023 Harmonica	0	89	23

1.5 Brass

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Brass	Trumpet Trombone	Trumpets	Trumpet 1	0	9	62
			Trumpet 1 Soft	0	9	63
			Trumpet 1 Bright	0	9	64
			Trumpet Solo 1	0	91	76
			Trumpet Solo 2	0	82	33
			Trumpet Solo 2 Soft	0	82	34
			Trumpet 3 Solo	0	93	99
			Trumpet 2	0	90	13
			Trumpet 2 Echo	0	91	120
			Trumpet 2 Filter	0	91	121
			Trumpet 2 Bright	0	90	55
			Trumpet Muted 1	0	90	56
			Trumpet Muted 2	0	82	37
			Trumpet Jazz	0	91	75
			Trumpet Live	0	93	89
			Trumpet Vibrato	0	7	71
			Trumpet Small	0	82	35
			Trumpet Duck	0	82	36
			Trumpet PingPong	0	93	42
			Trumpet Alarm	0	93	43
			Trumpet MF Port	0	63	1
			Trumpet F Port	0	63	2
			Trumpet Muted Port	0	63	3
			CD Trumpet	0	10	74
			KW Trumpet	0	12	13
			KW Muted Trumpet	0	12	15
			Flugelhorn	0	90	46
			Flugelhorn Port	0	63	4
			GM057 Trumpet	0	89	57
			GM060 Muted Trp.	0	89	60
			Flugelhorn JL	0	103	8
			Trumpet Soft JL	0	103	29
			Trumpet Solo JL	0	103	31
	Lowrey Organ	Lowrey Organ	Louis Trumpet LW	0	105	22
			Louis Shakes LW	0	105	23
			Louis Trumpet+Shakes Vel LW	0	105	24
			Plunger Trumpet LW	0	105	25
			Muted Cup Trumpet 1 LW	0	105	26
			Muted Cup Trumpet 2 LW	0	105	27
	Trombone	Trombone	Trombone 1	0	9	72
			Trombone 1 Warm	0	9	73
			Trombone 1 Soft	0	9	74
			Trombone 2	0	90	14
			Trombone 2 Warm	0	90	53
			Trombone 2 Jazz	0	91	77
			Trombone 3 Bass	0	82	38
			Trombone 4 Soft	0	82	39
			Mr. Trombone	0	6	63
			Trombone Small	0	82	40
			Trombone Port	0	63	5
			Trombone Soft Port	0	63	6
			KW Trombone	0	12	14
			GM058 Trombone	0	89	58
			Trombones JL	0	103	5

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Brass	Trumpet Trombone	Horn	Horn Solo	0	90	101
			French Horn Section	0	82	85
			Hybrid Horn Section	0	82	86
			KW Horn	0	12	16
			GM061 French Horn	0	89	61
	<i>Lowrey Organ</i>	<i>Lowrey Organ</i>	French Horn LW	0	105	32
			French Horn Solo LW	0	105	33
			French Horn Warm LW	0	105	34
			French HornSection LW	0	105	35
	Tuba	Tuba	Tuba 1	0	91	28
			Tuba 2	0	82	41
			Brass Bass	0	93	56
			Bariton Bras s& Bass	0	7	40
			Bariton Brass	0	7	41
			GM059 Tuba	0	89	59
	Ensemb.	Ensemb.	Trumpets Ensemble 1	0	9	66
			Trumpets Ensemble 2	0	90	107
			Trumpets Ensemble 3	0	93	96
			Trumpets Mariachi 1	0	9	65
			Trumpets Mariachi 2	0	93	88
			Trombone Ensemble 1	0	9	75
			Trombone Ensemble 2	0	90	106
			Horn Ensemble	0	90	98
			Horn Ensemble Swell	0	90	99
			Horn Ensemble Warm	0	90	100
			Trumpets Duo JL	0	103	2
			Trumpets Duo Pan JL	0	103	3
			Trumpet Full JL	0	103	4
			Trumpets Soft JL	0	103	30
			Trumpets Duo Up JL	0	103	32
			Trombones Down JL	0	103	33
			Trumpets Duo Down JL	0	103	38
			Trombones Up JL	0	103	40

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Brass	Brass	Normal	Brass Section 1	0	90	15
			Brass Section 2	0	84	76
			Brass Section 3	0	82	78
			Mr. James Brass	0	9	88
			Ensemble Brass 1	0	9	82
			Ensemble Brass 2	0	9	83
			Big Band Ensemble 1	0	9	84
			Big Band Ensemble 2	0	9	85
			Big Band Ensemble 3	0	6	87
			Brass Sforzando	0	90	104
			Brass Down Up	0	93	44
			Brass Shake	0	93	104
			TRP Ensemble Fall	0	9	86
			TRP Ensemble Shake	0	9	87
			TRP EnsembleModWheel	0	9	89
			TRP Ensemble Ups	0	9	90
			TRP Ens. Shake After	0	9	91
			Big Band Brass 1	0	91	81
			Big Band Brass 2	0	91	82
			Big Band Brass 3	0	90	108
			Big Band Brass soft	0	90	109
			Real Brass Section 1	0	82	79
			Real Brass Section 2	0	82	80
			Fanfare 1	0	91	118
			Fanfare 2	0	91	119
			Miller Section	0	6	5
			Brass Power	0	6	38
			Brass & Strings	0	6	50
			Muted Trp ->Bläser	0	93	39
			TRP-TRO Stack	0	9	76
			Sax Stack	0	9	77
			Brass Stack	0	9	78
			Final Music	0	6	22
			Anthem Brass	0	6	55
			Pirates Score	0	6	64
			Brass Section Small	0	82	81
			Soul Section Loose	0	82	82
			Hybrid Staps	0	82	83
			Velo Stabs	0	82	84
			DX-Beta Brass	0	10	73
			KW Brass 1	0	12	17
			KW Brass 2	0	12	18
			Brass full JL	0	103	19
			GM062 Brass Section	0	89	62
		Film	Movie Brass Orchestra	0	8	31
			Movie Horns	0	8	33
			Movie Zimmer Horns 1	0	8	34
			Movie Zimmer Horns 2	0	8	35
			Movie Brass	0	8	39
			Movie Brass Artikulation	0	8	40
		Split	Jazz Saxo Brass Split	0	93	37

Klanggruppe	Bedienfeld	Bank	Klangname	LSB	MSB	PRG
Brass	Bläser	BB Live	BB1 Full Mix	0	106	1
			BB1 Full Mix Smooth	0	106	2
			BB1 Full Mix Sharp	0	106	3
			BB1 Mix Trumpets 1+2	0	106	4
			BB1 Mix Trumpets 1+2 Smooth	0	106	5
			BB1 Mix Trumpet-Trombone	0	106	6
			BB1 Mix Trumpet-Trombone Smooth	0	106	7
			BB1 Mix Trumpet-Saxophon	0	106	8
			BB1 Mix Trumpet-Saxophon Smooth	0	106	9
			BB1 Mix Sax-Trombone	0	106	10
			BB1 Mix Sax-Trombone Smooth	0	106	11
			BB1 Trumpet 1 normal	0	106	12
			BB1 Trumpet 1 Smooth	0	106	13
			BB1 Trumpet 1 Sharp	0	106	14
			BB1 Trumpet 2 normal	0	106	15
			BB1 Trumpet 2 Smooth	0	106	16
			BB1 Trumpet 2 Sharp	0	106	17
			BB1 Trombone	0	106	18
			BB1 Trombone Smooth	0	106	19
			BB1 Trombone Sharp	0	106	20
			BB1 Saxophon	0	106	21
			BB1 Saxophon smooth	0	106	22
			BB1 Saxophon Sharp	0	106	23
			BB2 Full Mix Normal	0	106	31
			BB2 Full Mix Smooth	0	106	32
			BB2 Full Mix Sharp	0	106	33
			BB2 Mix AltSax TenorSax Clarinet	0	106	34
			BB2 Mix AltSax TenorSax	0	106	35
			BB2 Mix AltSax TenorSax Smooth	0	106	36
			BB2 Mix Trumpet Altsax	0	106	37
			BB2 Mix Trumpet Altsax Smooth	0	106	38
			BB2 Mix Trombone TenorSax	0	106	39
			BB2 Mix Trumpet Trombone	0	106	40
			BB2 Mix Trumpet Trombone Smooth	0	106	41
			BB2 Trompeten Normal	0	106	42
			BB2 Trompeten Smooth	0	106	43
			BB2 Trombone Normal	0	106	44
			BB2 Trombone Smooth	0	106	45
			BB2 AltSax Normal	0	106	46
			BB2 AltSax Normal Stac	0	106	47
			BB2 AltSax Smooth	0	106	48
			BB2 TenorSax Normal	0	106	49
			BB2 TenorSax Normal Stac	0	106	50
			BB2 TenorSax Smooth	0	106	51
			BB2 Clarinets Normal	0	106	52
			BB2 Clarinets Smooth	0	106	53
			BB More Trumpet	0	106	61
			BB More Trombones	0	106	62
			BB More AltSax	0	106	63
			BB More TenorSax	0	106	64
			BB More Alt + TenorSax	0	106	65

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Brass	Saxophon	Tenor	Tenor Sax 1	0	9	97
			Tenor Sax 2	0	9	98
			Tenor Sax 3 Bostic	0	90	16
			Tenor Sax 3 Forte	0	90	68
			Tenor Sax 3 Warm	0	90	77
			Tenor Sax 4	0	7	59
			Tenor Sax 5	0	82	42
			Sax Eloise	0	6	86
			Sexy Sax	0	6	88
			Tenor Sax Zirkus	0	7	61
			Tenor Sax Smooth	0	7	62
			Sax Sweet	0	7	67
			Tenor Sax W Port	0	63	8
			Tenor Sax Bostic Port	0	63	9
			Tenor Sax F Port	0	63	10
			Tenor Sax Sweet	0	91	122
			Tenor Rock Sax	0	91	123
			Tenor Sax Legato	0	93	78
			Tenor Sax Live	0	93	92
			GM066 Tenor Sax	0	89	66
			Solo Tenor JL	0	103	23
		Alt	Alt Sax 1	0	9	92
			Alt Sax 2 Medium	0	90	17
			Alt Sax 2 Forte	0	90	78
			Alt Sax 3 Medium	0	93	60
			Alt Sax 4	0	82	43
			Alt Sax 5	0	7	66
			Alt Sax Zirkus	0	7	63
			Alt Sax F Port	0	63	11
			Alt Sax MF Port	0	63	12
			Alt Sax JL	0	103	6
			Alt Sax Down JL	0	103	20
			GM066 Alto Sax	0	89	67
		Other	Sopran Sax 1	0	90	58
			Sopran Sax 2	0	91	124
			Sopran Dream	0	91	125
			Sopran Sax Port	0	63	13
			Baritone Sax 1	0	91	29
			Baritone Sax 2	0	82	44
			CD-Tenor Sax	0	7	60
			KW Saxophone	0	12	9
			KW Tenor Sax	0	12	10
			KW BaritonSax	0	12	11
			GM065 Sopran Sax	0	89	65
			GM068 Baritone Sax	0	89	68
		<i>Lowrey Organ</i>	Lyrical Sax LW	0	105	28

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Brass	Saxophon	Ensemble	Tenor Sax Section	0	9	104
			Alt Sax Section	0	91	126
			Sax Section 1 MF	0	90	72
			Sax Section 2 F	0	91	80
			Sax Section 3	0	5	14
			Soft Sax Section 1	0	82	45
			Soft Sax Section 2	0	82	46
			Brighter Sax Section 1	0	82	47
			Brighter Sax Section 2	0	82	48
			Sax -> Brass 16	0	93	33
			Sax -> Brass 8	0	93	34
			Sax & Organ	0	93	35
		Layer	Miller Brass 1	0	90	105
			Miller Brass 2	0	84	70

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Brass	Flutes	Flute	Flute Transverse 1	0	93	81
			Flute Transverse 2	0	9	106
			Flute Transverse 3	0	93	21
			Flute Transverse 4	0	90	19
			Marching Band	0	6	67
			Flute	0	82	52
			Flute Tremolo Fade	0	82	53
			Flute Tremolo Switch	0	82	54
			Flute Vibrato	0	82	55
			KW E-Flute	0	12	5
			KW Flute	0	12	6
			KW Piccolo	0	12	7
			GM074 Flute	0	89	74
			Piccolo Flute 1	0	91	31
			Piccolo Flute 2	0	82	56
			GM073 Piccolo	0	89	73
			Piccolo Flute JL	0	103	7
		Pan Flute	Pan Flute 1	0	90	20
			Pan Flute 2	0	93	19
			Pan Flute Horea	0	9	99
			Pan Flute Horea Delay	0	9	100
			Pan Flute Horea Soft 1	0	9	101
			Pan Flute Horea Soft 2	0	9	102
			Pan Flute Horea Soft 3	0	9	103
			Pan Flute Vibrato	0	7	64
			Pan Flute Wild	0	7	65
			Pan Flute & Synthe	0	91	78
			Pan Flute Tibetan	0	9	109
			Pan Flute Tibetan Art	0	9	110
			GG-Pan Flute	0	91	18
			KW Pan Flute	0	12	8
			GM076 Pan Flute	0	89	76
			Zamfir Flute JL	0	7	68
		Other	Recorder	0	91	32
			GM075 Recorder	0	89	75
		Lowrey Organ	Flute Ballad LW	0	105	29
			Calliope LW	0	105	30
			Recorder LW	0	105	31

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Brass	Woodwinds	Clarinet	Clarinet 1	0	90	18
			Clarinet 2	0	93	41
			Clarinet Swing	0	93	80
			Clarinet Sweet	0	93	20
			Clarinet Smooth	0	9	105
			Clarinet Concert	0	82	49
			Clarinet Bass	0	82	50
			Clarinet Port	0	63	7
			KW Clarinet	0	12	12
			GM072 Clarinet	0	89	72
		Orchest.	Oboe 1	0	90	21
			Oboe 2	0	8	38
			Bassoon 1	0	91	30
			Bassoon 2	0	82	51
			English Horn 1	0	90	97
			English Horn 2	0	8	65
			Orchestra Woodwinds 1	0	8	36
			Orchestra Woodwinds 2	0	8	37
			CD-Oboe	0	91	16
			CD-English Horn	0	91	17
			GM069 Oboe	0	89	69
			GM070 English Horn	0	89	70
			GM071 Bassoon	0	89	71
	Other Woodwinds	World	Bag Pipe	0	7	114
			Bag Pipe Grace	0	7	115
			Bag Pipe Duett	0	7	116
			Bag Pipe Band Tuned	0	91	67
			Oboe Shehnai	0	9	114
			Flute Native American	0	9	115
			Flute Erhu	0	9	116
			Flute Celtic	0	9	117
			Flute Enigma	0	10	75
			Shakuhachi	0	91	34
			Skakuhachi Solo	0	91	35
			Ocarina	0	91	37
			Shanai	0	91	69
			GG-Schalmei	0	91	97
			GM078 Shakuhachi	0	89	78
			GM080 Ocarina	0	89	80
			GM110 Bag Pipe	0	89	110
		Other	Whistle	0	91	36
			Bottle	0	91	33
			Whistle Port	0	63	21
			CD-Whistle 1	0	10	69

1.6 Vocals

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Choir Vocals	Choir	Church	Choir Mixed	0	90	86
			Choir Mixed & Boys	0	90	87
			Choir Boys	0	90	88
		Normal	Agnus "Dei"	0	60	35
			Gregorian Choir	0	60	36
			Choir Aah Woman	0	93	84
			Choir Ooh Woman	0	93	85
			Choir Synthe 1	0	90	126
			Choir Synthe 2	0	9	59
			Choir Oooh	0	9	58
			Choir Aah 1	0	93	83
			Choir Aah 2	0	9	60
			Choir Mixed	0	90	37
			Choir Opera	0	93	86
			Solist Choir	0	9	51
			Solist Choir Effect	0	9	52
			Choir Digital-Synthe	0	81	71
			Choir Spaced	0	81	72
			Choir Heaven	0	81	73
			Choir Dark	0	81	75
			Choir Reverse	0	81	76
			Choir Art	0	81	77
			Choir Attack	0	81	79
			Choir Belltime	0	81	80
			Choir Soft Sweeper	0	81	81
			Choir & Solo	0	91	79
			Choir & Bells	0	91	89
		Lowrey Organ	Arail	0	81	78
			GM053 Choir Aahs	0	89	53
			GM054 Voice Oohs	0	89	54
			Xtra Choir LW	0	105	36
			Xtra Choir Itopia LW	0	105	37
			Choir Aah (Far) LW	0	105	38
			Choir Aah (Near) LW	0	105	39

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Choir Vocals	Vocal	Jazz	Jazz Vocal Baah	0	90	89
			Jazz Vocal Dooh	0	90	90
			Jazz Vocal Mixed	0	90	91
			Jazz Vocal Mixed & Bass	0	90	92
			Jazz Vocal Bass	0	90	93
			Duh Vocal	0	90	43
			Duh Vocal Octave	0	84	101
			Aah Vocal	0	9	44
			Aah Vocal More	0	9	45
			Aah Vocal & Mixed	0	9	46
			Aah Vocal & Mixed & Boys	0	9	47
			Aah Vocal & Mixed Mono	0	9	48
			Africa Vocal 1	0	9	49
			Africa Vocal 2	0	9	50
			Dum Bass short	0	9	42
			Dum Bass long	0	9	43
			Vocal Dow JL	0	103	27
		Other Choirs	Vocal Girl Effect	0	90	12
			Vocal Girl Sustain	0	90	103
			Angel	0	90	67
			Miss Streisand	0	6	81
			KW Soprano	0	12	4
			GG-Synvocal	0	91	19
			GM055 Synthe Voice	0	89	55
			GM092 Pad 4 (choir)	0	89	92
			Choir Ah JL	0	103	9
			Solo Sopran JL	0	103	18
		Solo	Tenor Solo	0	9	53
			Tenor Group	0	9	54
			Sopran Solo	0	9	55
			Sopran Group	0	9	56
			Opera Group	0	9	57
			Girl Port	0	63	22
			Duett JL	0	103	36

1.7 Church/Theatre

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Church Theatre	Church	Plenum	Church Plenum 1	0	60	19
			Church Plenum 2	0	60	20
			Church Plenum 3	0	60	21
		Tutti	Church Tutti 1	0	93	50
			Church Tutti 2	0	93	51
			Church Tutti 3	0	90	49
			Church Tutti 4	0	90	50
			Church Tutti 5	0	93	48
			Church Vatikan	0	90	48
			GM020 Church Organ	0	93	49
		Single	Church Bourdon	0	60	1
			Church Cornet	0	60	3
			Church Duciana	0	60	4
			Church Flute 4	0	60	5
			Church Flute Celeste	0	60	6
			Church Gamba	0	60	7
			Church Gedackt 16	0	60	9
			Church Gedackt 8	0	60	8
			Church Clarinet	0	60	2
			Church Nasard	0	60	15
			Church Oboe	0	60	16
			Church Octave	0	60	17
			Church Principal 16	0	60	24
			Church Principal 4 a	0	60	49
			Church Principal 4 b	0	60	22
			Church Principal 8	0	60	23
			Church Quint 2 2-3	0	60	25
			Church Regal 16	0	60	26
			Church Reed Flute 1	0	60	27
			Church Reed Flute 2	0	60	50
			Church Reed Gedackt	0	60	18
			Church Super Oktave	0	60	28
			Church Terts	0	60	29
			Church Trumpet	0	60	30
			Church Voix Celeste	0	60	31
			Church Bells	0	60	128
		Layer	Church Tutti & Chor	0	93	52
			Church Mixed & Chor	0	93	53
		Mixture	Church Mixed 1	0	93	51
			Church Mixed 2	0	93	50
			Church Mixed 3	0	93	49
			Church Mixture 1	0	60	10
			Church Mixture 2	0	60	11
			Church Mixture 3	0	60	12
			Church Mixture 4	0	60	13
			Church Mixture 5	0	60	14
	Live Church	Silbermann	Silbermann Oberwerk	0	60	49
			Silbermann Manual	0	60	50
			Silbermann Pedal	0	60	51

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Church Theatre	Theatre	Blackpool	BP Piston 2	0	61	21
			BP Piston 3	0	61	22
			BP Piston 4	0	61	23
			BP Piston 5	0	61	24
			BP Piston 10	0	61	25
			BP GT66	0	61	26
			BP GTR5 Solo	0	61	27
			BP Bold Ranks 1	0	61	38
			BP Bold Ranks 2	0	61	39
			Broadway	0	6	91
	Combis	Combis	Theatre Big Pipes	0	6	92
			TH Mixed 1	0	61	17
			TH Mixed 2	0	61	18
			TH Mixed 3	0	61	19
			TH Mixed 4	0	61	20
			Theater Organ & Choir	0	93	54
			Grand Theatre	0	6	46
	Normal	Normal	Smooth Theatre	0	6	90
			TH Barton Full	0	61	1
			TH Barton Melo 1	0	61	2
			TH Barton Melo 2	0	61	3
			TH Big Pipes	0	61	4
			TH Bold Brass	0	61	5
			TH Full Brass	0	61	6
			TH Melo 1	0	61	7
			TH Melo 2	0	61	8
			TH Barton Tibias	0	61	9
			TH Morton-Str-Wurl.	0	61	10
			TH Morton-StrVox-Wurl.	0	61	11
			TH Robert Morton	0	61	12
			TH Wurlizer-Morton	0	61	13
			TH Wurl.-Morton-Barton	0	61	17
			TH Wurl.Bx-Morton	0	61	15
			TH Morton Strings	0	61	16
			Theater Tibia 8	0	90	69
			Theater Organ	0	90	70
			Theater Strings	0	90	71
			Theatre Sustain	0	90	73
			Theater Kinura	0	90	74
			Theatre Diaphone	0	90	75
			Theater Strings Sustain	0	93	56

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Church Theatre	Theatre	<i>Lowrey Organ</i>	Tibia 16 LW	0	105	81
			Tibia 8 LW	0	105	82
			Tibia 4 LW	0	105	83
			Tibia 8 + 4 LW	0	105	84
			Tibia Combination LW	0	105	85
			Reed 16 LW	0	105	86
			Reed 8 LW	0	105	87
			Reed 16 + 8 LW	0	105	88
			Post Horn 16 LW	0	105	89
			Post Horn 8 LW	0	105	90
			Post Horn 16 + 8 LW	0	105	91
			Post Horn 16 + Tibia 8 LW	0	105	92
			Kinura 8 LW	0	105	93
			Kinura 8 + Tibia 4 LW	0	105	94
			Diapason 4 LW	0	105	95
			Diapason 8 + 4 LW	0	105	96
			Vox Humana 16 LW	0	105	97
			Vox Humana 8 LW	0	105	98
			Vox Humana 16 + 8 LW	0	105	99
			Vox 8 + Tibia 4 LW	0	105	100
			Vox 8 + String 8 LW	0	105	101
			Vox 16 + Tibia 8 LW	0	105	102
			Vox 16 + String 16 LW	0	105	103
			Viole Celeste 16 LW	0	105	104
			Viole Celeste 8 LW	0	105	105
			Viole Celeste 16 + 8 LW	0	105	106
			Viole 16 LW	0	105	107
			Viole 8 LW	0	105	108
			Viole 16 + 8 LW	0	105	109
	Drums		Theater Drums	0	90	75
			Theater Tambo	0	105	121

1.8 Guitars

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Guitar	Acoustic	Concert	Natural Guitar 1	0	90	5
			Natural Guitar 1 Slide	0	93	100
			Natural Guitar 2	0	90	80
			Spain Guitar	0	93	107
			Concert Guitar	0	9	31
			Concert Guitar Slide	0	9	32
			Eco Guitar 1	0	11	2
			Eco Guitar 2	0	11	3
			Nature Guitar Nylon Finger	0	82	1
			Nylon Finger & Harm.	0	82	2
			Nylon1 & Harmonic & Ham.	0	82	3
			Nylon Finger Bright	0	82	4
			Finger Plucker	0	82	5
			Nylon Pick	0	82	6
			Nylon 2 & Harmonics & Ham.	0	82	7
			Nylon & Steel Hybrid	0	82	10
			Nylon Port	0	63	14
			CD-Acoustic Guitar 2	0	9	119
			CD-Acoustic Guitar 1	0	10	72
			GM025 Nylon Guitar	0	89	25
		<i>Lowrey Organ</i>	Flamenco Guitar 1 LW	0	105	7
			Flamenco Guitar 2 LW	0	105	8
		Steel	Steel Guitar 1	0	91	84
			Steel Guitar 2	0	93	106
			Steel Guitar 3	0	82	8
			Western Guitar 1	0	90	81
			Western Guitar 2	0	93	59
			St.String & Harmonics	0	82	9
			GM026 Steel Guitar	0	89	26
		12String	Other 12 String	0	5	22
			12 String Washy	0	82	11
			24 String Guitar	0	82	12
			12 String Atmos Pad	0	82	14
			12 String Guitar 1	0	90	82
			12 String Guitar 2	0	91	85
			12 String Guitar 3	0	6	23
			12 String Folk Gitarre	0	93	105
		Other Guitars	Mandoline 1 Tremolo 1	0	90	83
			Mandolin 1 Trem Sustain	0	7	46
			Mandoline 2	0	8	56
			Mandoline 2 Solo	0	8	55
			Mandoline 2 Tremolo	0	8	57
			Mandolin 1 Tremolo 2	0	6	37
			Mandolinen Orchestra	0	90	84
			Balalaika	0	8	58
			Balalaika Tremolo	0	8	59
			Mandolaika Tremolo	0	8	60
			Ukelele	0	8	61
			Banjo 1	0	91	63
			Banjo 2	0	84	28
			Zither 1	0	90	26
			Zither 2	0	90	85
			Dulcimer	0	90	45
			Shamisen	0	91	64
			Sitar	0	91	62

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Guitar	Natur	Other Guitars	Akustic Jazz Git	0	5	16
			KW 12 String Guitar	0	12	24
			GM105 Sitar	0	89	105
			GM106 Banjo	0	89	106
			GM107 Shamisen	0	89	107
			GM112 Shanai	0	89	112
		<i>Lowrey Organ</i>	Dobro Guitar LW	0	105	9
			Lute Guitar LW	0	105	10
			Ukelele LW	0	105	11
			Banjo LW	0	105	12
			Mandolin 1 LW	0	105	13
			Mandolin 2 LW	0	105	14
			Mandolin Orchestra LW	0	105	15
		Layer	12 String Guitar Pad	0	6	10
			SteelString & Atmos Pad	0	82	13
			Stereo Guitar Acc	0	7	44
			Nylon Guitar Acc	0	7	45

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Guitar	E-Guitar	Clean	E-Guitar Stratocaster	0	90	79
			E-Guitar Muted	0	90	119
			E-Guitar Clean	0	90	120
			E-Guitar Ricky	0	93	94
			E-Guitar Solid	0	93	108
			E-Guitar Telecaster	0	93	109
			Muted Guitar	0	6	6
			Fender Strat 1	0	7	47
			Fender Strat 2	0	7	48
			Fender Strat Chorus	0	7	49
			Strat Clean	0	82	15
			Strat & Harmonics & Ham.	0	82	16
			Strat Chorus	0	82	17
			Strat Tremolo	0	82	19
			Strat Harmonics	0	82	20
			Strat Muted Velo	0	82	21
			Clean Chord Guitar	0	6	68
			Stratocaster without Vibrato	0	93	98
			E-Guitar Strumming	0	5	1
			Steel Chords Velo	0	5	2
			All Steel Chords	0	5	3
			Steel Git Chords MJ	0	5	4
			Steel Git Chords MIN	0	5	5
			Steel Git Chords MJ7	0	5	6
			Steel Git Chords SUS	0	5	7
			Steel Git Chords 5+	0	5	8
			Steel Git Chords DIM	0	5	9
			Acc Clean Strat	0	6	3
			Stratocaster Port	0	63	17
			GG-Muted Guitar	0	7	42
			GM027 Jazz Guitar	0	89	27
			GM028 Electric Guitar	0	89	28
			GM029 Muted Guitar	0	89	29
			GM032 Harm. Guitar	0	89	32
		WahWah	Strat Wah	0	82	18
			Strat Muted Wah	0	82	22
			Lead Gitarre Wah	0	82	30
			E-Guitar WahWah	0	93	110

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Guitar	E-Guitar	Overdrive	E-Guitar Hardrock	0	82	26
			E-Guitar Distortion	0	90	122
			Overdriven Guitar	0	90	121
			Power Chords 1	0	5	13
			Power Chords 2	0	5	18
			Green Rock Guitar	0	5	12
			Amp Guitar	0	5	17
			Blues Chord Git	0	5	20
			Overdriven Gitarre Port	0	63	20
			Strat Glam	0	82	25
			Strat Grunge	0	82	27
			Strat Metal Stack	0	82	28
			Lead Guitar	0	82	29
			Lead Guitar Licks	0	82	31
			Dist. Guitar JL	0	103	16
			GM030 Overdr. Guitar	0	89	30
			GM031 Distor. Guitar	0	89	31
	Other E-Guitars		Jazz Guitar 1	0	90	6
			Jazz Guitar 2 Octave	0	84	25
			Jazz Guitar 3	0	6	101
			Jazz Guitar 4	0	5	11
			Jazz Guitar 5	0	5	19
			Jazz Guitar Django	0	93	91
			Jazz Guitar FM	0	82	24
			Hawaii Guitar	0	90	47
			Pedal Steel Guitar	0	93	101
			Pedal Steel Slide Guitar	0	93	102
			Synthe Guitar	0	82	23
			Lead Atmos & Pad	0	82	32
			Jazz Guitar Port	0	63	15
			CD-Jazz Guitar Port	0	63	16
			Comet Guitar Port	0	63	18
			Hawaii Guitar Port	0	63	19
			Comet Guitar	0	91	24
			CD-Jazz Guitar 1	0	10	67
			CD-Jazz Guitar 2	0	91	4
	Split		KW Django Guitar	0	12	25
			KW Rhythmus Guitar	0	12	26
			KW Plek. Guitar	0	12	27
	Split		Organ Stratocaster	0	7	92
			Jazz Guitar Split	0	93	38
			Jazz Git. ->Bläser	0	93	40

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Guitar	Bass	Acoustic	Acoustik Bass 1	0	90	35
			Acoustik Bass 2	0	90	94
			Acoustik Bass 3	0	5	15
			Acoustik Bass4	0	6	12
		Electric	Fat Acoustic Bass	0	82	63
			Punchy Acoustic Bass	0	82	64
			CD-Acoustik Bass	0	91	6
			GM033 Acoustic Bass	0	89	33
			Bass Guitar 1	0	90	34
			Bass Guitar 2	0	6	42
			Bass Guitar 3	0	6	58
			Picked Bass 1	0	7	90
			Picked Bass 2	0	82	65
			Picked Bass 3	0	82	66
			Finger Bass	0	7	91
			Finger Jazz Bass	0	82	67
			Finger P Bass	0	82	68
			Bass Guitar Cool	0	9	111
			Bass Guitar Picked	0	9	112
			Bass Guitar Unplugged	0	9	113
			Slap Bass	0	82	69
			Fretless Bass	0	82	70
			Fender Rock Bass	0	5	10
			Double Bass	0	6	96
			Bass Slide	0	82	71
			GM034 Finger Bass	0	89	34
			GM035 Picked Bass	0	89	35
			GM036 Fretles Bass	0	89	36
			GM037 Slap Bass 1	0	89	37
			GM038 Slap Bass 2	0	89	38
			Bassist JL	0	103	44
			Bass Guitar SGP150	0	9	121
			Stringbass SGP150	0	9	122
		Synthe	Disco Bass 1	0	82	77
			GM039 Synthe Bass 1	0	89	39
			GM040 Synthe Bass 2	0	89	40
		Pedal	Pedal Bass 1	0	90	36
			Pedal Bass 2	0	90	64
			Pedal Bass 3	0	9	127
			Akustikbass 1 Pedal	0	91	127
			Akustikbass 2 Pedal	0	90	95
			Fingerbass Pedal	0	93	1
			Picked Bass Pedal	0	93	2
			Pedal Bass SGP150	0	9	120
			Pedal Bass EKU	0	9	108
			Pedal Bass Perc EKU	0	9	107
			Pedal Bass & Kesselpauke	0	93	61
			Pedal Bass & Strings 1	0	93	62
			Pedal Bass & Strings 2	0	93	63
			Pedal Bass & Orchester	0	93	64

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Guitar	Bass	Pedal	Pedal Bass & Tuba	0	93	65
			Pedal Bass & Sinus	0	93	66
			Synthe Bass Pedal	0	93	3
			KW CD-Bass	0	12	29
			CD-Zupfbass Pedal	0	91	7
			Synthe Bass Ped. JL	0	103	13
			Bass Ped. JL	0	103	17
	<i>Lowrey Organ</i>		Pedal Bass LW	0	105	78
			Pedal Pick LW	0	105	79
			Pedal Deep LW	0	105	80
			Pedal Ensemble LW	0	105	81
			Pedal Diaphone LW	0	105	82

1.9 Percussion

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Percussion	Mallet	Vibes	Vibraphon 1	0	90	2
			Vibraphon 2	0	90	66
			Vibraphon Dark	0	6	102
			Vibraphon Bright	0	7	54
			Vibraphon Warm	0	81	50
			Vibraphon Stereo	0	81	51
			Vibraphon Tremolo	0	93	57
			CD-Vibraphone	0	10	66
			GM012 Vibraphone	0	89	12
		Marimba	Marimba 1	0	7	55
			Marimba 2	0	90	116
			Marimba 3	0	81	52
			Marimba Bass	0	81	53
			Marimba Repeat	0	93	103
			Kalimba	0	91	66
			GG-Marimba	0	91	23
			GM013 Marimba	0	89	13
		Other Percussion	Xylophon	0	7	53
			Xylophon Stereo	0	7	51
			Xylophon Metall	0	81	54
			Xylophon Octave	0	81	55
			Xylophon Hood	0	90	57
			Zirkus Renz	0	6	69
			Koto	0	91	65
			Steeldrum 1	0	91	71
			Steeldrum 2	0	81	56
			Steeldrum 3	0	81	57
			Karibik	0	91	83
			CD-Xylophon	0	7	52
			KW Steeldrums	0	12	32
			GM014 Xylophone	0	89	14
			GM016 Dulcimer	0	89	16
			GM108 Koto	0	89	108
			GM109 Kalimba	0	89	109
			GM115 Steel Drums	0	89	115
		Layer	Percussive & Strings	0	6	61

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Percussion	Bell	Normal	Celesta	0	90	11
			Musicbox	0	90	115
			Orchestra Chimes	0	8	54
			Bells Short	0	6	100
			GM009 Celesta	0	89	9
			GM010 Chimes	0	89	10
			GM011 Music Box	0	89	11
		Tubular	Tubular Bells Wood	0	90	117
			Tubular Bells Metall	0	81	60
			Tubular Bells Chimney	0	81	61
			Tubular Bells Double	0	81	59
			GM015 Tubular Bells	0	89	15
		Other	Schlager Bells	0	6	2
			Just Bells	0	6	28
			Bells & Strings	0	6	29
			Dynamic Bells	0	6	51
			Beauty & Beast	0	6	52
			Xanadu Bells	0	6	84
			All Bellz	0	81	58
			Melody Bells	0	81	62
			Hold Bell Layer	0	81	63
			Wheel Adjust Bell	0	81	64
			Tinker Bells	0	81	65
			Tinkle Bells	0	91	70
			Dreamharp	0	90	29
			Pretty Bells	0	81	66
			Chime Bells	0	81	67
			Chimey Bells Soft	0	81	68
			Viborbellz Cascade	0	81	69
			Special Bells Pad	0	81	70
			GM113 Tinkle Bell	0	89	113
		Lowrey Organ	Bells Repeat LW	0	105	16
			Musicbox LW	0	105	17
			Carrillon LW	0	105	18
			Woodblock LW	0	105	19
			Glockenspiel LW	0	105	20
			Hand Bells LW	0	105	21
		Synthe	Roland	0	90	28
			Dreaming	0	90	42
			Crystal	0	91	56
			Big Wave Bells	0	73	87
			Chimes Bright	0	73	93
			GG-Fusion	0	91	20
			GG-PercEcho	0	91	22
			GM099 FX 3 (crystal)	0	89	99

1.10 Piano

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Piano	Acoustic Piano	Software 3.0	Grand Standard	0	107	1
			Grand weich	0	107	2
			Bar Grand	0	107	3
		Grand Piano	Grand Piano 1a	0	9	1
			Grand Piano 1b	0	9	2
			Grand Piano 1 Closed	0	9	3
			Grand Piano 1 Octave	0	9	5
			Grand Piano 2	0	81	1
			Grand Piano 2 Bright	0	81	2
			Grand Piano 2 Soft	0	81	3
			Grand Piano 2 Hard	0	81	4
			Grand Piano 2 Concert Hall	0	81	5
			Grand Piano Pop	0	90	1
			Grand Piano Pop Bright	0	90	110
			Grand Piano Pop Oktave	0	91	72
			Grand Piano Pop Warm	0	93	90
			The Grand Piano 1	0	5	21
			The Grand Piano 2	0	5	23
			Grand Piano C7	0	9	8
			Grand Piano S-Way	0	9	9
			Grand Piano 3 Natural	0	70	1
			Grand Piano 3 Bright	0	70	2
			Grand Piano 3 Soft	0	70	3
			Grand Piano 3 Hard	0	70	4
			Grand Piano 3 Concert Hall	0	70	5
			Grand Piano 3 Mono	0	70	7
			Grand Piano 3 Simple	0	70	8
			Piano Ballad	0	6	65
			Piano Jazz	0	8	121
			Grand Piano California	0	81	17
			GM001 Acoustic Grand	0	89	1
			GM002 Bright Grand	0	89	2
		Klavier Software 3.0	Piano Upright	0	81	8
			Piano Standard	0	107	11
			Piano Resonance	0	81	14
			Piano LA Warm	0	81	15
			Piano LA Hard	0	81	16
			Piano Phaser	0	81	10
			Piano Steele Hammer	0	81	19
			Piano House	0	81	7
			Piano Ol Upright	0	70	9
			Piano 70s	0	6	72
			Honky Tonk Standard	0	107	16
			Honky Tonk 1	0	9	4
			Honky Tonk 2	0	90	111
			Honky Tonk 3	0	81	9
			Honky Tonk 4	0	70	10
			Honky Man	0	6	70
			CD-Piano	0	7	50
			Organ-Piano	0	7	93
			KW Piano 1	0	12	30
			KW Piano 2	0	12	31
			GM004 Honky Tonk	0	89	4

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Piano	Acoustik	Lowrey Organ	Society Piano LW	0	105	1
			Piano Mellow LW	0	105	2
			Old Upright Piano LW	0	105	3
			Toy Piano LW	0	105	4
			Honky Tonk 1 LW	0	105	5
			Honky Tonk 2 LW	0	105	6
	Piano & Strings	Piano & Strings	Grand Piano 1 & Strings	0	9	6
			Grand Piano 1 & Solo Strings	0	9	7
			Piano & Strings	0	91	92
	Piano Layer	Piano Layer	Piano Pad	0	6	8
			Piano Atmos 1	0	70	6
			Piano Phaser	0	70	11
			Piano Euro Ar	0	70	12
			Piano Gater	0	70	13
			Piano Sparkle	0	70	14
			True Sustain As Hall	0	70	15
			Piano Gramophone	0	70	16
			Piano Underwater	0	70	17
			Piano Gurgler Pulse	0	70	18
			Piano Rotor	0	70	19
			Depressed Mode	0	70	20
			Piano Trents	0	70	21
			Piano Toy	0	70	22
			Piano Asian Box	0	70	23
			Piano Wah Wah	0	70	24
			Piano Atmos 2	0	81	6
			Piano Heaven	0	81	18
			Piano & Dreams	0	90	96
			Piano & Vocals	0	91	74
	Split	Jazz Piano Split		0	93	36

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Piano	Elektric Piano	Rhodes	E-Piano 1	0	90	4
			E-Piano 2	0	91	100
			E-Piano 3	0	90	3
			E-Piano Vintage	0	81	21
			E-Piano Gentle Vintage	0	81	22
			E-Piano Soft Vintage	0	81	23
			E-Piano Sweet	0	81	38
			E-Piano Fantasy	0	91	96
			EP Rhodes Mark I	0	91	94
			EP Rhodes Mark II	0	91	95
			EP Rhodes	0	81	24
			EP Rhodes Chorus	0	6	32
			EP Paddy Roads	0	81	25
			EP Ultra Hard Vintage	0	81	26
			EP Vintage Amped	0	81	27
			EP Wurlitzer Amped	0	81	32
			EP Hybrid Stage Piano	0	81	33
			EP Dyno Stage	0	81	34
			EP Dyno Chorus	0	81	36
			EP Spectral	0	81	20
			EP Nice Tyne	0	81	39
			EP Metal Tyne	0	81	40
			EP Smooth	0	91	99
			EP Fusion	0	81	28
			EP Belly	0	81	41
			EP Nastichord	0	81	48
			EP Phaserichord	0	81	49
			CD-Stage Piano	0	9	118
			GM005 E-Piano 1	0	89	5
			GM006 E-Piano 2	0	89	6
		Wurlitzer	EP Wurlitzer	0	81	29
			EP Wurlitzer warm	0	81	30
			EP Wurlitzer Chorus	0	6	75
			EP Vintage Road & Wurli	0	81	31
			EP Synth Wurli	0	81	35
		Electric-Piano	Elektrik Grand 1	0	90	112
			Elektrik Grand 2	0	91	73
			Elektrik Grand 3	0	81	11
			Elektrik Grand Warm	0	81	12
			CD-E-Stage	0	10	68
			GM003 Electric Grand	0	89	3
		FM-Piano	Impact House Piano	0	6	83
			EP Electro Rhodes	0	73	67
			Elektrik Piano FM	0	81	37
		Layer	E-Piano Bells	0	91	101
			E-Piano Pad	0	91	102
			Rhodes Pad	0	6	9
			Elektrik Grand Atmos	0	81	13

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Piano	Elektric Piano	Clavinet	Clavinet 1	0	90	114
			Clavinet 1 Stereo	0	91	98
			Clavinet 2	0	81	42
			Clavinet 2 Stereo	0	81	43
			Clavinet 2 Chorus	0	81	44
			Clavinet 2 WahWah	0	81	45
			GM008 Clavinet	0	89	8
		Harpsichord	Harpsichord 1	0	90	113
			Harpsichord 1 Octave	0	6	47
			Harpsichord 2	0	6	60
			Harpsichord Italia	0	81	46
			Harpsichord & Octave	0	81	47
			CD-Harpsichord	0	91	13
			CD-Harpsichord Sustain	0	10	71
			GM007 Harpsichord	0	89	7

1.11 Strings

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Strings	Solo	Violin	Violin 1	0	90	9
			Violin 2	0	90	102
			Violin Solo 1	0	91	117
			Violin Solo 2	0	6	99
			Violin Fiddle	0	91	68
			Violin Gipsy	0	93	93
			Violin Port	0	63	23
			CD-Violin	0	91	1
			KW Violin	0	12	22
			GM041 Violin	0	89	41
			GM111 Fiddle	0	89	111
		Viola	Viola	0	90	123
			GM042 Viola	0	89	42
		Cello	Cello 1	0	90	124
			Cello 2	0	8	25
			Cello 3	0	8	112
			GM043 Cello	0	89	43
		Bass	Contrabass	0	91	93
			GM044 Contrabass	0	89	44
		Layer	Violins Solo	0	8	21
			Violins Solo Long	0	8	22
			Violins Solo Vibrato	0	8	23
			Violin & Strings	0	91	111
			2 Violins	0	91	116
Strings	Ensemble	Ensemble	Strings 1	0	8	3
			Strings 2	0	8	4
			Strings Classic 1	0	8	10
			Strings Classic 2	0	8	11
			Strings Full	0	8	9
			Strings Mantovani	0	91	103
			Strings Orchestra	0	93	82
			Strings Marcato	0	82	94
			Strings High	0	6	85
			Strings Classical Small	0	93	97
			Strings Pop	0	82	87
			Strings Pop & Pad	0	82	88
			Strings Legato 1	0	8	2
			Strings Legato 2	0	8	24
			Strings Ensemble Legato	0	8	52
			Strings Organ 1	0	90	7
			Strings Organ 2	0	93	120
			Strings 1 Sustain	0	91	104
			Strings 2 Sustain	0	82	89
			Strings Sustain Octave	0	82	90
			Strings Sustain & Syncvoc	0	82	91
			Strings Bass	0	93	95
			Strings Hollywood 1	0	8	29
			Strings Hollywood 2	0	6	30
			Strings Cinematic	0	8	28
			Grand Movie Score	0	6	16
			Big Score	0	6	18
			Strings Score	0	6	24
			Strings Marc	0	6	33

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Strings	Strings	Ensemble	Strings Xmas	0	6	36
			Higher & Higher	0	6	59
			Vienna Waltz Strings	0	6	62
			Strings Lush	0	8	30
			Strings Acro	0	8	12
			Chamber Strings	0	8	13
			Strings Sordino	0	8	14
			Strings Symphonie	0	8	15
			Strings Warm Pad	0	82	97
			CD-Strings	0	10	65
			KW Strings	0	12	21
			KW Mantovani Str.	0	12	19
			KW Symphonic Str.	0	12	20
			Strings 1 JL	0	103	25
			Strings 2 JL	0	103	22
			Strings 3 JL	0	103	47
			Strings 1 Acc. JL	0	103	46
			Strings 2 Acc. JL	0	103	45
			Strings Strong JL	0	103	11
			GM049 Strings 1	0	89	49
			GM050 Strings 2	0	89	50
		Solo	Chamber Solo	0	8	7
			Chamber Staccato	0	8	8
			Staccato Strings Marcando	0	8	19
			Staccato Strings	0	8	20
			Strings Attack 1	0	90	8
			Strings Attack 2	0	90	44
		Tremolo	Strings Tremolo 1	0	91	106
			Strings Tremolo 2	0	8	5
			Strings Tremolo 3	0	82	92
			GM045 Tremolo Strings	0	89	45
		Pizzicato	Pizzikato Strings 1	0	93	23
			Pizzikato Strings 2	0	8	6
			Pizzikato Strings 3	0	90	51
			Pizzikato Strings 4	0	82	93
			KW RHG Pizzicato	0	12	28
			GM046 Pizzicato Str.	0	89	46
			Pizzikato Strings JL	0	103	34
		Layer	Strings & Horns	0	91	112
			Strings & Bells	0	91	90
			Strings & Vocal	0	91	105
			Strings & Harp	0	91	107
			Strings & Pizzikato	0	91	108
			Strings Living Bell	0	6	56
			Legato Str. & Chamber Str.	0	8	26
			Legato Str. & Chamber Solo	0	8	27
			Legato -> Tremolo Wheel	0	82	95
			Legato Str. & Pizz -> Wheel	0	82	96
			Orchestra & Horns	0	82	98
			Strings Violins	0	91	109
			Strings Violins Att	0	91	110
			Strings Velocity Att	0	93	22

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Strings	Orchestra	Full	Orchestra Full	0	8	18
			Orchestra Huge	0	6	98
			Orchestra Tutti	0	82	100
			Orchestra & Timpani	0	90	41
			Orchestra Bass 1	0	8	53
			Orchestra Bass 2	0	6	95
			Orchestra Staccato	0	8	16
			Orchestra Staccato Perc	0	8	17
			Grand Chorus	0	6	97
			Rock Symphony	0	6	34
			Grand Final	0	6	53
			Orchestra Emporio	0	6	54
			Andr's Orchestra	0	6	66
			Orchestra Impact	0	6	73
			KW Orchester	0	12	23
		Software 3.0	Streichorchester	0	107	21
			Streichorchester Spiccato	0	107	22
			SoloStrings	0	107	23
		Lowrey Organ	Strings Ensemble 1 LW	0	105	40
			Strings Ensemble 2 LW	0	105	41
			Strings Ensemble 3 LW	0	105	42
			Strings Warm LW	0	105	43
			Strings Crescendo LW	0	105	44
			Strings Octave LW	0	105	45
			Strings Sforzando LW	0	105	46
			Strings Sustain LW	0	105	47
			Strings Slow Sustain LW	0	105	48
		Kammer	Orchestra Mozart	0	6	49
			Barock Ensemble	0	6	78
			Orchestra Veneziano	0	6	79
			Oboe & Basson & Strings	0	91	113
			Orchestra Rondo	0	91	114
		Software 3.0	Chamber Orchestra	0	107	24
			Chamber Orchestra	0	107	25
		Brass/Wood	Brass Orchestral	0	6	25
			Movie Strings & Vocals	0	8	32
			Brass Orchestra 1	0	91	115
			Brass Orchestra 2	0	82	99
		Hits	Hit Orchestra	0	91	27
			Hit Big Orchestra	0	81	82
			Hit Long Orchestra	0	81	83
			Hit Fat	0	81	84
			Hit Cluster	0	81	85
			Hit Italo	0	81	86
			GG-Hit	0	7	113
			GM056 Orchestra Hit	0	89	56
		Harp	Harp	0	90	125
			Harp 1 Orchestra	0	8	41
			Harp 2 Orchestra	0	6	71
			GM047 Harp	0	89	47
		Layer	Dance River	0	6	39
			Orchestra & Piano	0	6	80

1.12 Synthesizer

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Synthesizer	Synthe Lead	Soft	Lead Square	0	91	38
			Calliope	0	91	40
			Bass & Lead	0	91	45
			Dull Square Solo	0	83	47
			Soloing Lead	0	83	48
			Super Mini Lead	0	83	49
			Alfreds Filter Solo	0	83	50
			Theremin	0	83	51
			Basic Bend Lead	0	83	60
			Square Lead	0	83	61
			SynLeader	0	7	109
			Aah Soloist	0	72	115
			Heart Solo	0	72	5
			TV Mystery	0	72	35
			Ultraog Lead	0	72	55
			A Classic	0	72	65
			Joan's Lead	0	72	75
			Vocality	0	72	85
			Classic Square Lead	0	72	95
			Dirty Dance Organ	0	73	72
			Brassy Saw Lead	0	73	84
			TriStar Lead	0	73	117
			GM081 Lead 1 (square)	0	89	81
			GM083 Lead 3 (calliope)	0	89	83
			GM088 Lead 8 (bass&lead)	0	89	88
			Android JL	0	103	12
		Hard	Power Squared	0	72	98
			Binder Lead	0	72	105
			Square Bend Lead	0	72	125
			Quad Saw Solo	0	73	7
			Phat Solo Sync	0	73	17
			Ringtone Lead	0	73	28
			DnB Square	0	73	35
			Miss HipHop	0	73	46
			Nightmare Lead	0	73	71
			Drug Solo	0	73	107
			Dark Driver Lead	0	83	34
			Super Synth Lead	0	83	39
			Gangsta Whine	0	83	46
			5th Saw Lead	0	83	53
			Drum n Bass	0	83	56
			5th Pulse Lead	0	83	57
			Pulse Lead	0	83	58
			Dry Fat Pulse Solo	0	83	59
			Screamer Lead 1	0	83	62
			Screamer Lead 2	0	83	63
			Pitch EG Lead	0	83	64
			Fat Analog Lead	0	83	65

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Synthesizer	Synthe Lead	Sync&Reso	Ear Killer	0	72	15
			Ghost Rave	0	72	25
			Rave Signal Squares	0	72	26
			Dance Solo	0	72	86
			Karma Lead	0	72	126
			Develish Syncer	0	73	27
			Disto Sweep Lead	0	73	37
			Big Drive Lead	0	73	38
			Organic Lead	0	73	63
			Itchy Saws	0	73	78
			Self Oscillator	0	73	90
			Couter Games	0	73	96
			Square Sync Solo	0	73	100
			Sweepy Pulse Lead	0	73	104
			Overtone Solo Lead	0	73	53
			Wannabe TB	0	83	52
			808 State Lead	0	83	54
			Analog Heaven	0	83	55
			OscSync Solo	0	83	72

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Synthesizer	Synthe Pad	Soft	Sweeping Pad & Bells	0	83	2
			Soft Super Saw Pad	0	83	5
			Analogy Pad	0	83	11
			Mega Pad	0	83	12
			Lost Souls Pad	0	83	28
			Worried Dave Pad	0	83	29
			Big Dark Mega Pad	0	72	14
			Big Ass Pad	0	72	24
			Analog Pad	0	72	94
			Soft Rotor Sparkle Pad	0	72	124
			Horny	0	73	10
			Warm Pad	0	91	47
			Bowed Glass	0	91	50
			Halo Pad	0	91	52
			Atmosphere	0	91	57
			Vollenweider	0	91	86
			Paradise	0	91	87
			Deep Mistery	0	91	88
			Twilight	0	93	17
			Cosmic	0	90	40
			Warm Horn	0	73	65
			Big Octave Pad	0	73	36
			Thin Air Pad	0	81	74
			GM090 Pad 2 (warm)	0	89	90
			GM093 Pad 5 (bowed)	0	89	93
			GM095 Pad 7 (halo)	0	89	95
			GM100 FX 4 (atmosphere)	0	89	100
		Bright	Bassline Style Pad	0	83	36
			12 String Guitar Syn	0	7	106
			The Greek Pad	0	72	31
			Square & Hold Pad	0	72	74
			Jet Pad	0	73	6
			Mars n Venus	0	73	23
			VS Choir Pad	0	73	45
			Synth Brass Pad	0	81	97
			Pulsing Wave Pad	0	83	14
			Swoosh Pad	0	83	16
			Bright Sweep Pad	0	83	18
			Ceremonial Pad	0	83	19
			Power Swell Pad	0	83	20
			Stardust Pad	0	83	21
			Glassy Pad	0	83	23
			Bright Moving Pad	0	83	32
			Soundtrack	0	91	55
			Big Pad	0	91	91
			Brass Pad	0	93	18
			GM098 FX 2 (soundtrack)	0	89	98
			Monsterbreath JL	0	103	26

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Synthesizer	Synthe Pad	Motion	Atmo Pad	0	6	27
			Worlds Apart	0	72	1
			Release Shatter Pad	0	72	41
			Digi Echo Pad	0	72	54
			Bubble Swe	0	72	59
			Bell Tinkle Pad	0	72	67
			Cou Pad	0	72	77
			Falling Star Pad	0	72	81
			Mery Pad	0	72	114
			Dirty Sweep Pad	0	83	7
			Vocalizing Pad	0	83	8
			Retro Pad	0	83	17
			Chase 4 Pad	0	83	24
			Ghost Ship Pad	0	83	30
			Slave Camp Pad	0	83	33
		Sweep	Goblins	0	91	59
			GM102 FX 6 (goblins)	0	89	102
			Tinkling Wavetable Pad	0	72	21
			Sundown	0	72	27
			Softly Softly Pad	0	72	34
			De Sea	0	72	84
			Aurora	0	72	89
			Mega Swe Pad	0	72	91
			HP Dirty Swe	0	72	101
			Rich Sync Pad	0	72	111
			Touchy Swe Pad	0	72	121
			Century Pad	0	73	13
			Saw Pad Sweep 1	0	73	16
			Saw Pad Sweep 2	0	83	4
			Wavetable SweeperPad	0	73	42

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Synthesizer	Synthe Pad	String	Synthe Strings 1	0	91	25
			Synthe Strings 2	0	91	26
			Synthe Strings 3	0	84	107
			Virus Strings 1	0	8	45
			Virus Strings 2	0	8	46
			Solina Strings	0	8	42
			Moog Strings	0	8	43
			MKS Strings	0	8	44
			Warm Hybrid Strings	0	6	26
			FM Mix Strings	0	8	47
			Solina Violin	0	8	48
			Solina ViolinViola	0	8	49
			Solina ViolinViola & Bass	0	8	50
			Solina Full	0	8	51
			Numan Strings	0	72	48
			Astral Strings	0	72	51
			Big Pwm Strings	0	72	71
			SuperFizzy StringSynth	0	73	20
			Silky Synth Orchestra	0	73	124
			GM051 Synthe Str.1	0	89	51
			GM052 Synthe Str.2	0	89	52
		Entertainer	Entertainer Pad 1	0	10	100
			Entertainer Pad 2	0	10	101
			Entertainer Pad 3	0	10	102
			Entertainer Pad 4	0	10	103
			Entertainer Pad 5	0	10	104
			Entertainer Pad 6	0	10	105
			Schlager Pad 1	0	9	123
			Schlager Pad 2	0	9	124
			Schlager Pad 3	0	9	125
			Amazing 1	0	9	126
			Amazing 2	0	9	127
			Syn-Fair-Light	0	10	107
			D50 Pad	0	10	107
			CD-Galaxy 1	0	91	11
			CD-Galaxy 2	0	10	98
			CD-Fairlight 1	0	10	106
			CD-Fairlight 2	0	10	99
			CD-Fairlight 3	0	91	10
			CD-Theater	0	91	14

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Synthesizer	Synthe Analog	Soft	Soft Sweer Rlay	0	72	78
			EP Ano Rhodes	0	72	110
			Calorizer Pad	0	73	26
			EP Warm EE Piano	0	73	41
			Soft Super Saw	0	73	54
			Soft Synth Brass	0	73	101
			8 Voice Synth Horns	0	81	91
			Synthe Brass Warm 1	0	81	94
			Synthe Brass Warm 2	0	81	99
			Chiff	0	91	41
			GM084 Lead 4 (chiff)	0	89	84
		Classic	Synthe Brass 1	0	90	32
			Synthe Brass 2	0	93	13
			Synthe Brass 3	0	93	14
			Synthe Brass 4	0	81	98
			Synthe Brass 5	0	7	112
			Oberheim	0	90	30
			Matrix	0	90	31
			Polysynth	0	90	52
			Who the F*** is Axel	0	6	14
			Unison Bend Poly	0	72	8
			Bright Brass Section	0	72	108
			Fat Sync Poly	0	72	128
			Late Synbrass	0	73	39
			Phased Leader	0	73	64

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Synthesizer	Synthe Analog	Shortdecay	Melody Maker	0	72	66
			Velo Perc Chordulator	0	72	88
			Fuzz Melody	0	72	96
			Phaser HP Sequencer	0	73	8
			Analog Metal Perc	0	73	12
			Humble Stance	0	73	48
			Rich Square Bell	0	73	97
			P Vox Bell	0	73	114
			Elektro Perc Lead	0	83	35
			Poly Slap	0	83	66
			Analog Sequence	0	83	69
			Modern Lead	0	83	70
		Sync&Reso	Wavebend Poly	0	72	118
			The Buzz	0	72	53
			Synchronas	0	72	56
			Thick Pulse Bass	0	72	63
			Mind Machine	0	72	76
			Reso Smack Bass	0	73	5
			Hyper vs P	0	73	30
			Clavigue	0	73	79
			Sweeping Worlds	0	73	68
			Pure Wet Fat	0	73	105
			Time For Flange	0	73	110
			Sawpluck	0	73	116
			Prophet	0	73	122
			Metal BandBass	0	73	125
			Soft Res Brass	0	81	96
			Hybrid Brass Section	0	81	100
			Bigger Than Life	0	83	42
			Syncerator	0	83	43
			Filter Keys	0	73	47
			Industrialised	0	73	56
			Big Reso Bell	0	73	57
			Phaser Dance	0	83	71
			Seq Brass	0	93	16
			Nasty Synth	0	6	89

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Synthesizer	Synthe Analog	Other	Worlds Biggest Swe	0	72	18
			Wavpan	0	72	38
			Bubble Wave Electro	0	72	40
			Space Rescue Mission	0	72	44
			Dark Bell	0	72	50
			Roundabout	0	72	58
			Rich Wave Bells Pad	0	72	64
			LoFi Sinus	0	72	93
			Soft Bell Mallets	0	72	100
			Quaeko	0	72	106
			Digi Bell	0	73	3
			Firus	0	73	18
			Chorus Bells	0	73	22
			Interval og	0	73	55
			VS Bells	0	73	59
			Ambient Mind	0	73	60
			Square Bells	0	73	81
			LFO ve	0	73	86
			Journey To Pluto	0	73	88
			Jupiter Keys	0	73	118
			Digital Theme Park	0	83	40
			Shooting Stars	0	83	44
			Glass Menagerie	0	83	73
			Charang	0	91	42
			Solo Vox	0	91	43
			Fantasia	0	91	46
			Space Vocal	0	91	49
			Ice Rain	0	91	54
			Brightness	0	91	58
			Echo Drops	0	91	60
			Low Hangin Mumma	0	73	44
			GG-AirMallet	0	91	21
			GM085 Lead 5 (charang)	0	89	85
			GM086 Lead 6 (voice)	0	89	86
			GM089 Pad 1 (new age)	0	89	89
			GM097 FX 1 (rain)	0	89	97
			GM101 FX 5 (brightness)	0	89	101
			GM103 FX 7 (echoes)	0	89	103

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG	
Synthesizer	Synthe Analog	Synthe Bass	Synth Bass	0	6	4	
			Thuer Bass	0	72	3	
			Ultraog Bass	0	72	13	
			Aggressor Bass	0	72	16	
			Hairy Bass	0	72	23	
			Fat Analog Bass Slap	0	72	30	
			Rubber Reso Bass	0	72	43	
			Jupiter Thu	0	72	73	
			Fuzzy Chap	0	72	83	
			Chorused E-Bass	0	72	103	
			Buer Bass	0	72	113	
			FuzzaFizzle Bass	0	72	123	
			Hollow Bass	0	73	15	
			Sub Bass Fattener	0	73	25	
			Single Osc Bass	0	73	62	
			Thuy Stud Bass	0	73	70	
			LFO Bass	0	73	89	
			DnB Sub Bass	0	73	95	
			Phat Pwm Bass	0	73	99	
			OrgaThu Bass	0	73	103	
			Velocity BandBass	0	73	106	
			Unitea Bass	0	73	109	
			Bass Of Death	0	73	111	
			M-Bassy	0	73	113	
			Transistor Bass	0	73	115	
			UK Breakz Bass	0	73	119	
			Bouw Bass	0	73	121	
			Fuzzy Bass Riff	0	73	123	
			Bad Black Bass	0	73	127	
			Bass Sweep	0	82	72	
			Thumb Bass	0	82	73	
			SH Bass	0	82	74	
			Syn Bass	0	82	75	
			FM Bass	0	82	76	
			Muckiphonic PulsStr.	0	73	120	
Synthesizer	Synthe Trance	Soft	Init Patch	0	73	128	
			Club Rotation	0	72	6	
			Ambient Chord	0	72	28	
			Trancefloor Lead	0	83	68	
			Tech Siren	0	72	36	
		Hard	Monster Rave	0	72	46	
			Trance Orchestra	0	72	68	
			Techno Attack	0	72	116	
			Dance Stabs Lead	0	83	37	
			Rave Synth Lead	0	83	38	
			Dance Sawteeth	0	83	67	
			Trance Worlds	0	73	66	
			Motion	Oceanarium	0	72	4
			Noise	TranceNoise	0	85	127

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Synthesizer	Synthe Motion	Easy	Outback	0	72	17
			Fuzzy Gurgler	0	72	52
			Lunar Eclipse	0	72	57
			Arctic Circle	0	72	87
			Days Gone By	0	72	104
			Hyper Sweep Pad	0	73	1
			Stutter Pad	0	73	11
			Vocalizing	0	73	33
			Worlds Apart Motion	0	83	6
			Milky Way Pad 1	0	83	9
			S&H Worlds Pad	0	83	10
			Ghost Wave Pad	0	83	13
			Rising Star Pad	0	83	31
			Auto Synth	0	72	7
		Complex	Ice Cold Swe	0	72	9
			S&H Worlds	0	72	39
			Salthar	0	72	47
			Milky Way Pad 2	0	72	49
			Wave Pattern Pad	0	72	79
			Caldera	0	72	119
			Swirling Sync Keys	0	73	9
			Curves	0	73	31
			Sync Sweep	0	73	51
			Reso Gater	0	73	58
			Traveller	0	73	80
			Cascading	0	83	74
			Wave Line	0	73	49
		Rhythm	Good Vibes	0	72	2
			Polyrhythm Pad	0	72	19
			Chaser Pad	0	72	29
			BP Dreams	0	72	109
			Soft Groove Pad	0	83	22
			Rhythmic Pad	0	83	26
			Urban Pad	0	83	27

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Synthesizer	Synthe Arpeggio	Up&Down	Creamy Arpeggio	0	72	12
			Euro Chase Bass	0	72	22
			Jupiter Arp	0	72	32
			HP Dirty Swe Arp	0	72	42
			Triangle Arpeggio	0	72	62
			Filter Super Drivio	0	72	69
			Stereo Sync Arp	0	72	72
			Wicked Square Arp	0	72	82
			Sweet Square Bell	0	72	92
			Pinhead Arp	0	72	99
			Noise Zap Arp	0	72	102
			Dark Driver Arp	0	72	107
			Per Chime Arpeggio	0	72	112
			Sub Metal Arpeggio	0	72	122
		Complex	Classic Dance Saws	0	73	34
			HS Bassline	0	73	40
			Phaser Sequence	0	73	43
			Ethnic Pluck Loop	0	73	24
			Soft Ambi Swes	0	73	4
			Metalliga	0	73	14
			Beaver Att. Formation	0	73	21
			Paranoia	0	73	52
			Hi Tone Bell	0	73	61
			Glocken Loop	0	73	69
			Sile Saw Arpeggio	0	73	76
			Square Dance	0	73	82
			Transistor Bass Line	0	73	92
			Punchy Sequence	0	73	94
			Autotif Bass	0	73	98
			Prophet Arp	0	73	102
			Kraftworks	0	83	95
			Old School Tune	0	83	96
			Repeat Bass	0	83	97
			Dark Pulsator	0	83	98
			Pypa Arpeggio	0	83	99
			Speech Sequenzer	0	83	100

1.13 Drums

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Drums	Drumkits	Acoustic	Kit Standard 1	0	94	1
			Kit Standard 2	0	94	2
			Kit Acoustic	0	94	4
			Kit Room	0	94	9
			Kit Power 1	0	94	13
			Kit Power 2	0	94	14
			Kit Studio	0	94	32
			Kit Schlager	0	104	12
			Kit Pop	0	104	13
			Kit Hit	0	94	37
			Kit Vintage 1	0	104	14
			Kit Vintage 2	0	104	15
			Kit 80s Pop 1	0	104	16
			Kit 80s Pop 2	0	104	17
			Kit Rock 1	0	94	17
			Kit Rock 2	0	104	18
			Kit Rock 3	0	104	19
			Kit Brush 1	0	94	41
			Kit Brush 2	0	104	31
			Kit Brush 3	0	104	32
			Kit Brush 4	0	104	34
			Kit Jazz 1	0	94	33
			Kit Jazz 2	0	104	33
			Kit RealDrum	0	104	20
			Kit Orchestra XG	0	94	49
			Kit Orchestra GM	0	94	50
			Kit Enter Live	0	104	4
			Kit Eco Normal	0	104	6
			Kit Eco Latin	0	104	9
			Kit JL Standard	0	104	10
		Elektro	Kit Electro	0	94	25
			Kit Analog	0	94	26
			Kit Dance	0	94	27
			Kit Synthedrum JL	0	103	28
			Kit Enter Standard	0	104	2
			Kit Enter Dance	0	104	3
			Kit JL Dance	0	104	11
			Kit Eco Dance	0	104	7
			Kit Eco HipHop	0	104	8
			Kit Enter Elektro	0	104	5
			Kit HipHop 1	0	104	21
			Kit HipHop 2	0	104	22
			Kit T8 Analog	0	104	23
			Kit T9 Analog	0	104	24
			Kit House	0	104	25
			Kit Electro Machine	0	104	26
			Kit Elektronic Dance 1	0	104	27
			Kit Elektronic Dance 2	0	104	28
			Kit Elektronic Dance 3	0	104	29
			Kit Elektronic Dance 4	0	104	30

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Drums	Percussion	Perc Kits	Kit Pop Latin 1	0	94	46
			Kit Arabic	0	94	47
			Kit Cuban	0	94	48
			Kit Afro Cuban	0	104	42
			Kit Pop Latin 2	0	104	43
			Kit Pop Latin 3	0	104	44
			Kit PopPerc	0	104	45
			Kit Perc Brasil	0	104	51
	Drums	Loop	Real Analog Drums	0	72	20
			M Drums 1	0	72	80
			J Drums 1	0	72	120
			M Drums 2	0	73	50
			J Drums 2	0	73	74
			Combo Loop	0	83	89
			Tite Room Funk Loop	0	83	90
			Packman Loop	0	83	91
		Solo	Funky Chap Loop	0	83	92
			Blippo Loop	0	83	93
			Sequeaker Loop	0	83	94
			Timpani 1	0	90	33
			Timpani 2	0	8	84
			Orchestra Drum 1	0	8	82
			Orchestra Drum 2	0	8	83
			Orchestra Piati 1	0	8	92
			Orchestra Piati 2	0	8	93
			Orchestra Timpani	0	6	48
			Crash Cymbal 1	0	8	94
			Crash Cymbal 2	0	8	95
			Crash Cymbal March	0	8	96
			Crash Cymbal Splash	0	8	97
			Ride Cymbal 1	0	8	98
			Ride Cymbal 2	0	8	99
			Hihat Pedal	0	8	100
			Snare 1	0	8	112
			Snare 2	0	8	113
			Brush	0	8	114
			Bassdrum 1	0	8	115
			Bassdrum 2	0	8	116
			Claps 1	0	8	117
			Claps 2	0	8	118
			Snare Roll	0	8	123
			Snare Roll -> Crash	0	8	124
			KickAndRide	0	8	125
			Synthe Drum	0	93	58
			GM119 Synthe Drum	0	89	119
			GM117 Taiko Drums	0	89	117
			GM118 Melodic Tom	0	89	118
			GM120 Reverse Cymbal	0	89	120

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Drums	Percussion	Acoustic	Movie Hit 1	0	8	62
			Movie Hit 2	0	8	63
			Movie Hit Special	0	8	64
			WindChimes	0	8	102
			Woodblock	0	8	103
			Tubular Bells	0	8	104
			Tambourin 1	0	8	105
			Tambourin 2	0	8	106
			Jingle Bells	0	8	107
			Fingersnaps	0	8	108
			Castanets	0	8	109
			Triangle 1	0	8	119
			Triangle 2	0	8	120
			Big Timpani	0	81	87
			Medium Timpani	0	81	88
			Orchestral Perc	0	81	89
			GM048 Timpani	0	89	48
			GM114 Agogo	0	89	114
			GM116 Woodblock	0	89	116
			Church Bells	0	60	128

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Drums	Sound Effects	Nature	Birds	0	83	83
			Applause Small	0	83	84
			Applause Large	0	83	85
			Small Crowd Laugh	0	83	86
			Large Crowd Laugh	0	83	87
			Car	0	83	88
			Applause	0	93	4
			Bird	0	93	5
			Breath Noise	0	93	6
			Guitar Fretless	0	93	7
			Gunshot	0	93	8
			Helicopter	0	93	9
			Phone	0	93	10
			Seashore	0	93	11
			General Effects	0	93	111
			Latin Effects	0	93	112
			Traditional Effects	0	93	113
			Western Effects	0	93	114
			Sakral Effects	0	93	115
			Other Effects	0	93	116
			Timbal effects	0	93	118
			WERSI Effects	0	88	128
			GM121 Guitar FretNoise	0	89	121
			GM122 Breath Noise	0	89	122
			GM123 Seashore	0	89	123
			GM124 Bird Tweet	0	89	124
			GM125 Telephone	0	89	125
			GM126 Helicopter	0	89	126
			GM127 Applause	0	89	127
			GM128 Gunshot	0	89	128
		Stimme	Vocal Effects 1	0	93	12
			Vocal Effects 2	0	93	117
			Atonal Percussachap	0	72	10

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
Drums	Sound Effects	Synthe	The Swarm	0	72	11
			CineIntroBass	0	72	33
			Welcome	0	72	37
			Sandy Solo	0	72	45
			Drums Of Death	0	72	60
			Sad tion Pad	0	72	61
			Elektro Res Congas	0	72	70
			Elektro Noise Crash	0	72	90
			Fishsex	0	72	97
			Grain Brain	0	72	117
			S&H Noise	0	72	127
			Percy RezNoiselnator	0	73	2
			Space Phase	0	73	19
			Doom & Chaos	0	73	29
			Velo Perculator	0	73	32
			Chaos	0	83	75
			Wind Atmos	0	83	76
			Tension	0	83	77
			In Need Of Oil	0	83	78
			R2D2	0	83	79
			Yeah Yeah Frog	0	83	80
			Ufo	0	83	81
			SciFi LFO FX	0	83	82
			CD-Drops	0	91	15

1.14 ACC Specials

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
ACC Specials (only for Styles)	Drawbars	Zugriegel Presets	Acc Rock Organ	0	84	102
			Acc Drawbars Perc 3rd	0	84	103
			Acc Perc Organ	0	84	104
			Acc Organ	0	84	105
			Acc DB Full 1	0	84	111
			Acc DB Full 2	0	84	112
			Acc DB Variation 1	0	84	113
			Acc DB Variation 2	0	84	114
			Acc DB Open	0	84	115
			Acc DB Blues 1	0	84	116
			Acc DB Blues 2	0	84	117
			Acc DB Blues 1 Perc	0	84	118
			Acc DB Blues 2 Perc	0	84	119
			ACC DB Lower 1	0	84	120
			ACC DB Lower 2	0	84	121
	Accordion	Accordion	ACC Diatonisch	0	84	98
	Brass	Trumpets Trombones	Acc Trumpet	0	85	114
			Acc Trumpet	0	84	4
			Acc Trompete mid	0	84	77
			Acc Trompete Scharf	0	84	78
			Acc Trompete Gestopft	0	84	79
			Acc Posaune	0	84	73
			Acc Posaune weich	0	84	74
			Acc Posaunen Ensemble	0	84	75
			Acc Tuba	0	84	80
		Brass	Acc Brass	0	84	3
			Acc Brass	0	85	111
			Acc Pop Horns 1	0	85	112
			Acc Pop Horns 2	0	85	113
	Saxophon	Saxophon	Acc Tenor Sax	0	84	5
			Acc Tenor Sax F	0	84	65
			Acc Tenor Sax Sweet	0	84	66
			Acc Alt Sax 3 F	0	84	67
			Acc Sax Section 1	0	84	68
			Acc Sax Section 2	0	84	69
			Acc Tenor Bostic	0	84	71
			Acc Alt Saxo Section	0	84	72
			Acc Tenorsax	0	85	115
	Flute	ACC Flute	0	84	83	
	Clarinet	Acc Klarinette	0	84	84	

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
ACC Specials (only for Styles)	Guitar	Acoustic	Acc NylonGuitar	0	84	6
			Acc SteelGuitar	0	84	7
			Acc 12 String Gtr	0	84	8
			Acc HiStringGtr	0	84	9
			Acc Steel String +1	0	84	20
			Acc Nylon String +1	0	84	21
			Acc 12 String Guitar 4	0	84	23
			Acc Steel & Body	0	84	29
			Acc SteelGuitar Norm	0	84	81
			Acc Flamenco Guitar	0	85	1
			Acc Spanish Medium	0	85	2
			Acc Spanish Hard	0	85	3
			Acc Mandolin	0	85	4
			Acc Ukelele	0	85	5
			Acc Steel Guitar	0	85	6
			Acc Steel Acoustik Pick	0	85	11
			Acc Steel Acoustik Slap	0	85	12
			Acc Steel Guitar Twin1	0	85	13
			Acc Steel Guitar Twin2	0	85	14
			Acc 12String Pick Twin1	0	85	15
			Acc 12String Pick Twin2	0	85	16
			Acc D-Folk Guitar	0	85	17
			Acc Steel Acoustik Finger	0	85	18
			Acc Steel Ac Thum Pick	0	85	19
			Acc D & Hard Folk Twin 1	0	85	20
			Acc D & Warm Folk Twin 1	0	85	21
			Acc D & Hard Folk Twin 2	0	85	22
			Acc D & Warm Folk Twin 2	0	85	23
			Acc Hi String Guitar	0	85	24
			Acc 12 String Guitar	0	85	25

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
ACC Specials (only for Styles)	Guitar	E-Guitar	ACC Clean guitar	0	85	26
			Acc SolidGuitar 1	0	84	10
			Acc SolidGuitar 2	0	84	11
			Acc Clean Guitar	0	84	12
			Acc OverdriveGtr	0	84	13
			Acc DistortionGtr	0	84	14
			Acc Stratocaster +1	0	84	19
			Acc Solid Clean	0	84	22
			Acc Muted Guitar	0	84	24
			Acc Distortion Guitar	0	84	26
			Acc Solid Wah Wah	0	84	27
			Acc Clean Guitar	0	84	30
			Acc Jazz Gitarre	0	84	38
			Acc Pedal Steel	0	84	82
			Acc Solid Guitar 1	0	85	27
			Acc Solid Guitar 2	0	85	28
			Acc Single Coil Guitar	0	85	29
			Acc 50s Vintage Finger	0	85	30
			Acc 50s Vintage Finger Slap	0	85	31
			Acc 50s Vintage Pick	0	85	32
			Acc 50s Finger Slap	0	85	33
			Acc Slap Amp Guitar	0	85	34
			Acc 60s Vintage	0	85	35
			Acc 60s Vintage Slap	0	85	36
			Acc Overdrive Guitar	0	85	37
			Acc Distortion Guitar	0	85	38
			Acc Jazz Guitar	0	85	39
	Bass	Bass	Acc Akusticbass	0	84	15
			Acc ElektrikBass	0	84	16
			Acc PickBass	0	84	17
			Acc Fretless Bass 1	0	84	18
			Acc Finger Bass	0	84	31
			Acc Picked Bass 2	0	84	32
			Acc Akustikbass 3	0	84	33
			Acc Fretless Bass 2	0	84	34
			Acc Disco Bass 2	0	84	35
			Acc Slap Bass 1	0	84	36
			Acc Acoustik Bass	0	85	40
			Acc Electric Bass	0	85	52
			Acc Vintage Round	0	85	53
			Acc Vintage Flat	0	85	54
			Acc Active Bass Finger HarmOn	0	85	55
			Acc Active Bass Finger Harm	0	85	56
			Acc Active Bass Finger Slap	0	85	57
			Acc Pick Bass	0	85	58
			Acc Vintage Pick	0	85	59
			Acc Active Bass Finger Pick HarmOn	0	85	60
			Acc Active Bass Pick	0	85	61
			Acc Active Bass Pick Open	0	85	62
			Acc Active Bass Pick Mute	0	85	63
			Acc Fretless Bass	0	85	64
			Acc Activ Bass Slap	0	85	65
			ACC SynBass	0	85	66

Sound Group	User Panel	Bank	Soundname	LSB	MSB	PRG
ACC Specials (only for Styles)	Piano	Piano	Acc Clavinet	0	84	39
			Acc Grand Piano	0	84	106
	Strings	Strings	Acc Small Strings	0	84	1
			Acc Large Strings	0	84	2
			Acc Strings	0	84	108
			Acc Strings Attack	0	84	109
			Acc Small Strings	0	85	67
			Acc Classical Strings	0	85	72
			Acc Kino Small	0	85	73
			Acc Kino Small Comp	0	85	74
			Acc Kino Small Comp Oct	0	85	75
			Acc Kino Small Ambi	0	85	76
			Acc Large Strings	0	85	77
			Acc Seattle Strings	0	85	78
			Acc Kino Large	0	85	79
			Acc Kino Large Comp	0	85	80
			Acc Kino Large Oct Cb	0	85	81
			Acc Kino Large Ambi Oct Cb	0	85	82
			Acc Kino Large Ambi	0	85	83
	Synthesizer	Bass	Acc Synthe Bass	0	84	37
Synthe Pad		ACC Schlager Pad	0	84	99	
		Acc Rhythm Synthe	0	84	100	
		ACC Synthe Pad	0	84	110	

2 Style List

2.1 List of factory style by music genre

Note: The styles marked with an * are part of software version 3.0.

SECTION	No.	NAME	Tempo
POP	1	16 Beat 1	74
	2	16 Beat 2	76
	3	8 Beat 1	108
	4	8 Beat 2	100
	5	8 Beat 3	116
	6	8 Beat Latin	86
	7	Beat Alps	122
	8	Beat Easy	120
	9	Beat Oldie	138
	10	Standard Beat 1	124
	11	Standard Beat 2	115
	12	Sweet Beat	73
	13	Smooth 8-Beat +	72
	14	California Beat +	118
	15	Beatbox +	77
	16	Britpop +	133
	17	Basic Pop Rock +	120
	18	Sixties Pop +	125
	19	Good Old Times +	101
	20	Organ Euro Pop	145
	21	Basic 80s Pop +	120
	22	Pop Beat*	76
	23	Chilled Beat*	76
	24	Dream Beat*	110
	25	Easy Beat*	124
	101	PopFunk 1	102
	102	PopFunk 2	90
	103	Get Funky +	120
	104	Big Funk +	106
	105	LA Funky House	116

SECTION	No.	NAME	Tempo
ROCK	201	Rock 1	128
	202	Rock 2	130
	203	Rock JP 1	124
	204	Rock JP 2	110
	205	Festival Rock +	140
	206	Summer Rock +	145
	207	Deutsch Rock +	112
	208	Shades Of Rock +	76
	209	Straight Rock	138
	210	Metal City +	119

	211	Blue Metal	131
	212	Rock Pop Days +	100
	213	Elysium Rock	125
	241	Rock Shuffle 1	122
	242	Rock Shuffle 2	125
	243	Shuffle 1	162
	244	Shuffle 2	160
	245	Shuffle Rock'n Roll +	186
	246	Shuffle Slow	115
	247	Crooner Shuffle +	145
	248	Rock Shuffle +	136
	261	6-8 Blues	88
	262	Blues Shuffle	119
	263	Blues Slow	102
	264	Blues Swing	132
	265	Organ Blues	120
	266	Organ Gospel	58
	267	Organ Groove	180
	268	Twist 1 +	170
	269	Twist 2	172
	281	Rock'n Roll 1	193
	282	Rock'n Roll 2	171
	283	Rock'n Roll 3	184
	284	Rock'n Roll 4	168
	285	US-RockRoll	157
	286	Basic Rock'n Roll +	178
	321	Boogie 1	162
	322	Boogie 2	165
	323	Piano Boogie	170
	324	Boogie Woogie +	165
	325	Piano Boogie Man +	176
	326	Good Time Boogie	168
	341	Slow Rock 1 +	76
	342	Slow Rock 2 +	68
	343	Slow Rock 3	72
	344	12/8 Slow Rock +	115
	345	6/8 Blues Rock +	75
	346	Summer Slow Rock	78
	361	Metal Waltz +	142

SECTION	No.	NAME	Tempo
DANCE	401	Disco 1	122
	402	Disco 2 +	120
	403	70er Disco Schlager +	120
	404	Disco 70s +	122
	405	Disco Philly	119
	406	Gefühl disco +	125
	407	Basic Disco 1	115
	451	Dance 1	119
	452	Dance 2	128
	453	Dance 3	128
	454	Dance 4	125
	455	80's Dance Pop +	125
	456	Pop Dance +	118
	457	Club Titan +	126
	458	Vintage Minimal +	126
	459	Wersi on the beach	128
	460	Dance The 90s +	128
	501	Techno	131
	502	Trance Dance +	134
	503	Radio Dubstep +	130
	504	Rappers Swag +	100

SECTION	No.	NAME	Tempo
BALLAD	601	Beat Ballad 1	62
	602	Beat Ballad 2	64
	603	Beat Ballad Slow	105
	621	Ballad 1	68
	622	Ballad 2	74
	623	Organ Ballad	75
	624	US-Ballad	76
	625	Ballad Forever +	75
	626	Songwriter Ballad +	85
	627	Vocal Ballad +	77
	628	Please Release	84
	629	Ballad 3	78
	641	Pop Ballad 1	75
	642	Pop Ballad 2	70
	643	Basic Modern Ballad +	105
	681	Piano Ballad 1	60
	682	Piano Ballad 2	70
	683	Kölle am Dom Ballad	74
	701	6-8 Ballad 1	95
	702	6-8 Ballad 2	103
	703	6-8 Ballad Pop +	75
	704	6-8 Blues Ballad	120
	705	12-8 Ballad	63
	706	Basic 6/8 Ballad +	67
	707	Shuffle Ballad*	108

SECTION	No.	NAME	Tempo
BALLROOM	801	Beguine 1	120
	802	Beguine 2	110
	803	Beguine Stupid	108
	804	The Beguine +	100
	805	Organ Beguine	120
	831	Rumba 1	120
	832	Rumba 2 +	120
	833	Rumba Pop	96
	834	Organ Rumba	120
	861	Cha Cha 1 +	124
	862	Cha Cha 2	124
	863	Cha Cha 3 +	125
	864	Cha Cha 4	124
	865	Cha Cha Cha +	120
	866	Last Cha Cha +	134
	867	Organ Cha Cha	124
	868	Modern Cha Cha	130
	869	Basic ChaCha +	124
	881	Tango 1 +	124
	882	Tango 2	125

	883	US-Tango	120
	884	Tango Roberto +	130
	901	Jive 1 +	176
	902	Jive 2	173
	903	Jive 3	180
	904	Jive Conny	99
	921	Quickstep 1	192
	922	Quickstep 2 +	178
	923	Quickstep 3 +	200
	924	Organ Quickstep 1	200
	925	Organ Quickstep 2	200
	926	Basic Quick Step +	98
	941	Foxtrott 1	176
	942	Foxtrott 2 +	158
	943	Foxtrott 3 +	172
	944	Foxtrott 4 +	158
	945	Foxtrott Akkordeon	182
	946	Foxtrott Brush +	143
	947	Foxtrott Sleigh Ride	108
	956	Swinging Foxtrott	116
	948	Organ Foxtrott 1	128
	957	Organ Foxtrott 2*	143
	949	Organ Combo	175
	950	Slow Fox 1	106
	951	Slow Fox 2	116
	952	Slow Fox 3 +	114
	953	Slow Fox Brush +	88
	954	Acappella Fox +	121
	955	Basic BB Foxtrott +	120
	961	Slow Waltz 1	92
	962	Slow Waltz 2	89
	963	Slow Waltz 3 +	87
	964	Swing Waltz	120
	965	Pop Waltz	89
	966	Jazz Waltz	146
	967	Love Waltz	186
	968	Basic Waltz +	186
	969	Englischer Walzer*	92

SECTION	No.	NAME	Tempo
ENTERTAINER	1001	Schlager Beat 1	128
	1002	Schlager Beat 2 +	116
	1003	Popschlager +	120
	1004	Schlagernacht +	119
	1005	Schlager Pop 2014	117
	1006	Petry Party +	126
	1007	Schlager Polka +	120

1008	Schlagerqueen +	116
1009	Schlager Beat 1 Disco	128
1010	Fischer Dübel*	125
1011	Schlager 1*	124
1012	Schlager 2*	120
1013	Schlager Shuffle*	117
1014	Schlager Slowrock*	70
1015	Schlager Polka*	118
1051	Party Modern Mix	130
1052	Party Polka	106
1053	Party Pop	123
1054	Party Schlager Beat	125
1055	Party Time +	125
1056	Party Happy Polka	127
1057	Organ Party Pop	125
1058	Polonaise	120
1059	Happy Strike*	124
1060	Party*	120
1061	Latin Party*	122
1101	Schlager Rumba +	108
1121	Schunke Walzer +	180
1141	Die Hände Zum Himmel	123
1142	Gri. Wein	148
1143	Narhalla March	120
1144	Party Saragossa +	124
1145	Tropical Fruits	87
1146	Schlager Dance	130
1147	Schlager Espania	128
1148	Schlager Ballad	117
1149	Schlager Rumba	112
1161	8 Beat Romantica	113
1162	8 Beat Selena	105
1163	16-Beat Jonathan	76
1164	Discofox	122
1165	Lucia Waltz	95
1166	Atlantis Retro	130
1167	Schlager Disco	129
1168	Madonna	95
1169	Slow Country	121
1170	Samba Latino	129
1171	March	120
1172	Sentimental Fox	115
1173	Avignon Fox	169
1174	Step Fox	180
1175	Happy Organ Man	165
1176	Happy Polka	128
1177	Beguine	114
1178	Mon Amour	72

	1179	Happy Waltz	179
	1180	Sommerroses Ballad	103
	1181	Happy Beat	117
	1182	Happy Foxtrott	163
	1183	Happy Schlager	90

SECTION	No.	NAME	Tempo
SWING & BIG BAND	1201	Swing Combo	155
	1202	Swing Easy	121
	1203	Swing Sinatra	122
	1204	US-Cookin Jazz	120
	1205	Swing It +	200
	1206	Slow Swing Count Basie	120
	1207	Slow Swing Kaempfert	99
	1208	Slow Swing	105
	1209	Organ Swing	143
	1210	Swing Foxtrott	168
	1211	Swinging Accordion	177
	1212	Jingle Swing +	110
	1213	Swingin Romance +	110
	1214	Swing Shuffle	68
	1215	All Time Swing	95
	1216	Let's Swing	168
	1217	Slow Swinging*	128
	1218	Sunny Swing*	118
	1241	Big Band 1 +	230
	1242	Big Band 2	198
	1243	Big Band 3	197
	1244	Big Band Boogie	170
	1245	Big Band Curt P.	192
	1246	Big Band Let's Swing	160
	1247	Big Band Moonlight	80
	1248	Big Band Fast	192
	1249	Big Band Swing Miller	166
	1250	Big Big Band +	200
	1251	Slow Fox Big Band +	100
	1252	Boogie Big Band 1	168
	1253	Boogie Big Band 2	140
	1281	Swing Brush Fastl +	200
	1282	Slo' Brushes +	68
	1301	2 a.m. Jazz +	75
	1302	Organ Jazz	171
	1303	Swing'n Snap & Brush	55

SECTION	No.	NAME	Tempo
LATIN	1401	Samba 1 +	121
	1402	Samba 2	97
	1403	Samba 3 +	119
	1404	Samba 4	114
	1405	Samba Amor	112
	1406	Samba Brazil +	112
	1407	Disco Samba 1	120
	1408	Disco Samba 2	121
	1409	Organ Samba 1	118
	1410	Organ Samba 2	121
	1411	Organ Samba 3	110
	1412	Organ Tico Tico Tico FL	112
	1413	Samba Ole	115
	1414	Basic Samba +	126
	1431	Bossa Nova 1 +	144
	1432	Bossa Nova 2 +	122
	1433	Latin Ipanema	124
	1434	Bossa 4 Lovers +	120
	1435	Organ Bossa 1	120
	1436	Organ Bossa 2	163
	1437	Organ Bossa 3	160
	1438	Modern Bossa	78
	1439	Basic Bossa +	134
	1461	Latin Night +	110
	1462	US-Latin	119
	1463	Carnival +	132
	1464	Club Rio +	113
	1465	Latin Romance +	93
	1491	Salsa	123
	1492	Mambo +	109
	1493	Slow Latin*	116

SECTION	No.	NAME	Tempo
COUNTRY	1601	Country Hits +	106
	1602	Country Pop	145
	1603	Country Shuffle	107
	1604	My Country +	100
	1605	Country Fiddle	138
	1606	Country Foxtrott	170
	1607	Country Waltz	152
	1608	Hoedown	200
	1609	Green Grass +	113
	1610	Bluegrass	142
	1611	Basic Country 2 Step +	92

SECTION	No.	NAME	Tempo
TRADITIONELL	1801	March 1 +	117
	1802	March 2	114
	1803	Organ March	120
	1804	6-8 March +	120
	1805	March Beat 1	118
	1806	March Beat 2	118
	1831	Polka Oberkrainer 1 +	128
	1832	Polka Oberkrainer 2	128
	1833	Polka Tanz	121
	1834	6-8 Volkstümlich	62
	1861	Waltz Traditional 1	184
	1862	Waltz Traditional 2	181
	1863	Vienna Waltz 1 +	159
	1864	Vienna Waltz 2	87
	1865	Organ Waltz	102
	1901	Karneval +	110
	1902	Zirkus Polka +	144

SECTION	No.	NAME	Tempo
WORLD	2001	Musette Waltz	200
	2002	Valse Musette +	190
	2011	Espania	131
	2012	Flamenco	163
	2013	Pasodoble	130
	2014	Paso Doble +	120
	2015	Bolero Conquest	77
	2016	Viva Flamenco	115
	2017	O Sole Mio	111
	2021	Dixieland 1	109
	2022	Dixieland 2	193
	2023	US-Harlem	197
	2024	US-Hip	110
	2025	US-Praise	114
	2026	Hawaiian	101
	2027	Rag Doll +	105
	2041	Reggae 1 +	97
	2042	Reggae 2	86
	2043	Reggae 3	86
	2044	Tropical	111
	2045	Sun Island	122
	2051	Sirtaki	141
	2061	Venezia +	117
	2071	Gypsy Dance +	120
	2072	Gipsy Swing +	212

SECTION	No.	NAME	Tempo
SHOW	2201	March River Kwai	123
	2202	Broadway	146
	2203	Parade	123
	2204	Showtime	155
	2205	Hollywood	219
	2206	Organ Showtime	190
	2207	Xmas Swing	135
	2208	In The Movies +	125
	2209	Biskaya JL	103
	2210	Einsamer Hirte JL	74
	2211	El Mucho JL	112
	2212	Games That Lovers JL	86
	2213	Morgens Um Sieben JL	63
	2214	Traumschiff Dinner JL	115
	2215	Tijuana Taxi JL	196
	2216	Tango Argentina JL	128
	2217	Pokerface JL	121
	2218	Summer Place JL	63
	2219	Samba Parranda JL	128
	2220	Somewhere Swing JL	92
	2221	Last Classics JL	130
	2222	Irish Waltz JL	93
	2223	Hip Hop Polka JL	128
	2224	Hansi fest. Mary JL	128
	2225	Happy Hansi JL	121
	2226	Happy Luxemburg JL	175
	2227	Happy Music JL	180
	2228	Happy Party Dance JL	130
	2229	Mit 66 Jahren	125
	2230	Griechischer Wein	78
	2231	Ich war noch niemals in New York	130
	2232	Aber bitte mit Sahne	126
	2233	Liebe ohne Leiden	126
	2234	Merci Cheri	84

2.2 List the factory styles after the control panel buttons

Note: The styles marked with an * are part of software version 3.0.

POP Level 1	16 Beat 1	16 Beat 2	8 Beat 1
	8 Beat 2	8 Beat 3	8 Beat Latin
	Beat Alps	Beat Easy	Beat Oldie
	Standard Beat 1	Standard Beat 2	Sweet Beat
	Smooth 8-Beat +	California Beat +	Beatbox +
POP Level 2	Britpop +	Basic Pop Rock +	Sixties Pop +
	Good Old Times +	Organ Euro Pop	Basic 80s Pop +
	Pop Funk 1	Pop Funk 2	Get Funky +
	Big Funk +	LA Funky House 2013	
POP Level 3	Pop Beat*	Chilled Beat*	Dream Beat*
	Easy Beat*		

ROCK Level 1	Rock 1	Rock 2	Festival Rock +
	Rock JP 1	Rock JP 2	Summer Rock +
	Deutsch Rock +	Shades of Rock +	Straight Rock
	Metal City	Blue Metal	Rock Pop Days +
	Elysium Rock		
ROCK Level 2	Rock Shuffle 1	Rock Shuffle 2	Shuffle 1
	Shuffle 2	Shuffle Rock'n Roll	Shuffle Slow
	Crooner Shuffle +	Rock Shuffle +	
ROCK Level 3	Rock'n Roll 1	Rock'n Roll 2	Rock'n Roll 3
	Rock'n Roll 4	US- Rock Roll	Basic Rock'n Roll +
ROCK Level 4	Boogie 1	Boogie 2	Piano Boogie
	Boogie Woogie	Piano Boogie Man +	
	Twist 1 +	Twist 2	
ROCK Level 5	6-8 Blues	Blues Shuffle	Blues Slow
	Blues Swing	Organ Blues	Organ Gospel
	Organ Groove		
ROCK Level 6	Slow Rock 1 +	Slow Rock 2 +	Slow Rock 3
	12/8 Slow Rock +	6/8 Blues Rock +	Summer Slow Rock
	Metal Waltz +		

DANCE Level 1	Disco 1	Disco 2 +	70er Disco Schlager +
	Dance 1	Dance 2	Dance 3
	Dance 4	80's Dance Pop +	Pop Dance +
	Club Titan +	Vintage Minimal +	Wersi on the beach
DANCE Level 2	Dance the 90's +	Techno	Trance Dance 1
	Radio Dubstep 1	Rappers Swag +	
	Basic Disco +		

BALLAD Level 1	Beat Ballade 1	Beat Ballade 2	Beat Ballade Slow
	Ballade 1	Ballade 2	Ballade 3
	Organ Ballade	US-Ballad	Ballad Forever +
	Songwriter Ballad +	Vocal Ballad +	Please Release
	Pop Ballade 1	Pop Ballade 2	Basic Modern Ballad +
BALLAD Level 2	Piano Ballade 1	Piano Ballade 2	Kölle am Dom Ballad
BALLAD Level 3	6/8 Ballade 1	6/8 Ballade 2	6/8 Ballad Pop +
	6/8 Blues Ballade	12/8 Ballade	Basic 6/8 Ballad
	Shuffle Ballad*		

BALLROOM Level 1	Beguine 1	Beguine 2	Beguine Stupid
	The Beguine +	Organ Beguine	
	Rumba 1	Rumba 2 +	Rumba Pop
	Organ Rumba	Rumba Pop	
BALLROOM Level 2	Cha Cha 1 +	Cha Cha 2	Cha Cha 3 +
	Cha Cha 4	Cha Cha Cha +	Last Cha Cha +
	Organ Cha Cha	Modern Cha Cha	Basic Cha Cha +
	Organ Cha Cha	Tango 1 +	Tango 2
	US-Tango	Tango Roberto +	
BALLROOM Level 3	Tango 1 +	Tango 2	US-Tango
	Tango Roberto +		Basic Quickstep +
	Jive 1 +	Jive 2	Jive 3
	Jive Conny	Quickstep 1	Quickstep 2 +
	Quickstep 3 +	Organ Quickstep 1	Organ Quickstep 2
BALLROOM Level 4	Foxtrott 1	Foxtrott 2 +	Foxtrott 3 +
	Foxtrott 4 +	Foxtrott Accordion	Foxtrott Brush +
	Foxtrott Sleigh Ride	Swinging Foxtrott*	
	Slow Fox 1	Slow Fox 2	Slow Fox 3+
	Slow Fox Brush +	Accappella Fox +	Basic BB Foxtrott
BALLROOM Level 5	Organ Foxtrott 1	Organ Foxtrott 2*	Organ Combo
BALLROOM Level 6	Slow Waltz 1	Slow Waltz 2	Slow Waltz 3 +
	Swing Waltz	Pop Waltz	Jazz Waltz
	Love Waltz	Basic Waltz +	English Waltz*

ENTERTAINER Level 1	Schlager Beat 1	Schlager Beat 2 +	Popschlager +
	Schlagnacht +	Schlager Pop 2014	Petry Party +
	Schlager Polka +	Schlagerqueen +	Schlager Rumba +
	Schunkelwalzer	Schlager Beat Disco 1	
ENTERTAINER Level 2	Party Modern Mix	Party Polka	Party Pop
	Party Schlager Beat	Party Time +	Party Happy Polka
	Organ Party Pop	Polonaise	Die Hände Zum Himmel
	Gri. Wein	Narhalla March	Party Saragossa +
	Happy Strike*	Party*	Latin Party*
ENTERTAINER Level 3	8 Beat Romantica	8 Beat Selena	16 Beat Jonathan
	Discofox	Lucia Walzer	Atlantis Retro
	Schlager Disco	Madonna	Slow Country
	Samba Latino	March	Sentimental Fox
	Avignon Fox	Step Fox	Happy Organ Man
ENTERTAINER Level 4	Happy Polka	Beguine	Mon Amour
	Happy Walzer	Sommerroses Ballade	Tropical Fruits
	Happy Beat	Happy Foxtrott	Happy Schlager
	Schlager Dance	Schlager Espania	Schlager Ballade
	Schlager Rumba		
ENTERTAINER Level 5	Fischer Dübel*	Schlager 1*	Schlager 2*
	Schlager Shuffle*	Schlager Slowrock*	Schlager Polka*

SWING/BIG BAND Level 1	Swing Combo	Swing Easy	Swing Sinatra
	US-Cookin Jazz	Swing It +	Slow Swing Count Basie
	Slow Swing Kaempfert	Slow Swing	Organ Swing
	Swinging Foxtrott +	Swinging Akkordeon	Jingle Swing +
	Swingin Romance +	Swing Shuffle	All Time Swing
SWING/BIG BAND Level 2	Big Band 1 +	Big Band 2	Big Band 3
	Big Band Boogie	Big Band Curt P.	Big Band Let's Swing
	Big Band Moonlight	Big Band Fast	Big Band Swing Miller
	Big Big Band +	Slow Fox Big Band +	Boogie Big Band 1
	Boogie Big Band 2		
SWING/BIG BAND Level 3	Swinging Brush Fast +	Slo'Brushes +	2 a.m. Jazz +
	Organ Jazz	Swing'n Snap & Brush	Let's Swing
	Slow Swinging*	Sunny Swing*	

LATIN Level 1	Samba 1 +	Samba 2	Samba 3 +
	Samba 4	Samba Amor	Samba Brasil +
	Disco Samba 1	Disco Samba 2	Organ Samba 1
	Organ Samba 2	Organ Samba 3	Organ TicoTicoTico FL
	Samba Ole	Basic Samba +	Slow Latin*
LATIN Level 2	Bossa Nova 1 +	Bossa Nova 2 +	Latin Ipanema
	Bossa 4 Lovers +	Organ Bossa 1	Organ Bossa 2
	Organ Bossa 3	Basic Bossa +	Basic Bossa +
LATIN Level 3	Latin Night +	US-Latin	Carnival +
	Club Rio +	Latin Romance +	Salsa
	Mambo +		

COUNTRY Level 1	Country Hits 1	Country Pop	Country Shuffle
	My Country +	Country Fiddle	Country Foxtrott
	Country Waltz	Hoedown	Green Grass +
	Blue Grass	Basic Country 2 Step +	

TRADITIONAL Level 1	March 1 +	March 2	Organ March
	6-8 March +	March Beat 1	March Beat 2
	Polka Oberkrainer 1 +	Polka Oberkrainer	Polka Tanz
	6-8 Traditionell		
TRADITIONAL Level 2	Waltz Traditional 1	Waltz Traditional 2	Vienna Waltz 1 +
	Vienna Waltz 2	Organ Walzer	Karneval +
	Zirkus Polka +		

WORLD Level 1	Musette Waltz	Valse Musette +	Espania
	Flamenco	Pasodoble	Paso Doble +
	Bolero Conquest	Viva Flamenco	O Sole Mio
	Sirtaki	Venezia +	Gypsy Dance +
	Gipsy Swing +		
WORLD Level 2	Dixieland 1	Dixieland 2	US-Harlem
	US-Hip	US-Praise	Hawaiian
	Rag Doll +	Reggae 1 +	Reggae 2
	Reggae 3	Tropical	Sun Island

MOVIE&SHOW Level 1	March River Kwai	Broadway	Parade
	Showtime	Hollywood	Organ Showtime
	Xmas Swing	In The Movies +	
MOVIE&SHOW Level 2	Biskaya JL	Einsamer Hirte JL	El Mucho JL
	Games That Lovers JL	Morgens Um Sieben JL	Traumschiff Dinner JL
	Tijuana Taxi JL	Tango Argentina JL	Pokerface JL
	Summer Place JL	Samba Parranda JL	Somewhere Swing JL
	Last Classics JL	Irish Waltz JL	Hip Hop Polka JL
MOVIE&SHOW Level 3	Hansi fest. Mary JL	Happy Hansi JL	Happy Luxemburg JL
	Happy Music JL	Happ Party Dance JL	
	Mit 66 Jahren	Griechischer Wein	Ich war noch niemals in New York
	Aber bitte mit Sahne	Liebe ohne Leiden	Merci Cheri

3 Music Archive

3.1 Music Archive sorted by German and World

Tritsch Tratsch Polka	German
1000 Wege Führen Ins Paradies	German
Aber Bitte Mit Sahne	German
Aber Dich Gibts Nur Einmal Für Mich	German
Addio	German
Adios Amour	German
Alle Engel Sind Amigos	German
Alle Mädchen Wollen Küssen	German
Alle Vögel Sind Schon Da	German
Alles Wird Gut	German
Almenrausch Und Pulverschnee	German
Am Brunnen Vor Dem Tore	German
Am Golf Von Biskaya	German
Am Liebsten Tanz I Mit Dir	German
Am Montparnasse	German
Amapola Ricky King	German
Amboss Polka	German
An A Wunder Hoab I Glaub	German
An Der Nordseeküste	German
An Der Schönen Blauen Donau	German
Anita	German
Anna Lena	German
Ännchen Von Tharau	German
Anneliese	German
Anton Aus Tirol	German
Apache	German
Arrivederci Roma	German
Atlantis	German
Atlantis Der Berge	German
Auch Das Geht Klar	German
Auf Aamoa	German
Auf Auf Zum fröhlichen Jagen	German
Auf Der Autobahn	German
Auf Wiedersehn	German
Aus Böhmen Kommt Die Musik	German
Baby Blues	German
Baby Elephant Walk	German
Banjo Boy	German
Begin The Beguin	German
Beim Kronenwirt	German
Beim Stelldichein In Oberkrain	German
Bella Italia	German
Bella Musica	German
Berge Ohne Wiederkehr	German

Bergvagabunden	German
Blas Mir Mal Die Wolken Fort	German
Blau Blüht Der Enzian	German
Blaue Nacht Am Hafen	German
Blondes Gift	German
Blue Bayou German	German
Blue Tango	German
Blumenwalzer	German
Bora Bora	German
Bronze, Silber Und Gold	German
Buenos Dias Argentina	German
Bussi Bussi	German
Capri Fischer	German
Cara Mia	German
Cheerio	German
Cheri Cheri Lady	German
Chianti Wein	German
Ciao d'Amore	German
Ciao Maria Diao	German
Da Sprach Der Alte Häuptling Der Indianer	German
Danke Schön Und Auf Wiedersehn	German
Dann Nehm Ich Dich In Meine Arme	German
Danze Dun Ich Nur Mit Dir	German
Das Erste Gebot Ist Die Liebe	German
Das Geheimnis Der Johannesnacht	German
Das Jungfrauenchor	German
Das Kleine Hertzlerl In Der Linde	German
Das Mädchen Ohne Namen	German
Das Schöne Mädchen Von Seite 1	German
Das Wandern Ist Des Müllerslust	German
Davon Geht Die World Nicht Unter	German
De Lustigen Holzhackerleit	German
Deinen Namen Den Hab Ich Vergessen	German
Delicado Ricky King	German
Der Dritte Mann	German
Der Himmel Lässt Uns Nie Allein	German
Der Junge Mit Der Mundharmonika	German
Der Junge Von St. Pauli	German
Der Mail Ist Gekommen	German
Der Mond Hält Seine Wacht	German
Der Treue Husar	German
Des Is A Wahnsinn	German
Dicke Mädchen Haben Schöne Namen	German

Die Fischerin Vom Bodensee	German	Er Hat Ein Knallrotes Gummiboot	German
Die Gedanken Sind Frei	German	Erst Ein Cappuchino	German
Die Gitarre Und Das Meer	German	Erst Willst Du Mich Dann Willst Du Nicht	German
Die Glocken Von Rom	German	Es Gibt Kein Bier Auf Hawaii	German
Die Goldenen Jahre	German	Es Hängt Ein Pferdehalfter	German
Die Hände Zum Himmel	German	Es Klappert Die Mühle	German
Die Kleine Kneipe	German	Es War Im Böhmerwald	German
Die kloanne Tür Zum Paradies	German	Feuer Im Ewigen Eis	German
Die Rose Vom Wörthersee	German	Fiesta Mexicana	German
Die Rosen Der Madonna	German	Flieg Junger Adler	German
Die Schwarze Barbara	German	Frauen Sind Was Wunderbares	German
Die Sieben Leben Der Zärtlichkeit	German	Freut Euch Des Lebens	German
Die Sommernächte Und Du	German	Frühlingsstimmen	German
Die Trompeten Von Kastelruth	German	Für Gaby Tu Ich Alles	German
Die Weisse Braut Der Berge	German	Für Jedes Herz Das Einsam Ist	German
Die Wirtin Von Alm	German	Für Mich Soll's Rote Rosen Regnen	German
Dolannes Melodie	German	Ganz In Weiß	German
Dornenvögel	German	Gefühl Ist Eine Achterbahn	German
Drina Marsch	German	Gefunden Auf Der Autobahn	German
Drunten Im Unterland	German	Geh Doch	German
Du Bist Das Schönste Mädchen	German	Geisterreiter	German
Du Du Liegst Mir Im Herzen	German	Glaube Mir	German
Du Gehörst In Meine Arme	German	Gold Und Silber	German
Du Gehst Fort	German	Gondoletta	German
Du Hast Mich 1000 Mal Belogen	German	Griechischer Wein	German
Du Kannst Nicht Immer 17 Sein	German	Große Freiheit Nr.7	German
Du Schwarzer Zigeuner	German	Grün Grün Grün Sind Alle Meine Kleider	German
Echo Der Berge	German	Guten Abend Gute Nacht	German
Edelweiß German	German	Hab Ich Dir Heute Schon Gesagt Daß Ich	
Edelweißlied	German	Dich Liebe	German
Ein Bisschen Frieden	German	Hallo Frau Nachbarin	German
Ein Bisschen Spass Muss Sein	German	Hallo Guten Morgen Germanland	German
Ein Heller Und Ein Batzen	German	Hamburger Veermaster	German
Ein Jäger Aus Kurpfalz	German	Hände Zum Himmel	German
Ein Schlafsack Und Eine Gitarre	German	Hast A Biserl Zeit Für Mich	German
Ein Vogel Wollte Hochzeit Machen	German	Heimat Deine Sterne	German
Eine Kleine Träne Weinte Sie	German	Heimweh Nach Der Heimat	German
Eine Insel Aus Träumen Geboren Bora		Heimweh Nach Montana	German
Bora	German	Heimwehmelodie	German
Eine Mark Für Charly	German	Heinzelmännchens Wachtparade	German
Eine Seefahrt Die Ist Lustig	German	Heißer Sand	German
Eine Träne Von Ihr	German	Hello Again	German
Eine Weiße Hochzeitskutsche	German	Hello Mary Lou German	German
Eine Weiße Rose	German	Herzenssache	German
Einsamer Hirte	German	Herzilein	German
El Condor Pasa German	German	Herzklopfen	German
Elisabeth	German	Herzlich Willkommen	German
Er Gehört Zu Mir	German	Herzschlag Für Herzschlag	German

Herz-Schmerz	German
Hey Baby German	German
Hoch Auf Dem Gelben Wagen	German
Hohe Tannen	German
Holzschuh Polka	German
Horch Was Kommt Von Draußen Rein	German
Hummelflug	German
Ich Bau Dir Ein Schloss	German
Ich Bin Immer Da Wo Die Musik Spielt	German
Ich Bin Verliebt In Dich	German
Ich Bin Verliebt In Die Liebe	German
Ich Bleibe Immer Bei Dir	German
Ich Denk So Gern An Billy Vaughn	German
Ich Hab Den Himmel Gesehn	German
Ich Hab Dich Zum Küsselfen Gern	German
Ich Hab Die Liebe Gesehn	German
Ich Habe Was, Was Du Nicht Hast	German
Ich Hätt Dich Sowieso Geküsst	German
Ich Kann Keine Traurigen Augen Sehn	German
Ich Könnt Die Berge Umarmen	German
Ich Möcht' Gern Dein Herz Klopfen	
Hör'n	German
Ich Tanz Mit Dir In Den - Frank Galan	German
Ich Tanz Mit Dir In Den Himmel Hinein	German
Ich War Noch Nie Dem Himmel So Nah	German
Ich War Noch Niemals In New York	German
Ich Weiss Nicht Was Soll Es Bedeuten	German
Ich Wünsch Euch Eine Gute Nacht	German
Ich Würd Es Wieder Tun	German
Ich Zähle Täglich Meine Sorgen	German
Ich Zeig Dir Die Berge	German
Im Frühtau Zu Berge	German
Im Heißen Sand Von Rhodos	German
Im Krug Zum Grünen Kranze	German
Im Schönsten Wiesengrunde	German
Immer Wieder Sehnsucht	German
In Den Schönen Tiroler Bergen	German
In Einem Kühlen Grunde	German
In Einem Polenstädtchen	German
Ist Das Ein Sauladen Hier	German
Je,taime Heißt Ich Liebe Dich	German
Jeder Braucht Ein Bisschen Glück	German
Jedes Abendrot Ist Ein Gebet	German
Jetzt Geht Die Party Richtig Los	German
Jetzt Geht Die Party Tichtig Los - De Randfichten	German
Jetzt Kommen Die Lustigen Tage	German
Jetzt Oder Nie	German

Jive Connie	German
Julie	German
Junge Bergfee	German
Junge Komm Bald Wieder	German
Kaiserwalzer	German
Karamba Caracho Ein Whisky	German
Karawane-Medley	German
Kärntner Liedermarsch	German
Ketchup Song	German
Kleine Möwe Flieg Nach Helgoland	German
Komm Auf Das Schiff Meiner Träume	German
Komm Auf Ein Bier Zu Mir	German
Komm Nach Tirol Senorita	German
Kriminal-Tango	German
Kufsteinlied	German
Küss Mich	German
Küssen Wie Gott In Tirol	German
La Bamboloa	German
La Bella Bella Musica	German
La Mondonara	German
La Paloma	German
La Paloma (beguine)	German
La Provence	German
Lady Sunshine Und Mr. Moon	German
Lieb Mich Noch Mal	German
Liebe Darf Alles	German
Liebeskummer Lohnt Sich Nicht	German
Lustig Ist Das Zigeunerleben	German
Man Müsste Nochmal Zwanzig Sein	German
Manchmal Möchte Ich Schon Mit Dir	German
Märchenaugen	German
Mariandl	German
Marina	German
Märkische Heide	German
Marmor Stein Und Eisen Bricht	German
Mein Hut Der Hat Drei Ecken	German
Mein Schatz, Ich Hab' Dich Heut Noch Lieb	German
Mein Vater War Ein Wandermann	German
Meine Lieder Streicheln Dich	German
Memory Melodie	German
Mendocino	German
Mi Corazon	German
Michaela	German
Midnight Lady	German
Mit 17 Hat Man Noch Träume	German
Mit 66 Jahren	German
Mit Den Augen Gefunden	German

Mitternachtsblues	German	Air On The G String	World
Mona	German	Alfie	World
Monja	German	All By Myself	World
Monte D,amour	German	All I Ask Of You	World
Moonlight	German	All I Have To Do Is Dream	World
Morgen Früh Bin Ich Bei Dir	German	All Kinds Of Everything	World
Morgens Um Sieben	German	All Night Long	World
Moskau	German	All Of Me	World
Muss I Denn Zum Städtele Hinaus	German	All Out Of Love	World
O Mein Papa	German	All Right Now	World
O Solo Mio German	German	All Shook Up	World
Peppermint Twist	German	All You Need Is Love	World
Santa Maria	German	Always Look On The Brightside Of Life	World
Schiwago Melodie	German	Always On My Mind	World
Seemann Lass Das Träumen	German	Always Something There To Remind Me	World
Serenade Der Liebe	German	Amapola	World
Sieben Fässer Wein	German	Amazing Grace	World
So Ein Tag So Wunderschön Wie Heute	German	American Patrol	World
Sommernacht In Rom	German	American Pie	World
Tanze Mit Mir In Den Morgen	German	Amore	World
Tausend Rote Rosen	German	And Then He Kissed Me	World
Trompetenträume	German	Angels	World
Verde - Ricky King	German	Annies Song	World
You're My Heart You're My Soul	German	Another Day In Paradise	World
Zirkus Renz	German	Apache	World
A Crazy Little Thing Called Love	World	April In Portugal	World
A Hard Days Night	World	Are You Lonesome Tonight	World
A Kind Of Magic	World	Arrivederci Roma	World
A Kiss To Build A Dream On	World	Arthurs Theme	World
A Lovely Way To Spend An Evening	World	As Time Goes By	World
A Man And a Woman	World	Atmosphere	World
A Spoon Full Of Sugar	World	Autumn Leaves	World
A Swingin Safari	World	Ave Maria	World
A Walk In The Black Forest	World	Ave Maria No Moro	World
A Whiter Shade Of Pale	World	Baby Face	World
Abanda BW	World	Back For Good	World
Abide With Me	World	Bad Moon Rising	World
Abracadabra	World	Ballad Pour Adeline	World
Achy Breaky Heart	World	Be My Baby	World
Adagio For Strings Trance	World	Beauty And The Beast	World
After The Love Has Gone	World	Begin The Beguine	World
AfterYouve Gone	World	Believe	World
Agadoo	World	Besame Mucho	World
Against All Odds	World	Beyond The Sea	World
Ai No Corrida	World	Blanket On The Ground	World
Aint Misbehaving	World	Blue Bayou World	World
Aint No Pleasing You	World	Blue Eyes	World
Aint Nobody	World	Blue Moon	World

Blueberry Hill	World
Bolero	World
Brazil	World
Bridge Over Troubled Water	World
Brother Louie	World
By The Time I Get To Pheonix	World
Cabaret	World
Candle In The Wind	World
Cant Help Falling In Love	World
Cant Smile Without You	World
Cavaquinho	World
Cavatina	World
Chain Reaction	World
Chanson D'amour	World
Charleston	World
Chattanooga Choo Choo	World
Cheek To Cheek	World
Cherish	World
Cherry Pink And Apple Blossom	World
Chicago	World
Children	World
Chitty Chitty Bang Bang	World
Clair	World
Clocks	World
Close To You	World
Colonel Bogey	World
Come Fly With Me	World
Comment Cava	World
Congratulations	World
Conquest Of Paradise	World
Consider Yourself	World
Copacabana	World
Cracklin Rosie	World
Crazy	World
Crazy Little Thing Called Love	World
Crocodile Rock	World
Crying	World
Crying In The Rain	World
D.I.S.C.O.	World
Da doo Ron Ron	World
Daddy Cool	World
Dads Army	World
Dancing Queen	World
Daniel	World
Danke Schön	World
Danny Boy	World
Daydream Believer	World
Desafinado	World

Devil gate drive	World
Diana	World
Do You Think I'm Sexy	World
Dont Be Cruel	World
Dont Cry For Me Argentina	World
Dont Get Around Much Anymore	World
Dont Go Breaking My Heart	World
Dont Know Why I Love You	World
Dont Leave Me This Way	World
Dont Let The Sun Go Down On Me	World
Dont Look Back In Anger	World
Dont Sit Under The Apple Tree	World
Dont Stop Thinking About Tomorrow	World
Dont Want To Miss A Thing	World
Dont Worry Be Happy	World
Downtown	World
Dream Lover	World
Earth Song	World
Easy	World
Ebb Tide	World
Edelweiß World	World
Eine Kleine Nachtmusik	World
El Condor Pasa World	World
El Cumbanchero	World
Elizabethan Serenade	World
Elouise	World
Elvira Madigan	World
End Of The Road	World
Entry Of The Gladiators	World
Every Breath You Take	World
Every Thing I Do I Do It For You	World
Every Time You Go Away	World
Exactly Like You	World
Feelings	World
Fernando	World
Ferry Across The Mersey	World
Fields Of Gold	World
Five Foot Two Eyes Of Blue	World
Flashdance What A Feeing	World
Fly Me To The Moon	World
Fool If You Think Its Over	World
Foot Tapper	World
For Once In My Life	World
Forgotten Dreams	World
From A distance	World
Funky Town	World
Georgia On My Mind	World
Get Back	World

Ghostriders In The Sky	World
Gimmie Gimmie Gimmie	World
Girl Put Your Records On	World
Glory Of Love	World
Go West	World
Good Golly Miss Molly	World
Good Luck Charm	World
Goodbye Yellowbrick Road	World
Great Balls Of Fire	World
Greatest Love Of All	World
Green Green Grass Of Home	World
Greensleeves	World
Guantanamera	World
Halleluja	World
Hands Up	World
Happy Days Are Here Again	World
Happy Together	World
Have I Told You Lately	World
He Aint Heavy	World
Heartbeat	World
Heartbreaker	World
Heaven Is A Place On Earth	World
Hello	World
Hello Dolly	World
Hello Mary Lou World	World
Help Me Make It Through The Night	World
Help Yourself	World
Heres That Rainy Day	World
Hero Enreque	World
Hes Got The Whole In His Hand	World
Hey Baby World	World
Hey Good Looking	World
Hey Jude	World
Hi Ho Silver Lining	World
High Hopes	World
High Noon	World
Hillbilly Rock	World
Honeysuckle Rose	World
Honkytonk Woman	World
Hopelessly Devoted To You	World
Hot Stuff	World
Hot Toddy	World
Hotel California	World
House Of The Rising Sun	World
How Can You Mend A Broken Heart	World
How Deep Is Your Love	World
How Do I Live	World
Human Nature	World
Hungarian Dance	World
I Am A Cider Drinker	World
I Believe	World
I Believe I Can Fly	World
I Can See Clearly Now	World
I Cant Stop Loving You	World
I Could Have Danced All Night	World
I Dont Know Why I Love You But I Do	World
I Dont Wanna Dance	World
I Dreamed A Dream	World
I Get A Kick Out Of You	World
I Have A Dream	World
I Heard It Through The Grapevine	World
I Just Called To Say I Love You	World
I Just Cant Stop Loving You	World
I Know Him So Well	World
I Left My Heartin San Fransisco	World
I Love Ro Love	World
I Love You And Dont You Forget It	World
I Love Your Smile	World
I Miss You Like Crazy	World
I Only Wanna Be With You	World
I Shot The Sheriff	World
I Swear	World
I Wanna Hold Your Hand	World
I Wanna Know What Love Is	World
I Want To Break Free	World
I Want You To Want Me	World
I Will Always Love You	World
I Will Survive	World
I Wish	World
I Wont Last A Day Without You	World
I Wont Send Roses	World
I Write The Songs	World
Id Like To Teach The World To Sing	World
If I Could Dream	World
If I Could Turn Back Time	World
If I Had A Hammer	World
If Tomorrow Never Comes	World
If You Could Read My Mind	World
If you dont know me by now	World
I'll Be There	World
I'll Go Where Your Music Takes Me	World
I'll Make Love To You	World
I'll Never Fall In Love Again	World
I'm In The Mood For Love	World
I'm So Excited	World
Imagine	World

In A Spanish Town	World
In The Air Tonight	World
In The Ghetto	World
In The Hall Of The Mountain King	World
In The Mood	World
In The Navy	World
Islands In The Stream	World
Isn't She Lovely	World
It Don't Mean A Thing If It Aint	World
It Never Rains In Southern California	World
It's A Heartache	World
It's A Long Way To Tipperery	World
It's A Sin	World
It's A Small World	World
It's My Party	World
It's Not Unusual	World
It's Now Or Never	World
I've Got A Lovely Bunch Of Coconuts	World
Jailhouse Rock	World
Jambalayo	World
Java	World
Johnny B. Good	World
Jump	World
Just The Way You Are	World
Killing Me Softly	World
King Of The Road	World
Kingston Town	World
Knees Up Mother Brown	World
Knock Knocking On Heavens Door	World
Knock On Wood	World
Kumbaya	World
L O V E	World
La Bamba	World
La Cucaracha	World
La Cumparsita	World
La Isla Bonita	World
Ladies Night	World
Lady Be Good	World
Lady In Red	World
Lady Madonna	World
Lately	World
Laughter In The Rain	World
Lay All Your Love On me	World
Lay Down Sally	World
Leader Of The Pack	World
Let It Be	World
Let It Be Me	World
Let Your Love Flow	World
Let's Face Fhe Music And Dance	World
Let's Stick Together	World
Let's Twist Again	World
Licence To Kill	World
Life Is Life	World
Light My Fire	World
Little Brown Jug	World
Living La Vida Loca	World
Living Next Door To Alice	World
Living On A Prayer	World
Lonely Is A Man Without Love	World
Long Train Running	World
Love Changes Everything	World
Love Hurts	World
Love Is Here To Stay	World
Love Is In The Air	World
Love Letters	World
Love Letters In The Sand	World
Love Me Do	World
Love Me For A Reason	World
Love Me Tender	World
Love Story	World
Love Theme From Godfather	World
Loveboat Theme	World
Lullaby Of Birdland	World
Mack The Knife	World
Maggie May	World
Mama Mia	World
Mamy Blue	World
Mandy	World
Maria	World
Maria Wlana	World
Mary's Boy Child	World
Massachusetts	World
Me And My Shaddow	World
Meditation	World
Melody In F	World
Memory	World
Mexican Hat Dance	World
Michael Row The Boat Ashore	World
Midnight In Moscow	World
Mississippi	World
Misty	World
Monday Monday	World
Money Money Money	World
Moon River	World
Moontlight Shadow	World
More	World

More More More	World
Morning Has Broken	World
Morning In Cornwall	World
Mornings At 7	World
Moskow Moscow	World
Most Beautiful Girl In The World	World
Mr. Sandman	World
Mr. Tambourine Man	World
Mrs. Robinson	World
Mull Of Kintyre	World
Muppets Show	World
Music Box Dancer	World
Music Of The Night	World
Music To Watch Girls By	World
Mustang Sally	World
My Bonnie Lies Over The Ocean	World
My Boy Lollipop	World
My Cherie Amour	World
My Girl	World
My Old Man Dont Dilly Dally	World
My Way	World
Never Can Say Goodbye	World
Never On A Sunday	World
New York New York	World
Nights In White Satin	World
No Matter What	World
No Woman No Cry	World
Nobody Does It Better	World
Nothings Gonna Change My Love	World
O solo Mio World	World
Obladi Oblada	World
Ode To Joy	World
Oh Carol	World
Oh Suzanna	World
Old Man River	World
On The Road Again	World
On The Street Where You Live	World
On The Sunny Side Of The Street	World
On Top Of Old Smokie	World
One	World
One Day I'll Fly Away	World
Paper Moon	World
Parfidia	World
Patricia	World
Peggy Sue	World
Penny Lane	World
Pensylvania 6500	World
Petite Fleur	World

Piano Man	World
Picking Up The Pieces	World
Popcorn	World
Pretty Woman	World
Puppet On A String	World
Quando Quando	World
Raindrops Keep Falling On My Head	World
Rasputin	World
Red River Rock German	World
Red River Rock World	World
Red Roses For A Blue Lady	World
Red Roses For A Blue Lady	World
Redetzky March	World
Reet Petite	World
Release Me	World
Return To Sender	World
Rhinestone Cowboy	World
Ring Of Fire	World
Rivers Of Babylon	World
Rock Around The Clock	World
Rocking All Over The World	World
Romeo And Juliet Theme	World
Rosamunda	World
Rose Garden	World
Route 66	World
Runaway	World
Sabre Dance	World
Sailing	World
Samba De Janeiro	World
Satin Doll	World
Save All Your Kisses For Me	World
Save The Last Dance For Ne	World
Save Your Love	World
Sealed With A Kiss	World
Seasons In The Sun	World
See You Later Alligator	World
September	World
She	World
She Loves You	World
Shoop Shoop Song	World
Signed Sealed Delivered	World
Silence Is Golden	World
Singing In The Rain	World
Singing The Blues	World
Sitting On The Dock Of The Bay	World
Sloop John B.	World
Smoke Gets In Your Eyes	World
So Whats New	World

Some Broken Hearts Never Mend	World
Something	World
Something Stupid	World
Somewhere My Love	World
Somewhere Out There	World
Song For Guy	World
Sorry Seems To Be The Hardest Word	World
Spanish Eyes	World
Spirit In The Sky	World
Stand By Me	World
Stand By Your Man	World
Stop In The Name Of Love	World
Stranger In Paradise	World
Strangers In The Night	World
Streets Of London	World
String Of Pearls	World
Sugar Baby Love	World
Summer Holiday	World
Summer Of 69	World
Summertime	World
Sunny	World
Supercalifagilisticexpialidocious	World
Sway	World
Sweet Georgia Brown	World
Sweet Home Chicago	World
S'wonderfull	World
Symphony No. 40	World
Take Me Home Country Roads	World
Take The A Train	World
Tea For Two	World
Tears In Heaven	World
Tears On My Pillow	World
Teddybear	World
Tennessee Waltz	World
Tequila	World
That'll Be The Day	World
The Bare Necesities	World
The Breeze And I	World
The Cat	World
The End Of The World	World
The Final Countdown	World
The Girl From Ipanema	World
The Great Escape	World
The Great Pretender	World
The Lady Is A Tramp	World
The Last Waltz	World
The Locomotion	World
The Lonely Sheppard	World
The Magnificent Seven	World
The Nearness Of You	World
The Power Of Love	World
The Shadow Of Your Smile	World
The Sound Of Silence	World
The Sun Ain't Gonna Shine Anymore	World
The Tide Is High	World
The Typewriter Song	World
The Waltons	World
The Wanderer	World
The Way We Were	World
The Way You Look Tonight	World
The Wind Beneath My Wings	World
The Wonder Of You	World
The Young Ones	World
Theme From A Summers Place	World
Theme From Thornbirds	World
Theres A Kind Of A Hush	World
Thers No Business Like Showbusiness	World
These Boots Were Made For Walking	World
They Can't Take That Away From Me	World
This Guys In Love With You	World
This Masquerade	World
This Old House	World
Those Magnificent Men In Their Flying Mac	World
Three Times A Lady	World
Thunder And Lightening Polka	World
Tico Tico	World
Tie A Yellow Ribon	World
Tiger Feet	World
Tijuana Taxi	World
Till	World
Till There Was You	World
Tiptoe Through The Tulips	World
Titanium	World
To All The Airs I've Loved Before	World
To love somebody	World
Tonight	World
Too Much Heaven	World
Top Of The World	World
Toreador Song	World
Torn	World
Total Eclipse Of The Heart	World
Tragedy	World
Trolley Song	World
True Colours	World
True Love	World

Trumpet Voluntary	World
Turkey In The Straw	World
Tutti Fruity	World
Tuxedo Junction	World
Twentyfour Hours From Tulsa	World
Twist And Shout	World
Two Out Of Three Ain't Bad	World
Una Paloma Blanca	World
Unchained Melody	World
Unforgettable	World
Up Up And Away	World
Up Where We Belong	World
Uptown Girl	World
Venus	World
Video Killed The Radio Star	World
Vincent	World
Viva Espania	World
Volare	World
Walk Of Life	World
Walk On By	World
Waltz Of The Flowers	World
Waltzing Matilda	World
Wandering Star	World
Waterloo	World
Watermelon Man	World
Wave	World

We Are Family	World
We Are Going To Ibiza	World
We Are The Champions	World
We Are The World	World
We Have All The Time In The World	World
We Will Rock You	World
Welcome Home	World
Welcome To My World	World
We've Only Just Begun	World
What A Difference A Day Makes	World
What A Wonderful World	World
What Now My Love	World
What The World Needs Now	World
Whatever You Want	World
When A Man Loves A Woman	World
William Tell Overture	World
With A Little Help From My Friends	World
Without You	World
Woman	World
Woman In Love	World
Wonderful Land	World
Wonderwall	World
Yesterday	World
YouAre My Sunshine	World
Zip A Dee Doo Dah	World

3.2 Musik Archiv sorted by A - Z

1000 Wege Führen Ins Paradies	German	Always Something There To Remind Me	World
A Crazy Little Thing Called Love	World	Am Brunnen Vor Dem Tore	German
A Hard Days Night	World	Am Golf Von Biskaya	German
A Kind Of Magic	World	Am Liebsten Tanz I Mit Dir	German
A Kiss To Build A Dream On	World	Am Montparnasse	German
A Lovely Way To Spend An Evening	World	Amapola	World
A Man And a Woman	World	Amapola Ricky King	German
A Spoon Full Of Sugar	World	Amazing Grace	World
A Swingin Safari	World	Amboss Polka	German
A Walk In The Black Forest	World	American Patrol	World
A Whiter Shade Of Pale	World	American Pie	World
Abanda BW	World	Amore	World
Aber Bitte Mit Sahne	German	An A Wunder Hoab I Glaub	German
Aber Dich Gibts Nur Einmal Für Mich	German	An Der Nordseeküste	German
Abide With Me	World	An Der Schönen Blauen Donau	German
Abracadabra	World	And Then He Kissed Me	World
Achy Breaky Heart	World	Angels	World
Adagio For Strings Trance	World	Anita	German
Addio	German	Anna Lena	German
Adios Amour	German	Ännchen Von Tharau	German
After The Love Has Gone	World	Anneliese	German
AfterYouve Gone	World	Annies Song	World
Agadoo	World	Another Day In Paradise	World
Against All Odds	World	Anton Aus Tirol	German
Ai No Corrida	World	Apache	World
Aint Misbehaving	World	Apache	German
Aint No Pleasing You	World	April In Portugal	World
Aint Nobody	World	Are You Lonesome Tonight	World
Air On The G String	World	Arrivederci Roma	World
Alfie	World	Arrivederci Roma	German
All By Myself	World	Arthurs Theme	World
All I Ask Of You	World	As Time Goes By	World
All I Have To Do Is Dream	World	Atlantis	German
All Kinds Of Everything	World	Atlantis Der Berge	German
All Night Long	World	Atmosphere	World
All Of Me	World	Auch Das Geht Klar	German
All Out Of Love	World	Auf Aamoa	German
All Right Now	World	Auf Auf Zum fröhlichen Jagen	German
All Shook Up	World	Auf Der Autobahn	German
All You Need Is Love	World	Auf Wiedersehn	German
Alle Engel Sind Amigos	German	Aus Böhmen Kommt Die Musik	German
Alle Mädchen Wollen Küssen	German	Autumn Leaves	World
Alle Vögel Sind Schon Da	German	Ave Maria	World
Alles Wird Gut	German	Ave Maria No Moro	World
Almenrausch Und Pulverschnee	German	Baby Blues	German
Always Look On The Brightside Of Life	World	Baby Elephant Walk	German
Always On My Mind	World	Baby Face	World

Back For Good	World	Chattanooga Choo Choo	World
Bad Moon Rising	World	Cheek To Cheek	World
Ballad Pour Adeline	World	Cheerio	German
Banjo Boy	German	Cheri Cheri Lady	German
Be My Baby	World	Cherish	World
Beauty And The Beast	World	Cherry Pink And Apple Blossom	World
Begin The Beguin	German	Chianti Wein	German
Begin The Beguine	World	Chicago	World
Beim Kronenwirt	German	Children	World
Beim Stelldichein In Oberkrain	German	Chitty Chitty Bang Bang	World
Believe	World	Ciao d'Amore	German
Bella Italia	German	Ciao Maria Diao	German
Bella Musica	German	Clair	World
Berge Ohne Wiederkehr	German	Clocks	World
Bergvagabunden	German	Close To You	World
Besame Mucho	World	Colonel Bogey	World
Beyond The Sea	World	Come Fly With Me	World
Blanket On The Ground	World	Comment Cava	World
Blas Mir Mal Die Wolken Fort	German	Congratulations	World
Blau Blüht Der Enzian	German	Conquest Of Paradise	World
Blaue Nacht Am Hafen	German	Consider Yourself	World
Blondes Gift	German	Copacabana	World
Blue Bayou German	German	Cracklin Rosie	World
Blue Bayou World	World	Crazy	World
Blue Eyes	World	Crazy Little Thing Called Love	World
Blue Moon	World	Crocodile Rock	World
Blue Tango	German	Crying	World
Blueberry Hill	World	Crying In The Rain	World
Blumenwalzer	German	D.I.S.C.O.	World
Bolero	World	Da doo Ron Ron	World
Bora Bora	German	Da Sprach Der Alte Häuptling Der Indianer	German
Brazil	World	Daddy Cool	World
Bridge Over Troubled Water	World	Dads Army	World
Bronze, Silber Und Gold	German	Dancing Queen	World
Brother Louie	World	Daniel	World
Buenos Dias Argentina	German	Danke Schön	World
Bussi Bussi	German	Danke Schön Und Auf Wiedersehen	German
By The Time I Get To Pheonix	World	Dann Nehm Ich Dich In Meine Arme	German
Cabaret	World	Danny Boy	World
Candle In The Wind	World	Danke Dun Ich Nur Mit Dir	German
Cant Help Falling In Love	World	Das Erste Gebot Ist Die Liebe	German
Cant Smile Without You	World	Das Geheimnis Der Johannesnacht	German
Capri Fischer	German	Das Jungfrauenchor	German
Cara Mia	German	Das Kleine Hertzlerl In Der Linde	German
Cavaquinho	World	Das Mädchen Ohne Namen	German
Cavatina	World	Das Schöne Mädchen Von Seite 1	German
Chain Reaction	World	Das Wandern Ist Des Müllerslust	German
Chanson D'amour	World	Davon Geht Die World Nicht Unter	German
Charleston	World		

Daydream Believer	World
De Lustigen Holzhackerleit	German
Deinen Namen Den Hab Ich Vergessen	German
Delicado Ricky King	German
Der Dritte Mann	German
Der Himmel Lässt Uns Nie Allein	German
Der Junge Mit Der Mundharmonika	German
Der Junge Von St. Pauli	German
Der Mail Ist Gekommen	German
Der Mond Hält Seine Wacht	German
Der Treue Husar	German
Des Is A Wahnsinn	German
Desafinado	World
Devil gate drive	World
Diana	World
Dicke Mädchen Haben Schöne Namen	German
Die Fischerin Vom Bodensee	German
Die Gedanken Sind Frei	German
Die Gitarre Und Das Meer	German
Die Glocken Von Rom	German
Die Goldenen Jahre	German
Die Hände Zum Himmel	German
Die Kleine Kneipe	German
Die kloanne Tür Zum Paradies	German
Die Rose Vom Wörthersee	German
Die Rosen Der Madonna	German
Die Schwarze Barbara	German
Die Sieben Leben Der Zärtlichkeit	German
Die Sommernächte Und Du	German
Die Trompeten Von Kastelruth	German
Die Weisse Braut Der Berge	German
Die Wirtin Von Alm	German
Do You Think I'm Sexy	World
Dolannes Melodie	German
Dont Be Cruel	World
Dont Cry For Me Argentina	World
Dont Get Around Much Anymore	World
Dont Go Breaking My Heart	World
Dont Know Why I Love You	World
Dont Leave Me This Way	World
Dont Let The Sun Go Down On Me	World
Dont Look Back In Anger	World
Dont Sit Under The Apple Tree	World
Dont Stop Thinking About Tomorrow	World
Dont Want To Miss A Thing	World
Dont Worry Be Happy	World
Dornenvögel	German
Downtown	World
Dream Lover	World
Drina Marsch	German
Drunten Im Unterland	German
Du Bist Das Schönste Mädchen	German
Du Du Liegst Mir Im Herzen	German
Du Gehörst In Meine Arme	German
Du Gehst Fort	German
Du Hast Mich 1000 Mal Belogen	German
Du Kannst Nicht Immer 17 Sein	German
Du Schwarzer Zigeuner	German
Earth Song	World
Easy	World
Ebb Tide	World
Echo Der Berge	German
Edelweiß German	German
Edelweiß World	World
Edelweißlied	German
Ein Bisschen Frieden	German
Ein Bisschen Spass Muss Sein	German
Ein Heller Und Ein Batzen	German
Ein Jäger Aus Kurpfalz	German
Ein Schlafsack Und Eine Gitarre	German
Ein Vogel Wollte Hochzeit Machen	German
Eine Kleine Träne Weinte Sie	German
Eine Insel Aus Träumen Geboren Bora Bora	German
Eine Kleine Nachtmusik	World
Eine Mark Für Charly	German
Eine Seefahrt Die Ist Lustig	German
Eine Träne Von Ihr	German
Eine Weiße Hochzeitskutsche	German
Eine Weiße Rose	German
Einsamer Hirte	German
El Condor Pasa German	German
El Condor Pasa World	World
El Cumbanchero	World
Elisabeth	German
Elizabethan Serenade	World
Elouise	World
Elvira Madigan	World
End Of The Road	World
Entry Of The Gladiators	World
Er Gehört Zu Mir	German
Er Hat Ein Knallrotes Gummiboot	German
Erst Ein Cappuccino	German
Erst Willst Du Mich Dann Willst Du Nicht	German
Es Gibt Kein Bier Auf Hawaii	German
Es Hängt Ein Pferdehalfter	German
Es Klappert Die Mühle	German
Es War Im Böhmerwald	German

Every Breath You Take	World	Große Freiheit Nr.7	German
Every Thing I Do I Do It For You	World	Grün Grün Grün Sind Alle Meine Kleider	German
Every Time You Go Away	World	Guantanamera	World
Exactly Like You	World	Guten Abend Gute Nacht	German
Feelings	World	Hab Ich Dir Heute Schon Gesagt Daß Ich	
Fernando	World	Dich Liebe	German
Ferry Across The Mersey	World	Halleluja	World
Feuer Im Ewigen Eis	German	Hallo Frau Nachbarin	German
Fields Of Gold	World	Hallo Guten Morgen Germanland	German
Fiesta Mexicana	German	Hamburger Veermaster	German
Five Foot Two Eyes Of Blue	World	Hände Zum Himmel	German
Flashdance What A Feeing	World	Hands Up	World
Flieg Junger Adler	German	Happy Days Are Here Again	World
Fly Me To The Moon	World	Happy Together	World
Fool If You Think Its Over	World	Hast A Biserl Zeit Für Mich	German
Foot Tapper	World	Have I Told You Lately	World
For Once In My Life	World	He Aint Heavy	World
Forgotten Dreams	World	Heartbeat	World
Frauen Sind Was Wunderbares	German	Heartbreaker	World
Freut Euch Des Lebens	German	Heaven Is A Place On Earth	World
From A distance	World	Heimat Deine Sterne	German
Frühlingsstimmen	German	Heimweh Nach Der Heimat	German
Funky Town	World	Heimweh Nach Montana	German
Für Gaby Tu Ich Alles	German	Heimwehmelodie	German
Für Jedes Herz Das Einsam Ist	German	Heinzelmännchens Wachtparade	German
Für Mich Soll's Rote Rosen Regnen	German	Heißer Sand	German
Ganz In Weiß	German	Hello	World
Gefühl Ist Eine Achterbahn	German	Hello Again	German
Gefunden Auf Der Autobahn	German	Hello Dolly	World
Geh Doch	German	Hello Mary Lou German	German
Geisterreiter	German	Hello Mary Lou World	World
Georgia On My Mind	World	Help Me Make It Through The Night	World
Get Back	World	Help Yourself	World
Ghostriders In The Sky	World	Heres That Rainy Day	World
Gimmie Gimmie Gimmie	World	Hero Enreque	World
Girl Put Your Records On	World	Herzenssache	German
Glaube Mir	German	Herzilein	German
Glory Of Love	World	Herzklopfen	German
Go West	World	Herzlich Willkommen	German
Gold Und Silber	German	Herzschlag Für Herzschlag	German
Gondoletta	German	Herz-Schmerz	German
Good Golly Miss Molly	World	Hes Got The Whole In His Hand	World
Good Luck Charm	World	Hey Baby German	German
Goodbye Yellowbrick Road	World	Hey Baby World	World
Great Balls Of Fire	World	Hey Good Looking	World
Greatest Love Of All	World	Hey Jude	World
Green Green Grass Of Home	World	Hi Ho Silver Lining	World
Greensleeves	World	High Hopes	World
Griechischer Wein	German	High Noon	World

Hillbilly Rock	World	I Wont Send Roses	World
Hoch Auf Dem Gelben Wagen	German	I Write The Songs	World
Hohe Tannen	German	Ich Bau Dir Ein Schloss	German
Holzschuh Polka	German	Ich Bin Immer Da Wo Die Musik Spielt	German
Honeysuckle Rose	World	Ich Bin Verliebt In Dich	German
Honkytonk Woman	World	Ich Bin Verliebt In Die Liebe	German
Hopelessly Devoted To You	World	Ich Bleibe Immer Bei Dir	German
Horch Was Kommt Von Draußen Rein	German	Ich Denk So Gern An Billy Vaughn	German
Hot Stuff	World	Ich Hab Den Himmel Gesehn	German
Hot Toddy	World	Ich Hab Dich Zum Küsselfen Gern	German
Hotel California	World	Ich Hab Die Liebe Gesehn	German
House Of The Rising Sun	World	Ich Habe Was, Was Du Nicht Hast	German
How Can You Mend A Broken Heart	World	Ich Häfft Dich Sowieso Geküsselft	German
How Deep Is Your Love	World	Ich Kann Keine Traurigen Augen Sehn	German
How Do I Live	World	Ich Könnt Die Berge Umarmen	German
Human Nature	World	Ich Möcht' Gern Dein Herz Klopfen Hör'n	German
Hummelflug	German	Ich Tanz Mit Dir In Den - Frank Galan	German
Hungarian Dance	World	Ich Tanz Mit Dir In Den Himmel Hinein	German
I Am A Cider Drinker	World	Ich War Noch Nie Dem Himmel So Nah	German
I Believe	World	Ich War Noch Niemals In New York	German
I Believe I Can Fly	World	Ich Weiss Nicht Was Soll Es Bedeuten	German
I Can See Clearly Now	World	Ich Wünsch Euch Eine Gute Nacht	German
I Cant Stop Loving You	World	Ich Würd Es Wieder Tun	German
I Could Have Danced All Night	World	Ich Zähle Täglich Meine Sorgen	German
I Dont Know Why I Love You But I Do	World	Ich Zeig Dir Die Berge	German
I Dont Wanna Dance	World	Id Like To Teach The World To Sing	World
I Dreamed A Dream	World	If I Could Dream	World
I Get A Kick Out Of You	World	If I Could Turn Back Time	World
I Have A Dream	World	If I Had A Hammer	World
I Heard It Through The Grapevine	World	If Tomorrow Never Comes	World
I Just Called To Say I Love You	World	If You Could Read My Mind	World
I Just Cant Stop Loving You	World	If you dont know me by now	World
I Know Him So Well	World	I'll Be There	World
I Left My Heartin San Fransisco	World	I'll Go Where Your Music Takes Me	World
I Love Ro Love	World	I'll Make Love To You	World
I Love You And Dont You Forget It	World	I'll Never Fall In Love Again	World
I Love Your Smile	World	Im Frühtau Zu Berge	German
I Miss You Like Crazy	World	Im Heißen Sand Von Rhodos	German
I Only Wanna Be With You	World	I'm In The Mood For Love	World
I Shot The Sheriff	World	Im Krug Zum Grünen Kranze	German
I Swear	World	Im Schönsten Wiesengrunde	German
I Wanna Hold Your Hand	World	I'm So Excited	World
I Wanna Know What Love Is	World	Imagine	World
I Want To Break Free	World	Immer Wieder Sehnsucht	German
I Want You To Want Me	World	In A Spanish Town	World
I Will Always Love You	World	In Den Schönen Tiroler Bergen	German
I Will Survive	World	In Einem Kühlen Grunde	German
I Wish	World	In Einem Polenstädtchen	German
I Wont Last A Day Without You	World	In The Air Tonight	World

In The Ghetto	World
In The Hall Of The Mountain King	World
In The Mood	World
In The Navy	World
Islands In The Stream	World
Isn't She Lovely	World
Ist Das Ein Sauladen Hier	German
It Don't Mean A Thing If It Ain't	World
It Never Rains In Southern California	World
It's A Heartache	World
It's A Long Way To Tipperary	World
It's A Sin	World
It's A Small World	World
It's My Party	World
It's Not Unusual	World
It's Now Or Never	World
I've Got A Lovely Bunch Of Coconuts	World
Jailhouse Rock	World
Jambalayo	World
Java	World
Je, taime Heißt Ich Liebe Dich	German
Jeder Braucht Ein Bisschen Glück	German
Jedes Abendrot Ist Ein Gebet	German
Jetzt Geht Die Party Richtig Los	German
Jetzt Geht Die Party Tichtig Los - De Randfichten	German
Jetzt Kommen Die Lustigen Tage	German
Jetzt Oder Nie	German
Jive Connie	German
Johnny B. Good	World
Julie	German
Jump	World
Junge Bergfee	German
Junge Komm Bald Wieder	German
Just The Way You Are	World
Kaiserwalzer	German
Karamba Caracho Ein Whisky	German
Karawane-Medley	German
Kärntner Liedermarsch	German
Ketchup Song	German
Killing Me Softly	World
King Of The Road	World
Kingston Town	World
Kleine Möwe Flieg Nach Helgoland	German
Knees Up Mother Brown	World
Knock Knocking On Heavens Door	World
Knock On Wood	World
Komm Auf Das Schiff Meiner Träume	German
Komm Auf Ein Bier Zu Mir	German

Komm Nach Tirol Senorita	German
Kriminal-Tango	German
Kufsteinlied	German
Kumbaya	World
Küss Mich	German
Küssen Wie Gott In Tirol	German
L O V E	World
La Bamba	World
La Bambola	German
La Bella Bella Musica	German
La Cucaracha	World
La Cumparsita	World
La Isla Bonita	World
La Mondonara	German
La Paloma	German
La Paloma (beguine)	German
La Provence	German
Ladies Night	World
Lady Be Good	World
Lady In Red	World
Lady Madonna	World
Lady Sunshine Und Mr. Moon	German
Lately	World
Laughter In The Rain	World
Lay All Your Love On me	World
Lay Down Sally	World
Leader Of The Pack	World
Let It Be	World
Let It Be Me	World
Let Your Love Flow	World
Let's Face The Music And Dance	World
Let's Stick Together	World
Let's Twist Again	World
Licence To Kill	World
Lieb Mich Noch Mal	German
Liebe Darf Alles	German
Liebeskummer Lohnt Sich Nicht	German
Life Is Life	World
Light My Fire	World
Little Brown Jug	World
Living La Vida Loca	World
Living Next Door To Alice	World
Living On A Prayer	World
Lonely Is A Man Without Love	World
Long Train Running	World
Love Changes Everything	World
Love Hurts	World
Love Is Here To Stay	World
Love Is In The Air	World

Love Letters	World	Mona	German
Love Letters In The Sand	World	Monday Monday	World
Love Me Do	World	Money Money Money	World
Love Me For A Reason	World	Monja	German
Love Me Tender	World	Monte D,amour	German
Love Story	World	Moon River	World
Love Theme From Godfather	World	Moonlight	German
Loveboat Theme	World	Moontlight Shadow	World
Lullaby Of Birdland	World	More	World
Lustig Ist Das Zigeunerleben	German	More More More	World
Mack The Knife	World	Morgen Früh Bin Ich Bei Dir	German
Maggie May	World	Morgens Um Sieben	German
Mama Mia	World	Morning Has Broken	World
Mamy Blue	World	Morning In Cornwall	World
Man Müsste Nochmal Zwanzig Sein	German	Mornings At 7	World
Manchmal Möchte Ich Schon Mit Dir	German	Moskau	German
Mandy	World	Moskow Moscow	World
Märchenaugen	German	Most Beautiful Girl In The World	World
Maria	World	Mr. Sandman	World
Maria Wlana	World	Mr. Tambourine Man	World
Mariandl	German	Mrs. Robinson	World
Marina	German	Mull Of Kintyre	World
Märkische Heide	German	Muppets Show	World
Marmor Stein Und Eisen Bricht	German	Music Box Dancer	World
Mary's Boy Child	World	Music Of The Night	World
Massachusetts	World	Music To Watch Girls By	World
Me And My Shaddow	World	Muss I Denn Zum Städtele Hinaus	German
Meditation	World	Mustang Sally	World
Mein Hut Der Hat Drei Ecken	German	My Bonnie Lies Over The Ocean	World
Mein Schatz, Ich Hab' Dich Heut Noch Lieb	German	My Boy Lollipop	World
Mein Vater War Ein Wandermann	German	My Cherie Amour	World
Meine Lieder Streicheln Dich	German	My Girl	World
Melody In F	World	My Old Man Dont Dilly Dally	World
Memory	World	My Way	World
Memory Melodie	German	Never Can Say Goodbye	World
Mendocino	German	Never On A Sunday	World
Mexican Hat Dance	World	New York New York	World
Mi Corazon	German	Nights In White Satin	World
Michael Row The Boat Ashore	World	No Matter What	World
Michaela	German	No Woman No Cry	World
Midnight In Moscow	World	Nobody Does It Better	World
Midnight Lady	German	Nothings Gonna Change My Love	World
Mississippi	World	O Mein Papa	German
Misty	World	O Solo Mio German	German
Mit 17 Hat Man Noch Träume	German	O solo Mio World	World
Mit 66 Jahren	German	Obladi Oblada	World
Mit Den Augen Gefunden	German	Ode To Joy	World
Mitternachtsblues	German	Oh Carol	World
		Oh Suzanna	World

Old Man River	World	Schiwago Melodie	German
On The Road Again	World	Sealed With A Kiss	World
On The Street Where You Live	World	Seasons In The Sun	World
On The Sunny Side Of The Street	World	See You Later Alligator	World
On Top Of Old Smokie	World	Seemann Lass Das Träumen	German
One	World	September	World
One Day I'll Fly Away	World	Serenade Der Liebe	German
Paper Moon	World	She	World
Parfidia	World	She Loves You	World
Patricia	World	Shoop Shoop Song	World
Peggy Sue	World	Sieben Fässer Wein	German
Penny Lane	World	Signed Sealed Delivered	World
Pensylvania 6500	World	Silence Is Golden	World
Peppermint Twist	German	Singing In The Rain	World
Petite Fleur	World	Singing The Blues	World
Piano Man	World	Sitting On The Dock Of The Bay	World
Picking Up The Pieces	World	Sloop John B.	World
Popcorn	World	Smoke Gets In Your Eyes	World
Pretty Woman	World	So Ein Tag So Wunderschön Wie Heute	German
Puppet On A String	World	So Whats New	World
Quando Quando	World	Some Broken Hearts Never Mend	World
Raindrops Keep Falling On My Head	World	Something	World
Rasputin	World	Something Stupid	World
Red River Rock German	World	Somewhere My Love	World
Red River Rock World	World	Somewhere Out There	World
Red Roses For A Blue Lady	World	Sommernacht In Rom	German
Red Roses For A Blue Lady	World	Song For Guy	World
Redetzky March	World	Sorry Seems To Be The Hardest Word	World
Reet Petite	World	Spanish Eyes	World
Release Me	World	Spirit In The Sky	World
Return To Sender	World	Stand By Me	World
Rhinestone Cowboy	World	Stand By Your Man	World
Ring Of Fire	World	Stop In The Name Of Love	World
Rivers Of Babylon	World	Stranger In Paradise	World
Rock Around The Clock	World	Strangers In The Night	World
Rocking All Over The World	World	Streets Of London	World
Romeo And Juliet Theme	World	String Of Pearls	World
Rosamunda	World	Sugar Baby Love	World
Rose Garden	World	Summer Holiday	World
Route 66	World	Summer Of 69	World
Runaway	World	Summertime	World
Sabre Dance	World	Sunny	World
Sailing	World	Supercalifagilisticexpialidocious	World
Samba De Janeiro	World	Sway	World
Santa Maria	German	Sweet Georgia Brown	World
Satin Doll	World	Sweet Home Chicago	World
Save All Your Kisses For Me	World	S'wonderfull	World
Save The Last Dance For Ne	World	Symphony No. 40	World
Save Your Love	World	Take Me Home Country Roads	World

Take The A Train	World
Tanze Mit Mir In Den Morgen	German
Tausend Rote Rosen	German
Tea For Two	World
Tears In Heaven	World
Tears On My Pillow	World
Teddybear	World
Tennessee Waltz	World
Tequila	World
That'll Be The Day	World
The Bare Necesities	World
The Breeze And I	World
The Cat	World
The End Of The World	World
The Final Countdown	World
The Girl From Ipanema	World
The Great Escape	World
The Great Pretender	World
The Lady Is A Tramp	World
The Last Waltz	World
The Locomotion	World
The Lonely Sheppard	World
The Magnificent Seven	World
The Nearness Of You	World
The Power Of Love	World
The Shaddow Of Your Smile	World
The Sound Of Silence	World
The Sun Ain't Gonna Shine Anymore	World
The Tide Is High	World
The Typewriter Song	World
The Waltons	World
The Wanderer	World
The Way We Were	World
The Way You Look Tonight	World
The Wind Beneath My Wings	World
The Wonder Of You	World
The Young Ones	World
Theme From A Summers Place	World
Theme From Thornbirds	World
Theres A Kind Of A Hush	World
Thers No Business Like Showbusiness	World
These Boots Were Made For Walking	World
They Can't Take That Away From Me	World
This Guys In Love With You	World
This Masquerade	World
This Old House	World
Those Magnificent Men In Their Flying Mac	World
Three Times A Lady	World
Thunder And Lightening Polka	World
Tico Tico	World
Tie A Yellow Ribon	World
Tiger Feet	World
Tijuana Taxi	World
Till	World
Till There Was You	World
Tiptoe Through The Tulips	World
Titanium	World
To All The Airs I've Loved Before	World
To love somebody	World
Tonight	World
Too Much Heaven	World
Top Of The World	World
Toreador Song	World
Torn	World
Total Eclipse Of The Heart	World
Tragedy	World
Tritsch Tratsch Polka	German
Trolly Song	World
Trompetenträume	German
True Colours	World
True Love	World
Trumpet Voluntary	World
Turkey In The Straw	World
Tutti Fruity	World
Tuxedo Junction	World
Twentyfour Hours From Tulsa	World
Twist And Shout	World
Two Out Of Three Ain't Bad	World
Una Paloma Blanca	World
Unchained Melody	World
Unforgettable	World
Up Up And Away	World
Up Where We Belong	World
Uptown Girl	World
Venus	World
Verde - Ricky King	German
Video Killed The Radio Star	World
Vincent	World
Viva Espania	World
Volare	World
Walk Of Life	World
Walk On By	World
Waltz Of The Flowers	World
Waltzing Matilda	World
Wandering Star	World
Waterloo	World
Watermelon Man	World

Wave	World
We Are Family	World
We Are Going To Ibiza	World
We Are The Champions	World
We Are The World	World
We Have All The Time In The World	World
We Will Rock You	World
Welcome Home	World
Welcome To My World	World
We've Only Just Begun	World
What A Difference A Day Makes	World
What A Wonderful World	World
What Now My Love	World
What The World Needs Now	World

Whatever You Want	World
When A Man Loves A Woman	World
William Tell Overture	World
With A Little Help From My Friends	World
Without You	World
Woman	World
Woman In Love	World
Wonderful Land	World
Wonderwall	World
Yesterday	World
YouAre My Sunshine	World
You're My Heart You're My Soul	German
Zip A Dee Doo Dah	World
Zirkus Renz	German

4 Total Presets

No.	Bank Name	Display Name	Description
1	Drawbar Organs	Live Drawbars Standard	Drawbar sound with rotor slow / fast, adjustable via the drawbars
2		Preset Drawbars Full	Preset with full drawbar sound in the upper manual; lower manual standard drawbar preset.
3		Preset Drawbars Straight	Preset with a straight drawbar sound in the upper manual; lowe manual standard drawbar preset.
4		Preset Drawbars Open	Open drawbar sound in the upper manual; lower manual standard drawbar preset.
5		Preset Drawbars Blues	Bluesy drawbar sound in the upper manual; lower manual standard drawbar preset.
6		Preset Drawbars Blues Perc	Bluesy drawbar sound with percussion in the upper manual; lower manual standard drawbar preset.
7		Preset CD Drawbars 1	Preset sound of the legendary CD organ, vibrato effect via modulation wheel; lowe manual CD organ standard drawbar preset
8		Preset CD Drawbars 2	Preset sound of the legendary CD organ, vibrato effect via modulation wheel; lower manual CD organ standard drawbar preset
9		Church Organ	Great mix of different registers of a church organ, lower manual with tutti register
10		Theatre Organ	Typical sound of a theater organ on both manuals
11	Pianos	Grand Piano	Steinway grand piano on both manuals, strings can be activated
12		Bright Piano	Bright pianos on both manuals, strings switchable
13		Octave Piano	Octave Piano on the upper manual; lower-manual strings
14		Piano & Stings	Steinway grand piano with strings on both manuals
15		LA Piano	Modern piano mix; lower manual electric piano
16		Electric Piano CP80	Electronics Grand Piano in the upper manual; Electric lower manual Grand and strings
17		Electric Piano	Electric piano on the upper manual; lower manual strings
18		Electrik Piano Wurlitzer	Wurlitzer electric piano in the upper and lower manual
19		FM Electro Piano	FM piano in the upper and lower manual
20		Cembalo	Harpsichord in upper and lower manual with switchable strings
21	Strings	String Orchestra	Large string orchestra in the upper manual; lower manual strings
22		Tremolo Strings	Tremolo strings in the upper manual; lower manual strings
23		Solo Violin & Strings	Solo violin with strings in the upper mnanual; lower manual strings
24		Organ Strings	Soft organ strings in the upper and lower manual
25		Mantovani Strings	Mantovani strings in the upper manual; lower manual strings
26		Chamber Orchestra	Small chamber orchestra in the upper and lower manual
27		Chamber Orchestra Solo	Chamber orchestra with solo violin in the upper manual; lower manual strings

28		Oboe & String Orchestra	Solo oboe with string orchestra in the upper manual; lower manual strings
29		Sonic Orchestra Brass	Tutti orchestra with winds on upper and lower manual; special timpani effects in the lower manual
30		Sonic Orchestra	Tutti orchestra on upper and lower manual; special timpani effects in the lower lower manual
31	Guitars	Acoustic Guitar	Beautiful acoustic guitar; lower manual strings.
32		Spanish Guitar	Classical Spanish guitar; lower manual strings.
33		E-Guitar 1	Electric guitar mix; lower manual strings.
34		E-Guitar 2	Electric guitar mix; lower manual strings.
35		Distortion Guitar	Distorted guitar; lower manual strings.
36		Muted Guitar	Muted guitar; lower manual strings.
37		Pedal Steel Guitar	Soft Pedal Steel Guitar; lower manual strings.
38		12 String Guitar	12 string guitar; lower manual strings.
39		Entertainer Guitar	Soft guitar with entertainer SyntheSounds; lower manual strings.
40		Synthe & Guitar Mix	Distorted guitar with a lot of synthesis; lower manual motion synthe.
41	Wind Instruments	Trumpet	Trumpet in the upper manual, trumpet hell and trumpet ensemble switchable; lower manual strings.
42		Trombone	Trombone in the upper manual, trombone hell and ensemble brass can be activated; lower manual strings.
43		Alt Saxophon	Alto saxophone in upper manual, ensemble brass and trumpet ensemble can be activated; lower manual string
44		Tenor Saxophon	Switchable tenor saxophone in upper manual, tenor sax sweet and big band ensemble; lower manual strings.
45		Clarinet	Clarinet swing in the upper manual, clarinet and big band ensemble can be activated; lower manual strings.
46		Flute	Flute in the upper manual, piccolo flute and vibraphone can be activated; lower manual strings.
47		Pan Flute	Pan flute in the upper manual, pan flute soft and CD Galaxy switchable; lower manual strings.
48		Shakuhachi & Synthe	Shakuhachi Synthe Mix; lower manual strings.
49		Big Band Mix Soft	Big band ensemble, trombone ensemble and clarinet swing in the upper manual; lower manual strings.
50		Big Band Mix Bright	Big band ensemble, trumpet ensemble and alto saxophone in the upper manual; lower manual strings.
51	Synthe	Synthe Lead 1	Cool SquareLead with echo; lower manual strings and warm horns
52		Synthe Lead 2	Resonance lead; lower manual strings and warm horns
53		Synthe Pad	Synthe Pad Mix, resonance via aftertouch; lower manual Mega Pad Sound
54		Synthe Analog 1	Analog Synthe Brass; lower manual strings and warm horns
55		Synthe Analog 2	Analog mix with bells; lower manual strings and warm horns

56	Accordion	Synthe Trance	Cool trance sound mix; lower manual Mega Pad Sound
57		Synthe Rhythm	Automatic drum rhythm as soon as a key is played in the upper manual. Play legato; lower manual Mega Sound Pad
58		Synthe Motion	Large motion synth sound in the upper and lower manual
59		Arpeggio 1	SyntheBrass Arpeggio, tempo like current style; lower manual strings and warm horns
60		Arpeggio 2	Soft arpeggio, tempo like current style; lower manual strings and warm horns
61		Live Accordion Supita	World champion Supita with live operation of the registers and the typical switching noises; lower manual strings.
62		Live Accordion Morino	Hohner Morino with live operation of the registers and the typical switching noises; lower manual strings.
63		Live Accordion Alpina	Alpina accordion with live operation of the registers and the typical switching noises; lower manual strings.
64		Live Accordion Musette	Cavagnolo Musette button accordion with live operation of the registers and the typical switching noises in three casotto levels; lower manual strings.
65		Live Accordion Mengascini	Hohner Morino with live operation of the registers and the typical switching noises; lower manual strings.
66		Accordion Diatonisch	Alpine diatonic accordion as preset sound; lower manual strings.
67		Accordion Alpen Mix	Mix of diatonic accordion, trumpet and clarinet; lower manual strings.
68		Accordion Tango	Argentine Bandoneon; Ideal for tangos; lower manual strings.
69		Accordion Kermis	Typical fairground accordion with synthesis sounds; lower manual strings.
70		Mundharmonika Blues	Blues harmonica; lower manual strings.
71	Chor & Vocals	Jazz Vocals Duh Bap	Typical Duh Bap sound that is switched between Duh and Bap via the dynamics; lower manual strings.
72		Jazz Vocals Duh	Mix of Duh vocals; lower manual strings.
73		Jazz Vocals Yeah	Single female JazzVocal voice with Yeah in the upper range; lower manual strings.
74		Synthe Choir	Combination of different Synthe vocals; lower manual strings.
75		Large Choir	Large choir consisting of women, men and children; lower manual strings.
76		Choir - Oper Dynamik	Large choir, can be expanded with stronger operas with an opera choir; lower manual strings.
77		Women & Choir	Solo female voice with choir in the background; lower manual strings.
78		Women Choir & Oper	Large women's choir, can be expanded with stronger dynamics with an opera choir; lower manual strings.
79		Church Organ & Choir 1	Upper manual church choir; Sacral organ in the lower manual
80		Church Organ & Choir 2	Church choir and principal in the upper manual; Tutti sacred organ with choir in the lower manual

81	Mallet & Bells	Vibraphon	The classic vibraphone is often played in swing, clay bars here made of metal; lower manual strings.
82		Marimba	The marimba has a large tonal range and wooden sticks; lower manual strings.
83		Xylophon	The xylophone has wooden sticks; lower manual strings.
84		Steeldrums	The typical instrument of the Caribbean, real name Steel Pan; lower manual strings.
85		Ring Of Bells	Nice sound of a carillon; lower manual strings.
86		Tubular Bells	Pompous tubular bells struck with a hammer; lower manual strings.
87		Celesta	Nice classic celesta with soft timbre; lower manual strings.
88		Melodie Bells	Combination of small tubular bells; lower manual strings.
89		Entertainer Bells	Combination of different bells to create the typical hit bells; lower manual strings.
90		Synthe Bells	Combination of different Synthe Bell; lower manual strings.
91	Drums & Effects	Standard Drums - Set Lower	Standard drum set on the lower manual and drum effects on the upper manual.
92		Power Drums - Set Lower	Powerful power drum set on the lower manual and drum effects on the upper manual.
93		Dance Drums - Set Lower	Cool dance drum set on the lower manual and drum effects on the upper manual.
94		Analog Drums - Set Lower	Analog drum set on the lower manual and drum effects on the upper manual.
95		Funk Loop - Set Lower	Funk drum loop on the upper manual and a dance drum set on the lower manual.
96		Special Effects	Different car sounds on the upper manual and wind, sea noise, helicopter on the lower manual; please play monophony.
97		Voice Effects	Voice-Effekte auf dem Obermanual und großer Applause und Lachen auf dem Untermanual.
98		Percussion - Set Lower	Percussion drum set on the lower manual and drum effects on the upper manual.
99		Synthe Effect 1	Cool chaos synthesis effect on both manuals.
100		Synthe Effect 2	Mystical synthesis effects on both manuals.
101	Entertainer 1	DB Beta Vintage	From OAS FL-Package
102		DB CD Organ Vintage	
103		Organ Strings	
104		Symphonic Strings	
105		Timpani & Orchestra	
106		Synthe Pad 1	
107		Synthe Pad 2	
108		Synthebrass Vintage	
109		Jazz Guitar	
110		Trumpets	
111	Entertainer 2	Jazz Organ Vintage	From OAS FL-Package

112		CD Organ Tutti Vintage	
113		CD Percussion Vintage	
114		Viennese Waltz	
115		Let's Big Band	
116		Lovely Dream	
117		Synthe Dream	
118		Saxophon	
119		Acoustic Guitar	
120		Accordion	
121	MS Demo	MS Steinway Grand	Demo-Preset MusicStore
122		MS Orchestra with Timpani	
123		MS Alt Saxophon	
124		MS Pan Flute Horea	
125		MS Brass with Shake	
126		MS Live Accordion Morino	
127		MS Synthe Lead	
128		MS Synthe Pad	
129		MS Synthe Analog	
130		MS Arpeggio Synthe	
131	Sheet Music	Verde Verse Sheet	Demo preset for sheets on the display
132		Verde Refrain Sheet	
133		Es gibt kein Bier Refrain Sheet	
134		Es gibt kein Bier Verse Sheet	
135		Tanze mit mir Refrain Sheet	
136		Tanze mit mir Verse Sheet	
137		Youre My Heart Intro Sheet	
138		Youre My Heart Verse Sheet	
139		Youre My Heart Refrain Sheet	
140		Youre My Heart Bridge Sheet	
141	JL-Presets 1	Happy Musik JL	From OAS JL-Package
142		Hansi rockt JL	
143		Doo Wah Diddy JL	
144		Hey Baby JL	
145		Hip Hop Polka 1 JL	
146		Hip Hop Polka 2 JL	
147		Mamma Mia JL	
148		Einsamer Hirte JL	

149		Strings Episch JL	
150		Morricone Vocal JL	
151	JL-Presets 2	Happy Hansi JL	From OAS JL-Package
152		Dance Chor JL	
153		Pulstar 1 JL	
154		Pulstar 2 JL	
155		Mary meets Hansi JL	
156		Biscaya Organ JL	
117		Hammond A Go Go JL	
158		Happy Luxemburg JL	
159		Romantik Trumpets JL	
160		Strings Symphonisch JL	
161	JL-Presets3	Trumpets 1 JL	From OAS JL-Package
162		Trombones JL	
163		Strings Attack JL	
164		Strings 70er JL	
165		Strings 2011 JL	
166		Vocal klassisch JL	
167		Trumpets 2 JL	
168		Brass Full JL	
169		Pokerface 1 JL	
170		Pokerface 2 JL	
171	JL-Presets 4	Happy Music Keyboard JL	From OAS JL-Package
172		Hip Hop Polka Intro JL	
173		Einsamer Hirte Keyboard JL	
174		Morgens um 7 JL	
175		Games That Lovers Play JL	
176		Biscaya Keyboard JL	
177		Summerplace JL	
178		Doo Wah Diddy Keyboard JL	
179		Hey Baby Keyboard JL	
180		Over The Rainbow JL	
181	Style-Sequences	Verde	Demo Sequence with sheets
182		Your My Heart	
183		Ich bin verliebt in die Liebe	

184		Red Roses For A Blue Lady	
185		Rote Lippen soll man küssen	
186		Tanze mit mir in den Morgen	
191	Lowrey 1 Extension package	Lowrey Theater Organ Mix 1	Demo Total Preset from the Lowrey Organ extension package
192		Lowrey Theater Organ Mix 2	
193		Lowrey Theater Organ Mix 3	
194		Lowrey Theater Organ Mix Smooth	
195		Lowrey Theater Organ Mix Trem	
196		Lowrey Theater Big Brass	
197		Lowrey Theater Combi Big	
198		Lowrey Theater Combi Strings	
199		Lowrey Theater Horn Brass	
200		Lowrey Theater Organ Dias	
201	Lowrey 2 Extension package	Lowrey Rotor Full	Demo Total Preset from the Lowrey Organ extension package
202		Lowrey Rotor Perc	
203		Lowrey Rotor 16-1 Smooth	
204		Lowrey Rotor 16-1 Strings	
205		Lowrey Rotor Sustain Mix	
206		Lowrey Rotor Sustain	
207		Lowrey Mix Celeste Perc	
208		Lowrey Mix Chorus	
209		Lowrey Perc Chorus	
210		Lowrey Full Chorus	
211	Lowrey 3 Extension package	Lowrey Big Sound Mix	Demo Total Preset from the Lowrey Organ extension package
212		Lowrey Big String Sound Mix	
213		Lowrey Full Celeste Trumpet	
214		Lowrey Mix Celeste Bell	
215		Lowrey 16-1 Chorus Strings	
216		Lowrey 16-4 Chorus Bell	

217		Lowrey String Vocal Mix	
218		Lowrey Mix Celeste Brass	
219		Lowrey Rotor Mix Sax	
220		Lowrey Mix Celeste Brass WersiChord	
221	Lowrey 4 Extension package	LW Organ Standard Celeste	Demo Total Preset from the Lowrey Organ extension package
222		LW Organ Standard Rotor	
223		LW Organ Jazz Rotor	
224		LW Organ Tibia Chorus	
225		LW Organ Diapason Celeste	
226		LW Organ String Celeste	
231	Wersi Chord Band 1 Extension package	WC Brass smooth	Demo Total Preset from the WERSI Chord Band extension package
232		WC Swinging Brass	
233		WC Chamber Brass	
234		WC Disco Brass	
235		WC Saxophon	
236		WC Saxophon Smooth	
237		WC Swinging Flute	
238		WC Pop Brass	
239		WC Brass Quartett	
240		WC VB3 with Brass Band (Dynamic)	
241	Wersi Chord Band 2 Extension package	WC CD-Schlager	Demo Total Preset from the WERSI Chord Band extension package
242		WC Schlager Modern	
243		WC Mandolin Orchestra	
244		WC E-Piano Synthe	
245		WC Guitar Rockn Roll	
246		WC E-Guitar Slow	
247		WC Country Guitar	

248		WC Country Pedalsteel	
249		WC Jazz Guitar	
250		WC Acoustic Guitar	
251	Wersi Chord Band 3 Extension package	WC Alps Trio	Demo Total Preset from the WERSI Chord Band extension package
252		WC Alps Duet	
253		WC Alps Mix	
254		WC Zither	
255		WC Musette	
256		WC Jazz Vocals	
257		WC Theater Werks	
258		WC Church	
259		WC Wersi Percussion	
260		WC HELIOS Chords	
261	Wersi Chord Band 4 Extension package	WC Streicher	Demo Total Preset from the WERSI Chord Band extension package
262		WC Orchestra	
263		WC Hymne with Drums	
264		WC Chamber Orchestra	
265		WC Film Music Strings	
266		WC Film Music Mix	
267		WC Country Fiddle	
268		WC Panflute Ensemble	
269		WC Synthe	
270		WC Synthe Popcorn	
311	WERSI Vision Presets	WV Start with lower manual	Demo Total Preset from the WERSI Vision extension package
312		WV Start with style	
313		WV Link to variation	
314		WV Show mini display	
315		WV Piano Arpeggios	
316		WV Piano Klassik	

317		WV Pop Guitars	
318		WV Folk Guitars	
319		WV Schlager Move 1	
320		WV Schlager Move 2	
321	WERSI Vision Presets	WV Slow Latin 1	Demo Total Preset from the WERSI Vision extension package
322		WV Slow Latin 2	
323		WV Swing 1	
324		WV Swing 2	
325		WV Samba 1	
326		WV Samba 2	
327		WV Synthe 1	
328		WV Synthe 2	
329		WV Boogie Woogie 1	
330		WV Boogie Woogie 2	
691	Sound-Presets 1	Total Preset Leer	Sound Demos
692		Naturgitarre	
693		Naturgitarre Slide	
694		Naturgitarre & Streicher	
695		12 String Gitarre	
696		E. Gitarre 1	
697		E. Gitarre 2	
698		E. Gitarre 3	
699		Distortion Gitarre 1	
700		Distortion Gitarre 2	
701	Sound-Presets 2	Rock Piano	Sound Demos
702		Piano	
703		Piano & Strings 1	
704		Piano & Strings 2	
705		E.Piano 1	
706		E.Piano 2	
707		EP Wurlitzer	
708		DX Epiano	
709		Clavinet	
710		Harpsichord	
711	Sound-Presets 3	CP 80	Sound Demos
712		Piano DreamPad	
713		Piano & Pad	
714		Piano & Pad 1	
715		Piano & MotionPad 1	
716		Piano & MotionPad 2	

717		LA Piano	
718		Oktave Piano	
719		Vibraphon	
720		Marimba	
721	Sound-Presets 4	Strings	Sound Demos
722		Legato Strings	
723		Oxygene	
724		Whiter Shade Of Pale	
725		Hauptwerk	
731	Silbermann	Silbermann View 1	Sound Demos
732		Silbermann View 2	
733		Silbermann Mixture	
734		Silbermann weich	
735		Silbermann Chor	
736		Silbermann Agnus Dei	
737		Silbermann Bläser	
738		Silbermann Theater Organ	
739		Silbermann Koppel	
740		Silbermann Tutti	
741	Organ Live Specials	OX7 Live Display	Functional explanation Mini and Live Displays
742		OX7 Mini Display	
743		VB3 Live Display	
744		VB3 Mini Display	
745		Farfisa Live Display	
746		Farfisa Mini Display	
747		OX7 Live Display and Mini Display	
748		VB3 Mini Display Lower	
749		VB3 Mini UM Combination	
750		OX7 Special Samba Mix	

Bank SPECIALS A + B: Total presets for demo events.

5 List Factory sheets

ID	Title
0	Verde -Ricky King
1	Apache - Shadows
200	Shake Hands Drafi Deutscher
201	Yakety Sax
202	Peppermint Rock
401	You're my heart you're my soul
601	Kufsteinlied
602	Eine Seefahrt die ist lustig
603	Wo die Nordseewellen...
604	Hamburger Veermaster
605	My Bonnie is over the ocean
606	Alle Vögel sind schon da
607	Amboss Polka
608	Wochenend und Sonnenschein
609	Schwarzbraun ist die Haselnuss
610	Blau blüht der Enzian
611	Tanzende Finger
612	Akkordeon Polka
651	Oh Du Fröhliche
652	Stille Nacht
801	Begin the Beguine
802	Red Roses for a blue lady
1001	Sierra Madre
1002	Servus Pfüt Gott und ...
1003	Die kloane Tür zum Paradies
1004	Ganz in Weiß
1005	Rote Lippen soll man küssen
1006	Es hängt ein Pferdehalfter
1007	Michaela

ID	Title
1008	Ein bißchen Spaß muss sein
1009	Tanze mit mir in den Morgen
1010	Weine nicht kleine Eva
1011	Seemann lass das Träumen
1012	Es gibt kein Bier auf Hawaii
1013	Hello Mary Lou
1014	Liebeskummer lohnt sich ...
1015	Augen zu und durch
1016	Schöne Mädchen sind zum Küssen da
1017	Sommernacht in Rom
1018	Der Junge mit der Mundharmonika
1019	Adios Amor
1020	Das schöne Mädchen von Seite 1
1021	Ich bin verliebt in die Liebe
1022	Du hast mich 1000 mal belogen
1023	Über alle 7 Meere
1024	Und morgen früh küß ich dich wach
1025	Alle Engel sind Amigos - Amigos
1026	Die kleine Kneipe
1027	Santa Maria
1028	Bora Bora
1029	Capri Fischer
1030	Il Silencio
1031	Für mich soll's rote Rosen regnen
1400	Tico-Tico
1600	Tom Dooley
1601	Flieg junger Adler

6 Wersi Chord

6.1 List WERSI Chord Types

The following Wersi Chord types are available:

Nr.	Name	Description	Complete chord	Advanced voices
1	Standard Trio	Standard Trio Chords	3	2
2	Big Band	Polyphonic addition - very 'jazz-heavy' with lots of sixth chords	4	1
3	Duet 1	2 voices with thirds or sixths below	2	3
4	Duet 2	2 voices with sixths and fifths underneath	2	3
5	Country Duet 2	2 voices with thirds, fourths and fifths above	2	3
6	Block harmonie	Up to 4-part supplement. The lowest note is always the sub-octave of the melody note.	5	-
7	4-Voices close 1	Similar effect to BLOCK, but always in four voices in the narrow position	4	1
8	4-Voices close 2	Also 4 voices in the narrow location. However, this type also adds "jazzy sixth".	4	1
9	Hymne	Typical hymn set	4	2
10	Theatre	Chord set for typical theater organ music	3	1
11	Fanfare	Typical fanfare set	3	2
12	BB-Wood	Big band set for woodwinds	5	1
13	BB-Brass	Big band set for brass	4	1
14	Original	The notes / chords played on the lower manual are reproduced as they are gripped and without changes by the harmony detection.	Depending on the sub-manual, maximum 5	
15	Solo	Only the highest note of the chord played in the upper manual is reproduced as a sound as a solo voice. Not with WERSI Chord Band	2	3
16	Country Duet 2	Second version in 2 voices with overlying thirds, fourths and fifths	2	3
17	Country Trio	Creates two additional voices in country style	3	2
18	Rock Duet	Creates another voice in rock style	2	3
19	Full Chord	Three-part chord with normal playing style.	4	1
20	4-Voices close 3	Third version 4-part in the close register.	4	1
21	4-Voices close 4	Fourth version 4-part in the close register.	4	1
22	4-Voices wide 1	First version for 4 voices in a wide register. Notes are not played close together.	4	1
23	4-Voices wide 2	Second version for 4 voices in a wide register. Notes are not played close together.	4	1
24	Octave	Plays the note one octave lower	2	3
25	"1-5"	Plays the note a fourth lower	2	3

6.2 List WERSI Chord Presets

The WERSI Chord Presets 11 to 194 can be used with the WERSI Chord Band expansion pack.

No.	Name		
1	Connect to Upper 1	83	Church Choir 3
2	Brass 1	91	Duet Accordion+Trumpet
3	Brass 2	92	Duet Trumpet + Accordion
4	Saxophone	93	Trio Accordion + Trumpet +
5	E-Guitar	94	Folk music Brass
6	Strings	95	Folk music Brass smooth
7	Accordion	96	Folk music Brass Diatonisch
8	Jazz Vocals	97	Folk music Brass Clarinet
9	Theatre Organ	100	Accordion
10	Synthesizer	101	Musette
11	BB Brass 1	102	Musette + Strings
12	BB Brass 2	105	Zither 1
13	BB Brass 3	106	Zither 2
14	BB Brass 4	111	Synthesizer 1
15	BB Brass 5	112	Synthesizer 2
16	Swinging Brass	113	Synthesizer 3
17	Swinging Brass Velocity	114	Synthesizer 4
18	BB Brass 1 Smooth	115	Synthe Lead Warm
19	BB Brass 2 Smooth	116	Synthesizer Kurz
20	BB Brass Group Small	117	Popcorn Synthe
21	BB Saxophon	118	Synthe Sustain
22	BB Saxophon 1 Smooth	131	Acoustic Guitar Duet
23	BB Saxophon 2 Smooth	132	Acoustic Guitar Trio
26	Brass + Flute 1	134	E-Guitar Rockn Roll
27	Brass + Flute 2	135	E-Guitar Warm
31	Disco Brass	136	Rock Guitar
32	Modern Brass	138	Jazz Guitar Trio
33	Flute + Brass JL	140	Jazz Guitar + Brass
36	Chamber Brass	142	Country Guitar 1
37	Brass Quartet	143	Country Guitar 1 Advanced
38	Fanfare	144	Pedalsteel Guitar 1
39	Hymne Brass	145	Pedalsteel Guitar 2
40	Hymne Brass + Drums	146	Mandolin
51	String Orchestra 1	148	Schlager Guitar WERSI
52	String Orchestra 2	151	Organ WERSI Nostalgie
55	Strings Legato	152	Helios
57	Strings Sustain	156	CD Organ
60	Chamber Orchestra 1	157	Analog Organ
61	Chamber Orchestra 2	160	Organ plus Brass
62	Chamber Orchestra 3	161	Theatre Organ + Bells
65	Strings Movie Music 1	162	Theatre Organ 1
66	Strings Movie Music 2	163	Theatre Organ2
67	Strings Movie Music Mix 1	171	Grand Piano
68	Strings Movie Music Mix 2	172	Piano Synthe
70	Country Western Violine	175	Honky Tonk
71	Jazz Choir	181	E-Piano
76	Women's Choir	186	E-Piano Synthe
77	Aah Choir	191	CD-Line Synthe
81	Church Choir 1	192	Galaxy 2. Voice
82	Church Choir 2	193	CD-Line Jazz Guitar Synthe
		194	Pan Flute

7 WERSI Vision

7.1 List of WERSI Vision presets

Nr.	Name
1	Empty Start Preset
2	Start with lower manual
3	Start with style
4	Link to variation
5	Show Mini Display
11	Pop Guitars 1
12	Pop Guitars 2
16	Folk Guitars 1
21	Schlager Move 1
22	Schlager Move 2
31	Boogie Woogie 1
32	Boogie Woogie 2
41	Samba 1
42	Samba 2
43	Slow Latin 1
44	Slow Latin 2
61	Piano Arpeggios
62	Piano Classical
70	Swing 1
71	Swing 2
81	Synthe 1
82	Synthe 2

7.2 List of WERSI Vision Pattern

Nr.	Piano		
1	Piano Easy Beat 1	106	Piano Bossa Nova 2
2	Piano Easy Beat 2	107	Piano ChaCha 1
3	Piano Easy Beat 3	108	Piano ChaCha 2
4	Piano Easy Beat 4	109	Piano Beguine 1
5	Piano Easy Beat 5	110	Piano Beguine 2
6	Piano Easy Beat 6	126	Piano Swing 1
10	Piano Pop 1	127	Piano Swing 2
11	Piano Pop Shuffle 1	128	Piano Swing 3
12	Piano Pop Shuffle 2	129	Piano Swing 4
13	Piano Pop Shuffle 3	151	Piano Stride 1
14	Piano Pop Shuffle 4	152	Piano Stride 2
21	Piano Beat Groove 1	153	Piano Stride 3
22	Piano Beat Groove 2	161	Piano Honky Tonk
23	Piano Beat Groove 3	162	Hänger Test
24	Piano Beat Groove 4	171	Piano Arpeggio 1
40	Piano Rock'n Roll 1	172	Piano Arpeggio 2
41	Piano Rock'n Roll 2	173	Piano Arpeggio 3
51	Piano Boggie 1	174	Piano Arpeggio 4
52	Piano Boggie 2	175	Piano Arpeggio 5
53	Piano Boggie 3	176	Piano Arpeggio 6
54	Piano Boggie 4	177	Piano Arpeggio 7
76	Piano Folk Ballad 1	178	Piano Arpeggio 8
77	Piano Folk Ballad 2	179	Piano Arpeggio 9
78	Piano Folk Ballad 3	180	Piano Arpeggio 10
79	Piano Folk Ballad 4	181	Piano Arpeggio 11
80	Piano Ballad 1	182	Piano Arpeggio 12
81	Piano Ballad 2	183	Piano Klassik 1
82	Piano Ballad 3	184	Piano Klassik 2
101	Piano Samba 1	185	Piano Klassik 3
102	Piano Samba 2		
103	Piano Rumba 1		
104	Piano Rumba 2		
105	Piano Bossa Nova 1		

Nr.	AC-Guitar
201	AC-Guitar Beat 1
202	AC-Guitar Beat 2
203	AC-Guitar Beat 3
204	AC-Guitar Beat 4
205	AC-Guitar Beat 5
206	AC-Guitar Beat 6
207	AC-Guitar Beat 7
217	AC-Guitar Up Beat 1
218	AC-Guitar Up Beat 2
219	AC-Guitar Up Beat 3
220	AC-Guitar Up Beat 4
221	AC-Guitar Pop 1
222	AC-Guitar Pop 2
223	AC-Guitar Pop 3
224	AC-Guitar Pop 4
225	AC-Guitar Pop 5
226	AC-Guitar Pop 6
227	AC-Guitar Pop 7
228	AC-Guitar Pop 8
229	AC-Guitar Pop 9
230	AC-Guitar Pop 10
231	AC-Guitar Pop 1
232	AC-Guitar Pop 4
233	AC-Guitar Pop 5
234	AC-Guitar Pop 8
235	AC-Guitar Folk Pop 1
236	AC-Guitar Folk Pop 2
237	AC-Guitar Folk Pop 3
238	AC-Guitar Folk Pop 4
239	AC-Guitar Folk Pop 5
240	AC-Guitar Folk Pop 6
277	AC-Guitar Folk Ballad 1
278	AC-Guitar Folk Ballad 2
279	AC-Guitar Folk Ballad 3
280	AC-Guitar Folk Ballad 4
281	AC-Guitar Folk Ballad 5

282	AC-Guitar Folk Ballad 6
283	AC-Guitar Folk Ballad 7
284	AC-Guitar Folk Ballad 8
285	AC-Guitar Country Ballad
286	AC-Guitar Ballad Picking 1
287	AC-Guitar Ballad Picking 2
288	AC-Guitar Ballad Picking 3
289	AC-Guitar Ballad Picking 4
290	AC-Guitar 6-8 Ballad 1
291	AC-Guitar 6-8 Ballad 2
292	AC-Guitar 6-8 Ballad 3
293	AC-Guitar 6-8 Ballad 4
294	AC-Guitar Songwriter 1
295	AC-Guitar Songwriter 2
296	AC-Guitar Songwriter 3
297	AC-Guitar Songwriter 4
321	AC-Guitar Rock 1
322	AC-Guitar Rock 2

Nr.	E-Guitar
401	E-Guitar Pop 1 Rhythm

401	E-Guitar Pop 1 Rhythm
-----	-----------------------

402	E-Guitar Pop 2 Rhythm	433	E-Guitar Party 5 Rhythm
403	E-Guitar Pop 3 Muted	434	E-Guitar Party 6 Rhythm
404	E-Guitar Ballad 1 Rhythm	435	E-Guitar Pop 10 Rhythm
405	E-Guitar Ballad 2 Pick	436	E-Guitar Jazz Guit 1 Rhythm
406	E-Guitar Pop 3 Pick	437	E-Guitar Jazz Guit 2 Rhythm
407	E-Guitar Pop 4 Pick	438	E-Guitar Skiffle 1 Rhythm
408	E-Guitar Pop 5 Rhythm	439	E-Guitar Skiffle 2 Rhythm
409	E-Guitar Pop 6 Rhythm	440	E-Guitar Skiffle 3 Muted
410	E-Guitar Rock 1 Rhythm	441	E-Guitar Skiffle 4 Rhythm
411	E-Guitar Rock 2 Rhythm	442	E-Guitar Skiffle 5 Rhythm
412	E-Guitar Ballad 3 Pick	443	E-Guitar Skiffle 6 Pick
413	E-Guitar Shuffle 1 Rhythm	444	E-Guitar Ballad 7 Pick
414	E-Guitar Shuffle 2 Rhythm	445	E-Guitar Ballad 8 Pick
415	E-Guitar Ballad 4 Pick 6-8	446	E-Guitar Beat 04 Rhythm
416	E-Guitar Ballad 5 Pick 6-8	447	E-Guitar Pop 02 Pick
417	E-Guitar Ballad 6 Pick 6-8	448	E-Guitar Rock 01 Rhythm
418	E-Guitar Disco 1 Rhythm	449	E-Guitar 60s Rock 04 Rhythm
419	E-Guitar Disco 2 Rhythm	450	E-Guitar Dis Rock 04 Rhythm
420	E-Guitar Disco 3 Rhythm	451	E-Guitar Funk 09 Rhythm
421	E-Guitar Disco 4 Rhythm	452	E-Guitar Ballad 01 Pick
422	E-Guitar Disco 5 Rhythm	453	E-Guitar Ballad 04 Pick
423	E-Guitar Pop 7 Muted	454	E-Guitar Slow Rock 01 Pick
424	E-Guitar Pop 8 Muted	455	E-Guitar Twist 01 Muted
425	E-Guitar Schlager 1 Rhythm	456	E-Guitar Twist 02 Rhythm
426	E-Guitar Schlager 2 Pick	457	E-Guitar Twist 03 Rhythm
427	E-Guitar Pop 8 Pick	458	E-Guitar Twist 04 Rhythm
428	E-Guitar Pop 9 Pick	459	E-Guitar Shuffle 01 Muted
429	E-Guitar Party 1 Rhythm	460	E-Guitar Rock Muted
430	E-Guitar Party 2 Rhythm	461	E-Guitar Country 02 Pick
431	E-Guitar Party 3 Rhythm	462	E-Guitar Country 02 Muted
432	E-Guitar Party 4 Rhythm		

Nr.	Strings - Harp
-----	----------------

601	Harp Arpeggio 01
-----	------------------

602	Harp Arpeggio 02
603	Harp Arpeggio 03
604	Harp Arpeggio 04
605	Harp Arpeggio 05
606	Harp Arpeggio 06
607	Harp Arpeggio 07
608	Harp Arpeggio 08
609	Harp Arpeggio 09
610	Harp Arpeggio 10
611	Harp Arpeggio 11
612	Harp Arpeggio 12
613	Harp Arpeggio 13
614	Harp Arpeggio 14

615	Harp Arpeggio 15
641	Strings Arpeggio 01
642	Strings Arpeggio 02
643	Strings Arpeggio 03
644	Strings Arpeggio 04
645	Strings Arpeggio 05
646	Strings Arpeggio 06
647	Strings Arpeggio 07
648	Strings Arpeggio 08
649	Strings Vienna Waltz 01
650	Strings Vienna Waltz 02
651	Strings Waltz 01
652	Strings Waltz 02

Nr.	Synthe
681	Schlager Rhythm 1
682	Schlager Rhythm 2
683	Schlager Rhythm 3
684	Schlager Rhythm 4
685	Schlager Rhythm 5
686	Synthe Rhythm Schlager 01
687	Synthe Rhythm Schlager 02
688	Synthe Rhythm Schlager 03
689	Synthe 6-8 Schlager 01
690	Synthe 6-8 Schlager 02
691	Synthe 6-8 Schlager 03
692	Synthe 6-8 Schlager 04
693	Synthe Arp
694	Synthe Pad 1
695	Synthe Pad 2
696	House Brass
697	House Arpeggio 1
698	House Arpeggio 2
699	House Arp One Note 1
700	House Arp One Note 2
701	House Pad
702	Strings 1
703	Strings 2
704	Strings 3
705	Strings 4
706	Dance Phaser
707	Dance Stab 1
708	Dance Stab 2
709	Synthe Dance 01
710	Synthe Dance 02
711	Synthe Dance 03
712	Synthe Dance 04

713	Phasing Rhythm 1
714	Phasing Rhythm 2
715	Phasing Rhythm 3
716	80s Rhythm Pad 1
717	80s Rhythm Pad 2
718	80s Arp 1
719	80s Arp 2
720	Humble Arp
721	Club Staps
722	Club Square
723	Dream Left+Right
724	Electro Chords
725	Electro Melody
726	Bassline
727	Bass Dance 01
728	Synthe Techno 01
729	Synthe Techno 02
730	Synthe Techno 03

Nr.	Other
801	KW Organ Straight 1
802	KW Organ Straight 2
803	KW Organ Swing 1
804	KW Organ Swing 2
805	KW Organ Slow Straight 1
806	KW Organ Slow Straight 2
807	KW Organ Slow Swing 1
808	KW Organ Slow Swing 2
1000	Empty

8 List of effect programs for reverb, chorus and echo

No.	Reverb programs
1	Reverb Off
2	Reverb Normal
3	Reverb Long
4	Reverb Short
5	Reverb Damped
6	Reverb Bright
7	Church Reverb 1
8	Church Reverb 2
9	Reverb Room
10	Reverb Concert
11	Hall ACC
12	Entertainer 1
13	Entertainer 2
14	Entertainer Acc
15	Entertainer Drums
16	Reverb Drums
17	Delay Plate AZ
18	Short Drums Plate AZ
19	Accomp Delay Plate AZ
20	Sweet Sounds 1 LW
21	Sweet Sound 2 LW
22	Auditorium LW
23	Ballroom LW

No.	Delay programs
1	Delay Off
2	Delay 1
3	Delay 2
4	Delay 3
5	Delay 4
6	Delay 5
7	Delay Tempo
8	Delay STY

No.	Chorus programs
1	Chorus Off
2	Chorus 1
3	Chorus 2
4	Chorus 3
5	Chorus Drawbars

9 List of the foot switch functions

Function	Group
Start/Stop	Accompanimets
Intro 1	Accompanimets
Intro 2	Accompanimets
Intro 3	Accompanimets
Ending 1	Accompanimets
Ending 2	Accompanimets
Ending 3	Accompanimets
Break 1	Accompanimets
Break 2	Accompanimets
Variation Up	Accompanimets
Variation Down	Accompanimets
Break 1 + Var down	Accompanimets
Break 1 + Var up	Accompanimets
Break 2 + Var down	Accompanimets
Break 2 + Var up	Accompanimets
Fill	Accompanimets
Sync. Start On/Off	Accompanimets
Tempo faster	Accompanimets
Tempo slower	Accompanimets
WERSI Vision On/Off	Accompanimets
WERSI Vision Start/Stop	Accompanimets
WERSI Vision „Start with LM“	Accompanimets
Effect 1	Effect Sounds
Effect 2	Effect Sounds
Effect 3	Effect Sounds
Effect 4	Effect Sounds
Effect 5	Effect Sounds
Effect 6	Effect Sounds
Effect 7	Effect Sounds
Effect 8	Effect Sounds
Effect 9	Effect Sounds
Effect 10	Effect Sounds
Sustain all manuals	Sounds
Sustain Upper	Sounds
Sustain Lower	Sounds
Sustain Basspedal	Sounds
WersiChord On/Off	Sounds
Glide Effekt Upper	Sounds
Glide Effect Lower	Sounds
Glide Effect Solo	Sounds
Rotor Slow/Fast	Sounds
Rotor Fast	Sounds
Rotor Slow	Sounds

Function	Group
Transpose Up	Sounds
Transpose Down	Sounds
Sustain Solo	Sounds
Next Upper	Sounds
Mikro Talk On/Off	Mixer
Preset up	Total Presets
Preset down	Total Presets
Sheetmusic page down	Total Presets
Sheetmusic page up	Total Presets
No Funktion	

10 List of functions and presets "Assign drawbars"

10.1 Possible functions

No.	Function	Group
1	Volume Manual Upper 1	Manual Volumes
2	Volume Manual Upper 2	Manual Volumes
3	Volume Manual Upper 3	Manual Volumes
4	Volume Manual Upper 4	Manual Volumes
5	Volume Manual Upper 5	Manual Volumes
6	Volume Manual Upper 6	Manual Volumes
7	Volume Manual Upper 7	Manual Volumes
8	Volume Manual Upper 8	Manual Volumes
9	Volume Manual Upper 9	Manual Volumes
10	Volume Manual Upper 10	Manual Volumes
11	Volume Manual Upper 11	Manual Volumes
12	Volume Manual Upper 12	Manual Volumes
21	Upper Volume Complete	Manual Volumes
22	Lower Volume Complete	Manual Volumes
23	Pedal Volume Complete	Manual Volumes
24	Solo Manual Volume Complete	Manual Volumes
25	Volume Wersi Chord	Manual Volumes
26	Volume Wersi Vision	Vision Volume
31	Accompaniment Master Volume	Style Volumes
32	Accompaniment Drum 1 Volume	Style Volumes
33	Accompaniment Drum 2 Volume	Style Volumes
34	Accompaniment Bass Volume	Style Volumes
35	Accompaniment Acc 1 Volume	Style Volumes
36	Accompaniment Acc 2 Volume	Style Volumes
37	Accompaniment Acc 3 Volume	Style Volumes
38	Accompaniment Acc 4 Volume	Style Volumes
39	Accompaniment Acc 5 Volume	Style Volumes
40	Accompaniment Real Audio Track Volume	Style Volumes
41	Accompaniment Acc Tracks Master Volume	Style Volumes
42	Accompaniment Drum Tracks Master Volume	Style Volumes
51	Sequencer Track 1 Volume	Sequence Volumes
52	Sequencer Track 2 Volume	Sequence Volumes
53	Sequencer Track 3 Volume	Sequence Volumes
54	Sequencer Track 4 Volume	Sequence Volumes
55	Sequencer Track 5 Volume	Sequence Volumes
56	Sequencer Track 6 Volume	Sequence Volumes
57	Sequencer Track 7 Volume	Sequence Volumes
58	Sequencer Track 8 Volume	Sequence Volumes
59	Sequencer Track 9 Volume	Sequence Volumes
60	Sequencer Track 10 Volume	Sequence Volumes
61	Sequencer Track 11 Volume	Sequence Volumes
62	Sequencer Track 12 Volume	Sequence Volumes
63	Sequencer Track 13 Volume	Sequence Volumes
64	Sequencer Track 14 Volume	Sequence Volumes
65	Sequencer Track 15 Volume	Sequence Volumes
66	Sequencer Track 16 Volume	Sequence Volumes

No.	Function	Group
71	Drawbar Upper 16"	Drawbars
72	Drawbar Upper 5 1/3 "	Drawbars
73	Drawbar Upper 8 "	Drawbars
74	Drawbar Upper 4 "	Drawbars
75	Drawbar Upper 2 2/3 "	Drawbars
76	Drawbar Upper 2 "	Drawbars
77	Drawbar Upper 1 3/5 "	Drawbars
78	Drawbar Upper 1 1/3 "	Drawbars
79	Drawbar Upper 1 "	Drawbars
80	Drawbar Lower 16"	Drawbars
81	Drawbar Lower 5 1/3 "	Drawbars
82	Drawbar Lower 8 "	Drawbars
83	Drawbar Lower 4 "	Drawbars
84	Drawbar Lower 2 2/3 "	Drawbars
85	Drawbar Lower 2 "	Drawbars
86	Drawbar Lower 1 3/5 "	Drawbars
87	Drawbar Lower 1 1/3 "	Drawbars
88	Drawbar Lower 1 "	Drawbars
111	Drawbar Pedal 16"	Drawbars
112	Drawbar Pedal 5 1/3 "	Drawbars
113	Drawbar Pedal 8 "	Drawbars
114	Drawbar Pedal 4 "	Drawbars
131	Percussion Upper 16"	Drawbars
132	Percussion Upper 5 1/3 "	Drawbars
133	Percussion Upper 8 "	Drawbars
134	Percussion Upper 4 "	Drawbars
135	Percussion Upper 2 2/3 "	Drawbars
136	Percussion Upper 2 "	Drawbars
137	Percussion Upper 1 3/5 "	Drawbars
138	Percussion Upper 1 1/3 "	Drawbars
139	Percussion Upper 1 "	Drawbars
151	Percussion Lower 16"	Drawbars
152	Percussion Lower 5 1/3 "	Drawbars
153	Percussion Lower 8 "	Drawbars
154	Percussion Lower 4 "	Drawbars
155	Percussion Lower 2 2/3 "	Drawbars
156	Percussion Lower 2 "	Drawbars
157	Percussion Lower 1 3/5 "	Drawbars
158	Percussion Lower 1 1/3 "	Drawbars
159	Percussion Lower 1 "	Drawbars
171	Percussion Pedal 16"	Drawbars
172	Percussion Pedal 5 1/3 "	Drawbars
173	Percussion Pedal 8 "	Drawbars
174	Percussion Pedal 4 "	Drawbars
201	Reverb 1 - Manuals	Send Effects
202	Reverb 2 - Manuals	Send Effects
203	Delay - Manuals	Send Effects
204	Chorus - Manuals	Send Effects
221	Reverb 1 - Accompaniment	Send Effects
222	Reverb 2 - Accompaniment	Send Effects
223	Delay - Accompaniment	Send Effects
224	Chorus - Accompaniment	Send Effects

No.	Function	Group
301	Volume Manual Lower 1	Manual Volumes
302	Volume Manual Lower 2	Manual Volumes
303	Volume Manual Lower 3	Manual Volumes
304	Volume Manual Lower 4	Manual Volumes
305	Volume Manual Lower 5	Manual Volumes
306	Volume Manual Lower 6	Manual Volumes
307	Volume Manual Lower 7	Manual Volumes
308	Volume Manual Lower 8	Manual Volumes
309	Volume Manual Lower 9	Manual Volumes
310	Volume Manual Lower 10	Manual Volumes
311	Volume Manual Lower 11	Manual Volumes
312	Volume Manual Lower 12	Manual Volumes
321	Volume Pedal 1	Manual Volumes
322	Volume Pedal 2	Manual Volumes
323	Volume Pedal 3	Manual Volumes
325	Volume Pedal 4	Manual Volumes
331	Volume Manual Solo 1	Manual Volumes
332	Volume Manual Solo 2	Manual Volumes
333	Volume Manual Solo 3	Manual Volumes
334	Volume Manual Solo 4	Manual Volumes
335	Volume Manual Solo 5	Manual Volumes
336	Volume Manual Solo 6	Manual Volumes
337	Volume Manual Solo 7	Manual Volumes
338	Volume Manual Solo 8	Manual Volumes
339	Volume Manual Solo 9	Manual Volumes
340	Volume Manual Solo 10	Manual Volumes
341	Volume Manual Solo 11	Manual Volumes
342	Volume Manual Solo 12	Manual Volumes
401	Volume Effects Microphone	Microphone Settings
402	Microphone Send-Effect 1	Microphone Settings
403	Microphone Send-Effect 2	Microphone Settings
404	Microphone EQ-Bass	Microphone Settings
405	Microphone EQ-Mid1	Microphone Settings
406	Microphone EQ-Mid2	Microphone Settings
407	Microphone EQ-Mid3	Microphone Settings
408	Microphone EQ-Treble	Microphone Settings
421	Audio-Out 1 EQ-Bass	Audio Settings
422	Audio-Out 1 EQ-Mid1	Audio Settings
423	Audio-Out 1 EQ-Mid2	Audio Settings
424	Audio-Out 1 EQ-Mid3	Audio Settings
425	Audio-Out 1 EQ-Treble	Audio Settings
426	Audio-Out 2 EQ-Bass	Audio Settings
427	Audio-Out 2 EQ-Mid1	Audio Settings
428	Audio-Out 2 EQ-Mid2	Audio Settings
429	Audio-Out 2 EQ-Mid3	Audio Settings
430	Audio-Out 2 EQ-Treble	Audio Settings

No.	Function	Group
501	Selector: Panorama	Selector Settings
502	Selector: Reverb 1	Selector Settings
503	Selector: Reverb 2	Selector Settings
504	Selector: Delay	Selector Settings
505	Selector: Chorus	Selector Settings
506	Selector: Attack	Selector Settings
507	Selector: Release	Selector Settings
508	Selektor: Soundcontrol 1	Selector Settings
509	Selektor: Soundcontrol 2	Selector Settings
510	Selektor: Soundcontrol 3	Selector Settings
511	Selektor: Soundcontrol 4	Selector Settings
512	Selektor: Soundcontrol 5	Selector Settings
513	Selektor: Soundcontrol 6	Selector Settings
1000	No function	

10.2 Factory Presets OAX1 – OAX500 – OAX600 – OAX700

Factory-Presets 1 and 2

Drawbar	CC WersiChord Volume	CC Send Effects Microphone
CC-Drawbar	Wersichord Volume	Send Effects Microphone
1 - Upper 16 "	Drawbar Upper 16 "	Drawbar Upper 16 "
2 - Upper 5 1/3 "	Drawbar Upper 5 1/3 "	Drawbar Upper 5 1/3 "
3 - Upper 8 "	Drawbar Upper 8 "	Drawbar Upper 8 "
4 - Upper 4 "	Drawbar Upper 4 "	Drawbar Upper 4 "
5 - Upper 2 2/3 "	Drawbar Upper 2 2/3 "	Drawbar Upper 2 2/3 "
6 - Upper 2 "	Drawbar Upper 2 "	Drawbar Upper 2 "
7 - Upper 1 3/5 "	Drawbar Upper 1 3/5 "	Drawbar Upper 1 3/5 "
8 - Upper 1 1/3 "	Drawbar Upper 1 1/3 "	Drawbar Upper 1 1/3 "
9 - Upper 1 "	Drawbar Upper 1 "	Drawbar Upper 1 "
10 - Lower 8 "	Drawbar Lower 8 "	Drawbar Lower 8 "
11 - Lower 4 "	Drawbar Lower 4 "	Drawbar Lower 4 "
12 - Lower 2 2/3 "	Drawbar Lower 2 2/3 "	Drawbar Lower 2 2/3 "
13 - Lower 2 "	Drawbar Lower 2 "	Drawbar Lower 2 "
14 - Lower 1 3/5 "	Drawbar Lower 1 3/5 "	Drawbar Lower 1 3/5 "
15 - Lower 1 1/3 "	Drawbar Lower 1 1/3 "	Drawbar Lower 1 1/3 "
16 - Lower 1 "	Drawbar Lower 1 "	Drawbar Lower 1 "

Factory-Presets 3 and 4

Drawbar	Sequencer Volumes	Style Volumes
CC-Drawbar	Send Effekte Mikrofon	Wersichord Volume
1 - Upper 16 "	Sequencer Volume Track 1	Style Volume Drum Track 1
2 - Upper 5 ½ "	Sequencer Volume Track 2	Style Volume Drum Track 2
3 - Upper 8 "	Sequencer Volume Track 3	Style Volume Realdrums
4 - Upper 4 "	Sequencer Volume Track 4	Style Volume Bass
5 - Upper 2 ¾ "	Sequencer Volume Track 5	Style Volume Acc 1
6 - Upper 2 "	Sequencer Volume Track 6	Style Volume Acc 2
7 - Upper 1 3/5 "	Sequencer Volume Track 7	Style Volume Acc 3
8 - Upper 1 ½ "	Sequencer Volume Track 8	Style Volume Acc 4
9 - Upper 1 "	Sequencer Volume Track 9	Style Volume Acc 5
10 - Lower 8 "	Sequencer Volume Track 10	Drawbar Lower 8 "
11 - Lower 4 "	Sequencer Volume Track 11	Drawbar Lower 4 "
12 - Lower 2 ¾ "	Sequencer Volume Track 12	Drawbar Lower 2 ¾ "
13 - Lower 2 "	Sequencer Volume Track 13	Drawbar Lower 2 "
14 - Lower 1 3/5 "	Sequencer Volume Track 14	Drawbar Lower 1 3/5 "
15 - Lower 1 ½ "	Sequencer Volume Track 15	Drawbar Lower 1 ½ "
16 - Lower 1 "	Sequencer Volume Track 16	Drawbar Lower 1 "

Factory-Presets 5 and 6

Drawbar	Perkussion Upper	Sound Edit Live
CC-Drawbar	Wersichord Volume	Wersichord Volume
1 - Upper 16 "	Drawbar Upper 16 "	Selector: Reverb 1
2 - Upper 5 ½ "	Drawbar Upper 5 ½ "	Selector: Reverb 2
3 - Upper 8 "	Drawbar Upper 8 "	Selector: Echo
4 - Upper 4 "	Drawbar Upper 4 "	Selector: Chorus
5 - Upper 2 ¾ "	Drawbar Upper 2 ¾ "	Selector: Attack
6 - Upper 2 "	Drawbar Upper 2 "	Selector: Release
7 - Upper 1 3/5 "	Drawbar Upper 1 3/5 "	no function
8 - Upper 1 ½ "	Drawbar Upper 1 ½ "	no function
9 - Upper 1 "	Drawbar Upper 1 "	no function
10 - Lower 8 "	Percussion Upper 8 "	Selector: Soundcontrol 1
11 - Lower 4 "	Percussion Upper 4 "	Selector: Soundcontrol 2
12 - Lower 2 ¾ "	Percussion Upper 2 ¾ "	Selector: Soundcontrol 3
13 - Lower 2 "	Percussion Upper 2 "	Selector: Soundcontrol 4
14 - Lower 1 3/5 "	Percussion Upper 1 3/5 "	Selector: Soundcontrol 5
15 - Lower 1 ½ "	Percussion Upper 1 ½ "	Selector: Soundcontrol 6
16 - Lower 1 "	Percussion Upper 1 "	no function

Factory-Preset 7

Drawbar	Microphone Edit Live
CC-Drawbar	Send Effects Microphone
1 - Upper 16 "	Drawbar Upper 16 "
2 - Upper 5 1/3 "	Drawbar Upper 5 1/3 "
3 - Upper 8 "	Drawbar Upper 8 "
4 - Upper 4 "	Drawbar Upper 4 "
5 - Upper 2 2/3 "	Drawbar Upper 2 2/3 "
6 - Upper 2 "	Drawbar Upper 2 "
7 - Upper 1 3/5 "	Drawbar Upper 1 3/5 "
8 - Upper 1 1/3 "	Drawbar Upper 1 1/3 "
9 - Upper 1 "	Drawbar Upper 1 "
10 - Lower 8 "	Microphone Send-Effect 1
11 - Lower 4 "	Microphone Send-Effect 2
12 - Lower 2 2/3 "	Microphone EQ-Bass
13 - Lower 2 "	Microphone EQ-Mid1
14 - Lower 1 3/5 "	Microphone EQ-Mid2
15 - Lower 1 1/3 "	Microphone EQ-Mid3
16 - Lower 1 "	Microphone EQ-Treble

10.3 Factory Presets OAX800

Factory-Presets 1 and 2

Drawbar	CC Send Effects Microphone	Sequencer Volumes
CC-Drawbar	Send Effects Microphone	Send Effekte Mikrofon
1 - Upper 16 "	Drawbar Upper 16 "	Sequencer Volume Track 1
2 - Upper 5 1/3 "	Drawbar Upper 5 1/3 "	Sequencer Volume Track 2
3 - Upper 8 "	Drawbar Upper 8 "	Sequencer Volume Track 3
4 - Upper 4 "	Drawbar Upper 4 "	Sequencer Volume Track 4
5 - Upper 2 2/3 "	Drawbar Upper 2 2/3 "	Sequencer Volume Track 5
6 - Upper 2 "	Drawbar Upper 2 "	Sequencer Volume Track 6
7 - Upper 1 3/5 "	Drawbar Upper 1 3/5 "	Sequencer Volume Track 7
8 - Upper 1 1/3 "	Drawbar Upper 1 1/3 "	Sequencer Volume Track 8
9 - Upper 1 "	Drawbar Upper 1 "	Sequencer Volume Track 9
10 - Lower 16 "	Drawbar Lower 16 "	Sequencer Volume Track 10
11 - Lower 5 1/3 "	Drawbar Lower 5 1/3 "	Sequencer Volume Track 11
12 - Lower 8 "	Drawbar Lower 8 "	Sequencer Volume Track 12
13 - Lower 4 "	Drawbar Lower 4 "	Sequencer Volume Track 13
14 - Lower 2 2/3 "	Drawbar Lower 2 2/3 "	Sequencer Volume Track 14
15 - Lower 2 "	Drawbar Lower 2 "	Sequencer Volume Track 15
16 - Lower 1 3/5 "	Drawbar Lower 1 3/5 "	Sequencer Volume Track 16
17 - Lower 1 1/3 "	Drawbar Lower 1 1/3 "	no function
18 - Lower 1 "	Drawbar Lower 1 "	no function

Factory-Presets 3 and 4

Drawbar	Style Volumes	Sound Edit Live
CC-Drawbar	Send Effects Microphone	Send Effects Microphone
1 - Upper 16	Style Volume Drum Track 1	Selector: Reverb 1
2 - Upper 5 1/3 "	Style Volume Drum Track 2	Selector: Reverb 2
3 - Upper 8 "	Style Volume Realdrums	Selector: Echo
4 - Upper 4 "	Style Volume Bass	Selector: Chorus
5 - Upper 2 2/3 "	Style Volume Acc 1	Selector: Attack
6 - Upper 2 "	Style Volume Acc 2	Selector: Release
7 - Upper 1 3/5 "	Style Volume Acc 3	no function
8 - Upper 1 1/3 "	Style Volume Acc 4	no function
9 - Upper 1 "	Style Volume Acc 5	no function
10 - Lower 16 "	Drawbar Lower 16 "	Selector: Soundcontrol 1
11 - Lower 5 1/3 "	Drawbar Lower 5 1/3 "	Selector: Soundcontrol 2
12 - Lower 8 "	Drawbar Lower 8 "	Selector: Soundcontrol 3
13 - Lower 4 "	Drawbar Lower 4 "	Selector: Soundcontrol 4
14 - Lower 2 2/3 "	Drawbar Lower 2 2/3 "	Selector: Soundcontrol 5
15 - Lower 2 "	Drawbar Lower 2 "	Selector: Soundcontrol 6
16 - Lower 1 3/5 "	Drawbar Lower 1 3/5 "	no function
17 - Lower 1 1/3 "	Drawbar Lower 1 1/3 "	no function
18 - Lower 1 "	Drawbar Lower 1 "	no function

Factory-Preset 5

Drawbar	Microphone Edit Live
CC-Drawbar	Send Effects Microphone
1 - Upper 16	Drawbar Upper 16 "
2 - Upper 5 1/3 "	Drawbar Upper 5 1/3 "
3 - Upper 8 "	Drawbar Upper 8 "
4 - Upper 4 "	Drawbar Upper 4 "
5 - Upper 2 2/3 "	Drawbar Upper 2 2/3 "
6 - Upper 2 "	Drawbar Upper 2 "
7 - Upper 1 3/5 "	Drawbar Upper 1 3/5 "
8 - Upper 1 1/3 "	Drawbar Upper 1 1/3 "
9 - Upper 1 "	Drawbar Upper 1 "
10 - Lower 16 "	Microphone Send-Effect 1
11 - Lower 5 1/3 "	Microphone Send-Effect 2
12 - Lower 8 "	Microphone EQ-Bass
13 - Lower 4 "	Microphone EQ-Mid1
14 - Lower 2 2/3 "	Microphone EQ-Mid2
15 - Lower 2 "	Microphone EQ-Mid3
16 - Lower 1 3/5 "	Microphone EQ-Treble
17 - Lower 1 1/3 "	no function
18 - Lower 1 "	no function

10.4 Factory Presets PERGAMON

Factory-Presets 1 and 2

Drawbar	CC WersiChord Volume	CC Send Effects Microphone
CC-Drawbar	Wersichord Volume	Send Effects Microphone
1 - Upper 16 "	Drawbar Upper 16 "	Drawbar Upper 16 "
2 - Upper 5 1/3 "	Drawbar Upper 5 1/3 "	Drawbar Upper 5 1/3 "
3 - Upper 8 "	Drawbar Upper 8 "	Drawbar Upper 8 "
4 - Upper 4 "	Drawbar Upper 4 "	Drawbar Upper 4 "
5 - Upper 2 2/3 "	Drawbar Upper 2 2/3 "	Drawbar Upper 2 2/3 "
6 - Upper 2 "	Drawbar Upper 2 "	Drawbar Upper 2 "
7 - Upper 1 3/5 "	Drawbar Upper 1 3/5 "	Drawbar Upper 1 3/5 "
8 - Upper 1 1/3 "	Drawbar Upper 1 1/3 "	Drawbar Upper 1 1/3 "
9 - Upper 1 "	Drawbar Upper 1 "	Drawbar Upper 1 "
10 - Lower 16 "	Drawbar Lower 16 "	Drawbar Lower 16 "
11 - Lower 5 1/3 "	Drawbar Lower 5 1/3 "	Drawbar Lower 5 1/3 "
12 - Lower 8 "	Drawbar Lower 8 "	Drawbar Lower 8 "
13 - Lower 4 "	Drawbar Lower 4 "	Drawbar Lower 4 "
14 - Lower 2 2/3 "	Drawbar Lower 2 2/3 "	Drawbar Lower 2 2/3 "
15 - Lower 2 "	Drawbar Lower 2 "	Drawbar Lower 2 "
16 - Lower 1 3/5 "	Drawbar Lower 1 3/5 "	Drawbar Lower 1 3/5 "
17 - Lower 1 1/3 "	Drawbar Lower 1 1/3 "	Drawbar Lower 1 1/3 "
18 - Lower 1 "	Drawbar Lower 1 "	Drawbar Lower 1 "

Factory-Presets 3 and 4

Drawbar	Sequencer Volumes	Style Volumes
CC-Drawbar	Wersichord Volume	Wersichord Volume
1 - Upper 16 "	Sequencer Volume Track 1	Style Volume Drum Track 1
2 - Upper 5 1/3 "	Sequencer Volume Track 2	Style Volume Drum Track 2
3 - Upper 8 "	Sequencer Volume Track 3	Style Volume Realdrums
4 - Upper 4 "	Sequencer Volume Track 4	Style Volume Bass
5 - Upper 2 2/3 "	Sequencer Volume Track 5	Style Volume Acc 1
6 - Upper 2 "	Sequencer Volume Track 6	Style Volume Acc 2
7 - Upper 1 3/5 "	Sequencer Volume Track 7	Style Volume Acc 3
8 - Upper 1 1/3 "	Sequencer Volume Track 8	Style Volume Acc 4
9 - Upper 1 "	Sequencer Volume Track 9	Style Volume Acc 5
10 - Lower 16 "	Sequencer Volume Track 10	Drawbar Lower 16 "
11 - Lower 5 1/3 "	Sequencer Volume Track 11	Drawbar Lower 5 1/3 "
12 - Lower 8 "	Sequencer Volume Track 12	Drawbar Lower 8 "
13 - Lower 4 "	Sequencer Volume Track 13	Drawbar Lower 4 "
14 - Lower 2 2/3 "	Sequencer Volume Track 14	Drawbar Lower 2 2/3 "
15 - Lower 2 "	Sequencer Volume Track 15	Drawbar Lower 2 "
16 - Lower 1 3/5 "	Sequencer Volume Track 16	Drawbar Lower 1 3/5 "
17 - Lower 1 1/3 "	no function	Drawbar Lower 1 1/3 "
18 - Lower 1 "	no function	Drawbar Lower 1 "

Factory-Presets 5 and 6

Drawbar	Sound Edit Live	Microphone Edit Live
CC-Drawbar	Wersichord Volume	Send Effects Microphone
1 - Upper 16 "	Selector: Reverb 1	Drawbar Upper 16 "
2 - Upper 5 1/3 "	Selector: Reverb 2	Drawbar Upper 5 1/3 "
3 - Upper 8 "	Selector: Echo	Drawbar Upper 8 "
4 - Upper 4 "	Selector: Chorus	Drawbar Upper 4 "
5 - Upper 2 2/3 "	Selector: Attack	Drawbar Upper 2 2/3 "
6 - Upper 2 "	Selector: Release	Drawbar Upper 2 "
7 - Upper 1 3/5 "	no function	Drawbar Upper 1 3/5 "
8 - Upper 1 1/3 "	no function	Drawbar Upper 1 1/3 "
9 - Upper 1 "	no function	Drawbar Upper 1 "
10 - Lower 16 "	Selector: Soundcontrol 1	Microphone Send-Effect 1
11 - Lower 5 1/3 "	Selector: Soundcontrol 2	Microphone Send-Effect 2
12 - Lower 8 "	Selector: Soundcontrol 3	Microphone EQ-Bass
13 - Lower 4 "	Selector: Soundcontrol 4	Microphone EQ-Mid1
14 - Lower 2 2/3 "	Selector: Soundcontrol 5	Microphone EQ-Mid2
15 - Lower 2 "	Selector: Soundcontrol 6	Microphone EQ-Mid3
16 - Lower 1 3/5 "	no function	Microphone EQ-Treble
17 - Lower 1 1/3 "	no function	no function
18 - Lower 1 "	no function	no function

11 List of effect-sounds

No.	Name
1	Empty
3	Bum-Vocal
4	Au-Vocal
5	Bullshit-Vocal
6	DiDiDip-Vocal
7	Funky-Vocal
8	Hey-Vocal
9	Huh-Vocal
10	Jackson-Vocal
11	Gloria-Vocal
12	OneTwo-Vocal
13	Yeah-Vocal
14	DonJov-Vocal
15	Bang-Vocal
16	Music [C3]
17	Andyle
18	Ole Large
19	Ole-Vocal
20	Zillertal Jodeln
21	Jodeln-Vocal
22	Jauchzen-Vocal
23	Juchhu-Vocal
65	Applause
66	Applause Small
67	Applause Yeah
68	FretNoise
69	GunShot
70	Helicopter
71	Phone
72	Beach
73	Western Train
74	Church Bells
75	Thunder 1
76	Auto horn
77	Whistle
78	The Wave
79	Amen in G
80	Prosit
81	Horse
82	Goat
83	Dogs bark
84	Bird
85	Airplane
86	Autohupe

87	Thunderbolt
88	Cow
89	Glas
90	Rocket
91	Rocket Start
92	Schubidu
93	Groan
94	Chimes Glas Fast
95	Chimes Metal Slow
96	China Gong
97	Cresc Cymbal
98	Reverse Crash 2
99	Thunder 2
100	Laser 4
101	Laser 5
102	Laser 6
103	TamTam
104	Lion
105	Rainstick
106	Synthesizedrum 1
107	Synthesizedrum 2
108	Synthesizedrum 3
109	Bell C5
110	Bell C#5
111	Bell D5
112	Bell D#5
113	Bell E5
114	Bell F5
115	Bell F#5
116	Bell G5
117	Bell G#5
118	Bell A5
119	Bell A#5
120	Bell B5
121	Bell C6
122	Airplane Piston Engine Ground
123	Airplane Piston Engine Flyby 1
124	Airplane Piston Engine Flyby 2
125	Airplane Piston Engine Flyby 3
126	Airplane Piston Engines Flyby
129	Kick + Crash 01
130	Kick + Crash 02
131	Kick + Crash 03
132	Kick + Crash 04
133	Kick + Crash 05

134	Kick + Crash 06	184	Orchestra Piatи 2
135	Kick + Crash 07	185	Orchestra Tam 1
136	Crash Cymbal 01	186	Orchestra Tam 2
137	Crash Cymbal 02	187	Windchimes 1
138	Crash Cymbal 03	188	Windchimes 2
139	Crash Cymbal 04	189	Woodblocks
140	Crash Cymbal 05	190	Castanet 1
141	Movie Hit 1	191	Castanet 2
142	Movie Hit 2	192	Castanet 3
143	Movie Hit 3	193	Fingersnap 1
144	Orchestra Kettle 1	194	Fingersnap 2
145	Orchestra Kettle 2	207	Backspin
146	Orchestra Kettle 3	208	90th Hit
147	Orchestra Kettle 4	209	Asian Bell
148	Timpani G0	210	Break Down
149	Timpani G#0	211	Drum Explosion
150	Timpani A0	212	Dumpster Hit
151	Timpani A#0	213	Echo Sounder
152	Timpani H0	214	Invasion
153	Timpani C1	215	Lift to Down 01
154	Timpani C#1	216	Lift to Down 02
155	Timpani D1	217	Lift to Down 03
156	Timpani D#1	218	Lift to Down 04
157	Timpani E1	219	Noise Up
158	Timpani F1	220	Noise Attack 01
159	Timpani F#1	221	Noise Attack 02
160	Timpani G1	222	Noise Attack 03
161	Timpani G#1	223	Parade Hit
162	Timpani A1	224	Space Signal
163	Timpani A#1	225	Sparkely
164	Timpani H1	226	Speed Up Stab
165	Timpani C2	227	Speed Up Synthe
166	Timpani C2	228	Swippy
167	Timpani C2	229	Synthe Down
168	Timpani C2	230	Synthe Stab
169	Timpani C2	231	WowWowWow
170	Timpani C2	232	ZyZyZysch
171	Timpani C2	233	Comic
172	Timpani C2	234	Going 1
174	Handclaps 1	235	Going 2
175	Handclaps 2	236	Laser 1
176	Handclaps 3	237	Laser 2
177	Sticks	238	Laser 3
179	Roll 1	239	Gag Whistle 1
180	Roll 2	240	Gag Whistle 2
181	Roll 3	241	Space
182	Roll 4	242	Trrrip
183	Orchestra Piatи 1	243	Churchbell LW

244	Gong 1 LW	285	Metronom LW
245	Gong 2 LW	286	Metronom Bell LW
246	Trolley Bell LW	287	Game Show Correct LW
247	Pop LW	288	Game Show Wrong LW
248	Boink LW	289	Telephone Modern LW
249	Footstep1 LW	290	Telephone LW
250	Footstep2 LW	291	Thunder LW
251	Typewriter LW	292	Thunder Rain LW
252	Whistle Down LW	293	Seagulls LW
253	One LW	294	Seashore Surf LW
254	Two LW	295	Rain LW
255	Three LW	296	Surf wSeals LW
256	Four LW	297	Steam LW
257	Play LW	298	Door Bell LW
258	And LW	299	Door Creaking LW
259	Ready LW	300	Door LW
260	Finger Cymbal LW	301	Car Horn LW
261	Laughing LW	302	Train LW
262	Laughter LW	303	Car-Aaooga-Claxon LW
263	Scream LW	304	Car-Pass LW
264	Kiss LW	305	Jetplane LW
265	Heart Beat LW	306	Wind LW
266	Ah LW	307	Typewriter
267	Applause LW	308	Typewriter Bell
268	Cu-Coo LW	309	Typewriter Back
269	Dog LW	310	Animal Howl
270	Horse Whinney LW	311	Animal Laugh
271	Horse LW	312	Jungle
272	Birds LW	313	Rain
273	Rooster LW	314	Thunder 3
274	Cow LW	315	Thunder 4
275	Crow LW	316	Thunder 5
276	Gun Shot LW	317	Water Rowing
277	Helicopter LW	318	Seagals
278	Lasergun LW	319	Waves
279	Machine Gun LW	320	Sonar 1
280	Explosion LW	321	Sonar 2
281	Plane LW	322	Sonar 3
282	Siren LW		
283	Starship LW		
284	Punch LW		

12 Harmony Types for Accompaniment

12.1 The following harmony types are recognized

The following harmony types are currently available for playing with automatic accompaniment:

---	Major	1+3+5
6	Major + Sixth	1+(3)+5+6
Maj7	Major seventh	1+3+(5)+7
Maj7#11	Major seventh add sharp eleventh	1+(2)+3+#4+5+7
add9	Add ninth	1+2+3+5
Maj9	Major seventh ninth	1+2+3+(5)+7
6/9	Sixth ninth	1+2+3+(5)+6
aug	Augmented	1+3+#5
m	Minor	1+b3+5
m6	Minor sixth	1+b3+5+6
m7	Minor seventh	1+b3+(5)+b7
m7b5	Minor seventh flattened fifth	1+b3+b5+b7
madd9	Minor add ninth	1+2+b3+5
m9	Minor major seventh ninth	1+2+b3+(5)+7
m11	Minor seventh eleventh	1+(2)+b3+4+5+(b7)
mMaj7	Minor major seventh	1+b3+(5)+7
mMaj9	Minor major seventh ninth	1+2+b3+(5)+7
mMaj7b5	Minor major seventh flattened fifth	1+b3+b5+7
dim	Diminished	1+b3+b5
dim7	Diminished seventh	1+b3+b5+6
7	seventh	1+3+(5)+b7
7sus4	Seventh suspended fourth	1+4+5+b7
7b5	Minor seventh flattened fifth	1+b3+b5+b7
9	Seventh ninth	1+2+3+(5)+b7
7(#11)	Seventh add sharp eleventh	1+(2)+3+#4+5+b7
7(13)	Seventh add thirteenth	1+3+(5)+6+b7
7(b9)	Seventh flattened ninth	1+b2+3+(5)+b7
7(b13)	Seventh add flattened thirteenth	1+3+5+b6+b7
7(#9)	Seventh sharp ninth	1+#2+3+(5)+b7
Maj7aug	Major seventh augmented	1+(3)+#5+7
7aug	Seventh augmented	1+3+#5+b7
1+8	Interval from prime + octave	1+8
1+5	Interval from prime + fifth	1+5
sus4	Suspended fourth	1+4+5
sus2	One plus two plus five	1+2+5
b5	Flattened fifth	1+3+b5
Maj7b5	Major seventh flattened fifth	1+3+b5+7
1	Only Prime (Intervall Mode)	1
1+b2	Prime + kleine Sekunde (Intervall Mode)	1+b2
1+2	Prime + Sekunde (Intervall Mode)	1+2
1+b3	Prime + kleine Terz (Intervall Mode)	1+b3
1+3	Prime + große Terz (Intervall Mode)	1+3
1+4	Prime + Quarte (Intervall Mode)	1+4
1+b5	Prime + kleine Quinte (Intervall Mode)	1+b5
1+#5	Prime + übermäßige Quinte (Intervall Mode)	1+#5
1+6	Prime + Sexte (Intervall Mode)	1+6
1+b7	Prime + kleine Septime (Intervall Mode)	1+b7
1+7	Prime + große Septime (Intervall Mode)	1+7
Cancel1	Special Function (YAMAHA) Mute ACC	1+b2+2

12.2 Different chord modes

The following 9 harmony detection modes (variants/types) are available:

1-Finger-Modus	Multi-Finger-Modus	Special-Mode
Easy 1	Advanced harmonies	Organist Mode
Easy 2	Bass To Lowest	Piano Mode
One Finger WERSI	Intervall Mode	

 In the case of a preset re-storage, the harmony detection mode set here is saved.

Easy 1

A very simple (but limited) control of the automatic accompaniment, which, despite its simplicity, adheres to musical specifications by using only notes that are included in the chord (comparable to the mode Single Finger WERSI – here only fewer possibilities / variants).

 A new keystroke is usually required for each harmony change!

However, only the following harmonies are recognized after entering 1 up to 3 keys:

Major Chord	Root Note Example C = C Major or A = A Major
Seventh Chord	Root Note + one whole note (= 2 semitones) below Example C2 + Bb1 = C7 oder: A1 + G1 = A7
Minor Chord	Root Note + a minor third (= 3 semitones) above Example C2 + Eb2 = cm oder A1 + C2 = am
Minor Seventh Chord	Root Note + a minor third (= 3 semitones) above + one whole tone (= 2 semitones) below Example C2 + Eb2 + Bb1 = cm7
Major Seventh Chord	Root Note + a semitone below Example C2 + B1 = Cmaj7 oder A1 + G#1 = Amaj7

Easy 2 (YAMAHA®-Style-Modus)

Likewise, a very simple (but limited) control of the automatic accompaniment. However, this requires the timbres to be switched off in the lower manual, since dissonances (through notes that are foreign to chords) must be entered.

 A new keystroke is usually required for each harmony change!

Major Chord	Root Note Example C = C Major or A = A Major
Seventh Chord	Root Note + a white keyboard key on the left Example C2 + B1 oder C2 + A1 = C7
Minor Chord	Root Note + a black keyboard key on the left Example C2 + Bb1 oder C2 + Ab1 = cm
Minor Seventh Chord	Root Note + one black and one white keyboard key on the left Example C2 + H1 + Bb1 oder C2 + Ab1+ G1 = cm7

WERSI Single Finger

A simple (and musically more meaningful) control of the automatic accompaniment, which by entering 1 to 3 matching chord tones hardly makes it necessary to switch off the lower sound.



A new keystroke is usually required for each harmony change!

Major Chord	Root Note Example	C = C Major A= A Major
Seventh Chord	Root Note Example	+ one whole note (= 2 semitones) below C2 + Bb1 = C7 oder: A1 + G1 = A7
Minor Chord	Root Note Example	+ a minor third (= 3 semitones) above C2 + Eb2 = cm oder A1 + C2 = am
Minor Seventh Chord	Root Note Example	+ a minor third (= 3 semitones) above + a whole note (= 2 semitones) below C2 + Eb2 + Bb1 = cm7
Major Seventh Chord	Root Note Example	+ a semitone below C2 + B1 = Cmaj7 oder: A1 + G#1 = Amaj7
Minor Seventh Chord	Root Note Example or:	+ a minor third (= 3 semitones) above + a semitone below C2 + Eb2 + Bb1 = cmMaj7 A1 + C2 + Ab1 = amMaj7
Dur-None-Akkord	Root Note Example	+ a whole note above + major third above + a whole note underneath C2 + D2 + E2 + Bb1 = C9
Moll-None-Akkord	Root Note Example	+ a whole note above + minor third above + whole note underneath C2 + D2 + Eb2 + Bb1 = cm9
Other chord variants with a similar structure:		CMaj9 cmMaj9



Mute all Acc tracks except drums:

Pressing 3 keys next to each other - e.g.: A + Bb + B → **ACancel1**

This function is particularly suitable for switching off the accompaniment tracks (except drums) in a running piece - quickly and using the manual keys - and then reactivating them immediately with a normal chord grip.



This type of muting is **not possible** for the variants:

Easy 1+2 and Pedal Harmony

Chord mode [advanced chord (input)]

This accompaniment mode is a very extensive mode, in which a large number of pressed keys can be implemented for the harmony detection of your accompaniment.



At least three chord notes must be entered here. However, a partial change in your chord is recognized as a harmony change in this mode. So a complete new stop is not always necessary.

See chapter 12.1 The following harmony types are recognized.

Chord mode with bass

[*Bass To Lowest* = Bass to the lowest position; *Bassinversion* = Reversal of the bass]

The same chord entries are accepted as in Chord Mode.

However, in this mode the lowest note in the chord area (= the lowest note of your gripped chord) is interpreted as a bass note. You can use this (by choosing your chord inversions) to force precise bass runs in your accompaniment.

Procedure for creating chord inversions:

- Set the bottom note of the chord up by one octave (= 8 notes)
- Repeat this process until the chord grip lies in a meaningful key area
- In the case of inversions downwards, the top note is set down by 1 octave

Example:	Reversals upwards	Reversals downwards
C Major – initial position	= C - E - G	C - E - G
C Major – 1. Reversal	= E - G - C	G - C - E
C Major – 2. Reversal	= G - C - E	E - G - C



Musical information:

For a controllable process, it is advisable to choose a suitable style that always plays the same basic bass, so that it does not contain an alternating bass pattern.



Music example

The first 2 bars of pop-ballad „A Whiter Shade Of Pale“ (Procul Harum):

Bar	Harmony	Harmony in display
Bar 1 – Beat 1:	C – E – G (C-Dur + Bass note C)	C
Bar 1 – Beat 3:	H – C – E – G (Cmaj7 + Bass note H)	Cmaj7/B
Bar 2 – Beat 1:	A – C – E (am + Bass note A)	am
Bar 2 – Beat 3:	G – A – C – E (am7 + Bass note G)	am7/G

 The chord on the display reads e.g.: C / G = C major chord over bass G = (C on G)

Organist

- In this mode, the bass track (Acc-BASS) is automatically removed from the accompaniment, i.e.: the bass note can thus be played on the bass pedal itself!
- Sometimes the remaining accompaniment tracks (Acc1 - Acc5) are also played in the octave range and reversal of your chord.
- So you basically hear exactly what you are playing and playing in the accompaniment area.
- The harmony display ("on-bass" display) is only for general information.
- The accompaniment tracks (Acc1 - Acc5) are only played as long as a chord in the accompaniment area is pressed and held.



However, the drums (DRUM 1 + 2) keep running.

Interval

This mode basically corresponds to the Chord mode.



However, if there are fewer than 3 keys in the chord area, only these tones will be included in your accompaniment pattern.

The interval mode is particularly suitable for a very sophisticated, varied playing with the automatic accompaniment.



Played keys	Display	Harmony	Comment
C – G	C1+5	C Major	C- (not Major / Minor), because it is played without third
C	C1	----	The accompaniment only plays the C note
C – c	C1+8	----	The accompaniment only plays the notes C + c
C – Eb	C1+b3	C Minor	Cm without the fifth
G – C	G1+4	Gsus4	Gsus4 without the fifth

In this mode there are many other variants available, in which the notes used are always displayed exactly and used accordingly in the accompanying pattern.

Piano

This mode is especially intended for two-handed playing on the complete keyboard without a split in the style of a pianist and is essentially based on the interval mode.



Comment:

- At least 3 keys must be pressed for chord recognition.
- The chords can be played with the right or left hand.
- However, the lowest note is always interpreted as a bass tone (like Bass To Lowest).

In this mode, all played notes and chords are recognized across the whole keyboard and incorporated into the accompanying harmony recognition. However, intelligent programming ensures that individually played (1- to 2-part) melody runs are not used for accompanying harmony recognition in the solo as well as in the bass range.

Logic of harmony detection in this mode (only in principle):

- A chord with 3 or more notes always takes precedence
- Note of the right hand (melody notes) that are higher than the eleventh tone of the scale (# 11 = increased undezime) are no longer used for harmony detection
- 1+5 - Harmonies (pure chords) are possible by doubling the fundamental
e. g.: C + g + c → C1+5
- 1+8 - Harmonies (root chords) are possible by tripling the root
e. g.: C + c + c1 → C1+8
- and many more variants.

13 Effects for Input Mixer

Nr.	Name	Parameter
1	Reverb	1 MIX 2 - 3 Time 4 Low EQ 5 High EQ
2	Hall Reverb	1 MIX 2 - 3 Time 4 Pre Delay 5 HF Damp 6 Low EQ 7 High EQ
3	Plate reverb	1 Mix 2 - 3 Time 4 Pre Delay 5 HF Damp 6 Low EQ 7 High EQ
4	Room Reverb	1 Mix 2 - 3 Time 4 Pre Delay 5 Damping 6 Low EQ 7 High EQ 8 Size 9 Shape
5	Reverse Reverb	1 Mix 2 Sync 3 Time 4 Diffusion 5 Wet Mix 6 Dry Mix
6	Linear Reverb	1 Mix 2 - 3 Time 4 Low EQ 5 High EQ
7	Early Reflections	1 Mix 2 - 3 Time 4 Low EQ 5 High EQ

8	Hall Tuned Resonators	1 Mix 2 - 3 Band 4 Root 5 Detune 6 Spacing 7 Decay 8 Low EQ 9 HF Damp 10 Width 11 Fix/Track
9	Overheads	1 Mix 2 - 3 Time 4 Low EQ 5 High EQ 6 Diffusion 7 Room Size
10	Delay	1 Mix 2 Sync 3 Delay 4 Feedback 5 Balance 6 HF Damp
11	Stereo Delay	1 Mix 2 Sync 3 Delay 4 Feedback 5 Balance 6 HF Damp
12	Long Delay	1 Mix 2 Sync 3 Delay 4 Feedback 5 Balance 6 HF Damp
13	Tape Delay	1 MIX 2 Sync 3 Delay 4 Feedback 5 Vintage 6 Head1 7 Head2 8 Head3 9 Head4 10 Pan3+4 11 Vol3+4

14	Ducking Delay	1 MIX 2 Sync 3 Delay 4 Feedback 5 Balance 6 Low damp 7 High Damp 8 Depth 9 Thresh 10 Attack 11 Release	20	Space Chorus	1 MIX 2 - 3 Rate 4 Depth 5 Pre Delay 6 Crossover
15	Grain Delay	1 MIX 2 Sync 3 Delay 4 Feedback 5 Grain 6 Pitch 7 Pit Mod1 8 Pit Mod2 9 PM2 Rate 10 Del Mod 11 Pan Mod	21	Ensemble Chorus	1 MIX 2 - 3 Rate 4 Depth 5 Shimmer 6 Width
16	Diffuser Delay	1 Mix 2 Sync 3 Delay 4 Feedback 5 Balance 6 Diffusion	22	Flanger	1 MIX 2 - 3 Rate 4 Depth 5 Feedback 6 Pre Delay
17	Chorus + Reverb	1 Mix 2 - 3 Rate 4 Depth 5 Chorus <> Reverb 6 Rev Time 7 Pre Delay 8 Damping 9 Low Cut 10 Hi Cut	23	Step Flanger	1 MIX 2 - 3 Sync 4 Rate 5 Depth 6 Feedback 7 Pre Delay 8 Step rate 9 Step Depth
18	Chorus	1 MIX 2 - 3 Rate 4 Depth 5 Pre Delay	24	Phaser	1 MIX 2 - 3 Rate 4 Depth 5 Feedback 6 Stereo 7 Centre
19	Quad Chorus	1 MIX 2 - 3 Rate 4 Depth 5 Pre Delay 6 Tone 7 Feedback	25	Deep Phaser	1 MIX 2 - 3 Rate 4 Feedback 5 Centre 6 Env Mod 7 Env Rate
			26	Bi-Phaser	1 MIX 2 - 3 Rate 4 Depth 5 Feedback 6 Stereo 7 Centre
			27	Pan/Tremolo	1 MIX 2 Rate 3 Phase 4 Shape

28	Stereo Width	1 Output 2 - 3 Delay 4 Width 5 Low 6 Mid 7 High 8 Mode	34	Detune	1 MIX 2 - 3 Detune 4 Latency
29	Stereo Enhancer	1 Width 2 - 3 Stage 1 4 Stage 2 5 Stage 3 6 Stages 7 Pan Trim	35	Vintage Filter	1 MIX 2 - 3 Cutoff 4 Resonanz 5 Mode 6 LFO Rate 7 LFO Depth 8 Envelope Depth 9 Envelope Mode 10 Attack 11 Release 12 Mode
30	Scanner Vibrato	1 Mode 2 - 3 Rate 4 Depth 5 Grit 6 Amp Mod	36	Wah Pedal	1 MIX 2 - 3 Sync 4 Rate 5 Depth 6 Pedal 7 Mode 8 Reso 9 Tracking
31	Rotary Speaker 1	1 MIX 2 - 3 Rate 4 Dirt 5 Lo/Hi 6 Width 7 High Speed 8 Low Speed 9 High Acc 10 Low Acc 11 Tone	37	Talkbox	1 MIX 2 Sync 3 Rate 4 Depth 5 Vowel 6 Env mod 7 Env Att 8 Env Rel
32	Rotary Speaker 2	1 MIX 2 - 3 Rate 4 Drive 5 Lo/Hi Mix 6 Width 7 Freq Mod 8 Fast Speed 9 Low Speed 10 Crossover 11 Horn Reso 12 Boost	38	Shelf EQ	1 Output 2 - 3 Bass 4 Treble
33	Pitch Shift	1 MIX 2 Sync 3 Left in Cent 4 Right in Cent 5 Latency 6 Delay 7 Feedback	39	Parametric EQ	1 Output 2 - 3 Gain 1 4 Frequenz 1 5 Width 1 6 Gain 2 7 Frequenz 2 8 Width 2
			40	Enhancer	1 Hight Depth 2 Low Depth 3 Low
			41	Limiter	1 Output 2 Drive 3 Attack 4 Release

42	Compressor	1 Output 2 - 3 Thresh 4 Ratio 5 Attack 6 Release
43	Multiband Compressor	1 Output 2 - 3 Drive 4 Lo/Hi 5 Mid 6 Attack 7 Release
44	Punch	1 Output 2 - 3 Drive 4 Ratio 5 Attack 6 Release
45	Gate	1 Output 2 - 3 Thresh 4 Range 5 Attack 6 Release
46	Distortion	1 MIX 2 - 3 Drive 4 Bias 5 Out 6 Tone
47	Overdrive	1 MIX 2 - 3 Drive 4 Bias 5 Out 6
48	Bit Reduction	1 MIX 2 - 3 Rate 4 Depth 5 SlewRate 6 Mode
49	Amp Simulator	1 MIX 2 - 3 Model 4 Drive 5 Feedback 6 Treble 7 Mode

50	Tube Drive	1 Mix 2 - 3 Drive 4 Clip 5 Bias 6 Hi cut 7 Low Cut 8 Mode
51	Waveshaper	1 Mix 2 - 3 Drive 4 Rate 5 Out
52	Modulate L/R	1 MIX 2 - 3 Smooth 4 Drive 5 Thru

14 Drum kits

MSB-LSB-PRG	94-000-000	94-000-001	94-000-002
Nr.	Note	Standard 1	Standard 2
13	C#-1	Surdo Mute	Surdo Mute
14	D-1	Surdo Open	Surdo Open
15	D#-1	Hi Q	Hi Q
16	E-1	WhipSlap	WhipSlap
17	F-1	Scratch High	Scratch High
18	F#-1	Scratch Low	Scratch Low
19	G-1	FingerSnap 1	FingerSnap 1
20	G#-1	Click Noise	Click Noise
21	A-1	Metronome Click	Metronome Click
22	A#-1	Metronome Bell	Metronome Bell
23	B-1	Seq Click Low	Seq Click Low
24	C0	Seq Click High	Seq Click High
25	C#0	Brush SP Snare 1	Brush SP Snare 1
26	D0	Brush SP Snare Swirl	Brush SP Snare Swirl
27	D#0	Brush SP Snare 2	Brush SP Snare 2
28	E0	Brush SP Snare Mute	Brush SP Snare Mute
29	F0	Snare Roll	Snare Roll
30	F#0	Castanet	Castanet
31	G0	Snare Uni 3	Snare Uni 3
32	G#0	CountIn Stick	Sticks
33	A0	Uni Kick 02	Uni Kick 01
34	A#0	Funk Snare Rim	Snare Pearl Master
35	B0	Uni Kick 01	DW Kick V1
36	C1	DW Kick V2	Sonor Kick V2
37	C#1	Sonor SQ2 CrossStick	DW Steel CrossStick
38	D1	Snare Sonor SQ2 Rimshot	Snare DW Steel
39	D#1	Claps 1	Claps 1
40	E1	Noble Cooley	Snare DW Steel Rim
41	F1	DW16 Tom <	Yam 13x15 <
42	F#1	Hihat Zildjian Cl	Hihat Sabian CL
43	G1	DW16 Tom >	Yam Tom 13x15 >
44	G#1	Hihat Foot	Hihat Sabian Pedal
45	A1	DW14 Tom	Yam Tom 9x13
46	A#1	Hihat Zildjian Open	Hihat Sabian Open
47	B1	DW12 Tom	Yam Tom 8x12
48	C2	DW10 Tom <	Yam Tom 8x10 <
49	C#2	Crash 1 Medium	Crash 2 Extreme
50	D2	DW10 Tom >	Yam Tom 8x10 >
51	D#2	Ride Modern	Groove Ride
52	E2	Chinese Sabian	Chinese Sabian
53	F2	Ride Bell Modern	Groove Ride Bell
54	F#2	Tambo 3	Tambo 2
55	G2	Splash Sabian	Splash Sabian
56	G#2	Cowbell 3 Low open	Cowbell 1 Open
57	A2	Crash 2 Extreme	Crash 1 Medium
58	A#2	Vibraslap	Vibraslap
59	B2	Ride Beat	Ride Modern
60	C3	Bongo H Open + Tip	Bongo High Stick
61	C#3	Bongo L Rim + Slap	Bongo Low Stick
62	D3	Conga High Mute	Conga 2 High Mute
63	D#3	Conga High Open	Conga 2 High Open
64	E3	Conga Low	Conga Low
65	F3	Timbales High	Timbales High AfroCuban
66	F#3	Timbales Low	Timbales Low AfroCuban
67	G3	Agogo High 1	Agogo High Brasil
68	G#3	Agogo Low 1	Agogo Low Brasil
69	A3	Cabasa 1	Cabasa 3
70	A#3	Maracas 1	Maracas 2
71	B3	Whistle High	Whistle High
72	C4	Whistle Low	Whistle Low
73	C#4	Guiro Short	Metal Guiro Short
74	D4	Guiro Long	Metal Guiro Long
75	D#4	Clave High	Clave Pop
76	E4	Wood Block High	Wood Block High Pop
77	F4	Wood Block Low	Wood Block Low Pop
78	F#4	Cuica High	Cuica High
79	G4	Cuica Low	Cuica Low
80	G#4	Triangle High Short	Triangle Brasil Short
81	A4	Triangle High Long	Triangle Brasil Long
82	A#4	Shaker 1 Egg	Shaker 2
83	B4	Sleighbells	Sleighbells
84	C5	Wind Chimes	Wind Chimes AfroCuban
85	C#5		Wind Chimes
86	D5		
87	D#5		
88	E5		
89	F5		
90	F#5		
91	G5		
92	G#5		
93	A5		
94	A#5		

MSB-LSB-PRG	94-000-008	94-000-012	94-000-013
Nr.	Note	Room Kit	Power Kit 1
13	C#-1	Surdo Mute	Surdo Mute
14	D-1	Surdo Open	Surdo Open
15	D#-1	Hi Q	Hi Q
16	E-1	WhipSlap	WhipSlap
17	F-1	Scratch High	Scratch High
18	F#-1	Scratch Low	Scratch Low
19	G-1	FingerSnap 1	FingerSnap 1
20	G#-1	Click Noise	Click Noise
21	A-1	Metronome Click	Metronome Click
22	A#-1	Metronome Bell	Metronome Bell
23	B-1	Seq Click Low	Seq Click Low
24	C0	Seq Click High	Seq Click High
25	C#0	Brush SP Snare 1	Brush SP Snare 1
26	D0	Brush SP Snare Swirl	Brush SP Snare Swirl
27	D#0	Brush SP Snare 2	Brush SP Snare 2
28	E0	Brush SP Snare Mute	Brush SP Snare Mute
29	F0	Snare Roll	Snare Roll
30	F#0	Castanet	Castanet
31	G0	Snare Uni 3	Snare Uni 3
32	G#0	CountIn Stick	CountIn Stick
33	A0	DW Kick V2 Room	Pop Kick V3
34	A#0	Funk Snare Rim	Noble Cooley Rim
35	B0	Rock Kick V1	Pop Kick V2
36	C1	DW Kick V2 Room	Pop Kick V1
37	C#1	DW Steel Room CrossStick	Noble Cooley CrossStick
38	D1	Snare DW Steel Room	Snare Z-Noobley Cooley
39	D#1	Claps 6 Open	Claps 2 Disco
40	E1	Snare Sonor SQ2 Room	Snare Noobley Cooley
41	F1	DW16 Room Tom <	Pop Tom Low 1
42	F#1	Hihat Sabian CL	Hihat Heavy Closed B
43	G1	DW16 Room Tom >	Pop Tom Low 2
44	G#1	Hihat Sabian Pedal	Hihat Heavy Foot
45	A1	DW14 Room Tom	Pop Tom Midi 1
46	A#1	Hihat Sabian Open	Hihat Heavy Open
47	B1	DW12 Room Tom	Pop Tom Midi 2
48	C2	DW10 Room Tom <	Pop Tom High 1
49	C#2	Crash 1 Medium	Heavy Crash 1
50	D2	DW10 Room Tom >	Pop Tom High 2
51	D#2	Groove Ride	Ride Modern
52	E2	Chinese Sabian	Chinese Sabian
53	F2	Groove Ride Bell	Ride Bell Modern
54	F#2	Tambo 3	Tambo 2
55	G2	Splash Sabian	Splash 2
56	G#2	Cow 1 Open	Cowbell 3 Low open
57	A2	Crash 2 Extreme	Rock Crash 1
58	A#2	Vibraslap	Vibraslap
59	B2	Dry Ride	Groove Ride
60	C3	Bongo High 1	Bongo Stick High
61	C#3	Bongo Low 1	Bongo Stick Low
62	D3	Conga High Mute	Conga 2 High Mute
63	D#3	Conga High Open	Conga 2 High Open
64	E3	Conga Low	Conga Low
65	F3	Timbales High	Timbales High
66	F#3	Timbales Low	Timbales Low
67	G3	Agogo High 1	Agogo High 1
68	G#3	Agogo Low 1	Agogo Low 1
69	A3	Cabasa 1	Cabasa 3
70	A#3	Maracas 1	Maracas 2
71	B3	Whistle High	Whistle High
72	C4	Whistle Low	Whistle Low
73	C#4	Guiro Short	Guiro Short
74	D4	Guiro Long	Guiro Long
75	D#4	Clave High	Clave High
76	E4	Wood Block High	Wood Block High
77	F4	Wood Block Low	Wood Block Low
78	F#4	Cuica High	Cuica High
79	G4	Cuica Low	Cuica Low
80	G#4	Triangle High Short	Triangle High Short
81	A4	Triangle High Long	Triangle High Long
82	A#4	Shaker 1 Egg	Shaker 2
83	B4	Sleighbells	Sleighbells
84	C5	Wind Chimes	Wind Chimes
85	C#5		
86	D5		
87	D#5		
88	E5		
89	F5		
90	F#5		
91	G5		
92	G#5		
93	A5		
94	A#5		
95	B5		
96	C6		

MSB-LSB-PRG		94-000-016	94-000-024	94-000-025
Nr.	Note	Rock Kit 1	Electro Kit	Analog Kit
13	C#-1	Surdo Mute	Surdo Mute	Surdo Mute
14	D-1	Surdo Open	Surdo Open	Surdo Open
15	D#-1	Hi Q	Hi Q	Hi Q
16	E-1	WhipSlap	WhipSlap	WhipSlap
17	F-1	Scratch High	Scratch High	Scratch High
18	F#-1	Scratch Low	Scratch Low	Scratch Low
19	G-1	FingerSnap 1	FingerSnap 1	FingerSnap 1
20	G#-1	Click Noise	Click Noise	Click Noise
21	A-1	Metronome Click	Metronome Click	Metronome Click
22	A#-1	Metronome Bell	Metronome Bell	Metronome Bell
23	B-1	Seq Click Low	Seq Click Low	Seq Click Low
24	C0	Seq Click High	Seq Click High	Seq Click High
25	C#0	Brush SP Snare 1	Brush SP Snare 1	Brush SP Snare 1
26	D0	Brush SP Snare Swirl	Brush SP Snare Swirl	Brush SP Snare Swirl
27	D#0	Brush SP Snare 2	Brush SP Snare 2	Brush SP Snare 2
28	E0	Brush SP Snare Mute	Brush SP Snare Mute	Brush SP Snare Mute
29	F0	Snare Roll	Snare Roll	Snare Roll
30	F#0	Castanet	Castanet	Castanet
31	G0	Snare 1 Disco	Snare Uni 3	Snare Uni 3
32	G#0	CountIn Stick	CountIn Stick	CountIn Stick
33	A0	Heavy Kick V1	Pop Kick 1	R6B Kick 2
34	A#0	Funk Snare Rim	Funk Snare Rim	Funk Snare Rim
35	B0	Rock Kick V1	Elektro Kick 2	808 Kick 2
36	C1	Rock Kick V2	Elektro Kick 1	808 Kick 1
37	C#1	Rock Snare CrossStick	808 Rimshot	808 Rimshot
38	D1	Rock Snare	Elektro Snare 1	808 Snare 1
39	D#1	Claps 1	808 Claps	808 Claps
40	E1	Snare Ludwig Beauty	Pop Snare 5	808 Snare 2
41	F1	Rock16 Tom <	Simmons Tom Low	808 Tom Low Low
42	F#1	Hihat Heavy CL	Hihat Heavy CL	Hihat Heavy CL
43	G1	Rock16 Tom >	Simmons Tom Mid <	808 Tom Low
44	G#1	Hihat Heavy Pedal	Hihat Heavy Pedal	Hihat Heavy Pedal
45	A1	Rock14 Tom	Simmons Tom Mid >	808 Tom Mid
46	A#1	Hihat Heavy Open	Hihat Heavy Open	Hihat Heavy Open
47	B1	Rock12 Tom	Simmons Tom Mid 1	808 Tom Mid High
48	C2	Rock10 Tom <	Simmons Tom High <	808 Tom High
49	C#2	Rock Crash 1	Crash 1 Medium	808 Crash
50	D2	Rock10 Tom >	Simmons Tom High >	808 Tom High High >
51	D#2	Groove Ride	Ride 1	Ride 1
52	E2	Chinese Sabian	Chinese Sabian	Chinese Sabian
53	F2	Groove Ride Bell	Ride 1 Bell	Ride 1 Bell
54	F#2	Tambo 3	Tambo 1	808 Tambo
55	G2	Rock Splash	Splash Sabian	Splash Sabian
56	G#2	Cowbell 3 Low Open	Cowbell 1 Open	808 Cowbell
57	A2	Rock Crash 2	Crash 2 Extreme	Crash 2 Extreme
58	A#2	Vibraslap	Vibraslap	Vibraslap
59	B2	Ride Modern	Ride 2	Ride 2
60	C3	Bongo Stick High	Bongo Stick High	Bongo Stick High
61	C#3	Bongo Stick Low	Bongo Stick Low	Bongo Stick Low
62	D3	Conga 2 High Mute	Conga 2 High Mute	Conga 2 High Mute
63	D#3	Conga 2 High Open	Conga 2 High Open	Conga 2 High Open
64	E3	Conga Low	Conga Low	Conga Low
65	F3	Timbales High	Timbales High	Timbales High
66	F#3	Timbales Low	Timbales Low	Timbales Low
67	G3	Agogo High 1	Agogo High 1	Agogo High 1
68	G#3	Agogo Low 1	Agogo Low 1	Agogo Low 1
69	A3	Cabasa 3	Cabasa 3	Cabasa 3
70	A#3	Maracas 2	Maracas 2	Maracas 2
71	B3	Whistle High	Whistle High	Whistle High
72	C4	Whistle Low	Whistle Low	Whistle Low
73	C#4	Guiro Short	Guiro Short	Guiro Short
74	D4	Guiro Long	Guiro Long	Guiro Long
75	D#4	Clave High	Clave High	Clave High
76	E4	Wood Block High	Wood Block High	Wood Block High
77	F4	Wood Block Low	Wood Block Low	Wood Block Low
78	F#4	Cuica High	Cuica High	Cuica High
79	G4	Cuica Low	Cuica Low	Cuica Low
80	G#4	Triangle High Short	Triangle High Short	Triangle High Short
81	A4	Triangle High Long	Triangle High Long	Triangle High Long
82	A#4	Shaker 2	Shaker 2	Shaker 2
83	B4	Sleighbells	Sleighbells	Sleighbells
84	C5	Wind Chimes	Wind Chimes	Wind Chimes
85	C#5			
86	D5			
87	D#5			
88	E5			
89	F5			
90	F#5			
91	G5			
92	G#5			
93	A5			
94	A#5			
95	B5			
96	C6			

MSB-LSB-PRG	94-000-026	94-000-031	94-000-032
Nr.	Note	Dance Kit	Studio Kit
13	C#-1	Dance Kick 1	Surdo Mute
14	D-1	Dance Kick 2	Surdo Open
15	D#-1	Hi Q	Hi Q
16	E-1	WhipSlap	WhipSlap
17	F-1	Dance Eff 1	Scratch High
18	F#-1	Dance Eff 2	Scratch Low
19	G-1	FingerSnap 2	FingerSnap 1
20	G#-1	Click Noise	Click Noise
21	A-1	Dance Eff 3	Metronome Click
22	A#-1	Dance Eff 4	Metronome Bell
23	B-1	Dance Eff 5	Seq Click Low
24	C0	Dance Eff 6	Seq Click High
25	C#0	Dance Eff 7	Brush SP Snare 1
26	D0	Dance Eff 8	Brush SP Snare Swirl
27	D#0	Dance Eff 9	Brush SP Snare 2
28	E0	Reverse Crash	Brush SP Snare Mute
29	F0	Dance Eff 10	Snare Roll
30	F#0	Hi Q2	Castanet
31	G0	R+B Snare 2	Jazz Snare
32	G#0	Dance Eff 12	Countin Stick
33	A0	R+B Kick 2	DW Kick V2
34	A#0	R+B Snare 1	DW Craviotto Rim
35	B0	Dance Kick 1	GMS Kick V2
36	C1	Dance Kick 2	Uni Kick 02
37	C#1	909 Rimshot	Ludwig Beauty CrossStick
38	D1	Dance Snare 1	Snare Ludwig Beauty
39	D#1	Dance Claps 1	Claps 1
40	E1	Dance Snare 2	Snare Noolley Cooley
41	F1	Dance Tom Low <	Yam 13x15
42	F#1	Hihat Dance 2 CL	Hihat Sabian CL
43	G1	Dance Tom Low >	Yam Tom 11x14
44	G#1	Hihat Dance 2 Foot	Hihat Sabian Pedal
45	A1	Dance Tom Mid <	Yam Tom 9x13
46	A#1	Hihat Dance 2 open	Hihat Sabian Open
47	B1	Dance Tom Mid >	Yam Tom 8x12
48	C2	Dance Tom high <	Yam Tom 8x10 <
49	C#2	Crash 1 Medium	Heavy Crash 1
50	D2	Dance Tom High >	Yam Tom 8x10 >
51	D#2	Ride 1	Groove Ride
52	E2	Chinese Sabian	Chinese Sabian
53	F2	Ride 1 Bell	Ride 1 Bell
54	F#2	Tambo 1	Tambo 3
55	G2	Splash Sabian	Splash 2
56	G#2	Cowbell 1 Open	Cowbell 1 Open
57	A2	Crash 2 Extreme	Rock Crash 1
58	A#2	Vibraslap	Vibraslap
59	B2	Ride 2	Jazz Ride 1
60	C3	Bongo High 1	Bongo High Stick
61	C#3	Bongo Low 1	Bongo Low Stick
62	D3	Conga High Mute	Conga High Mute
63	D#3	Conga High Open	Conga High Open
64	E3	Conga Low	Conga Low
65	F3	Timbales High	Timbales High
66	F#3	Timbales Low	Timbales Low
67	G3	Agogo High 1	Agogo High 1
68	G#3	Agogo Low 1	Agogo Low 1
69	A3	Cabasa 1	Cabasa 3
70	A#3	Maracas 1	Maracas 3
71	B3	Whistle High	Whistle High
72	C4	Whistle Low	Whistle Low
73	C#4	Guiro Short	Guiro Short
74	D4	Guiro Long	Guiro Long
75	D#4	Clave High	Clave High
76	E4	Dance Perk 3	Wood Block High
77	F4	Dance Perc 4	Wood Block Low
78	F#4	Dance Eff 14	Cuica High
79	G4	Dance Eff 15	Cuica Low
80	G#4	Triangle High Short	Triangle High Short
81	A4	Triangle High Long	Triangle High Long
82	A#4	Shaker 1 Egg	Shaker 3
83	B4	Sleighbells	Sleighbells
84	C5	Wind Chimes	Wind Chimes
85	C#5		
86	D5		
87	D#5		
88	E5		
89	F5		
90	F#5		
91	G5		
92	G#5		
93	A5		
94	A#5		
95	B5		
96	C6		

MSB-LSB-PRG	94-000-036	94-000-037	94-000-040	
Nr.	Note	Hit Kit 1	Hit Kit 2	Brush Kit 1
13	C#-1	Surdo Mute	Surdo Mute	Surdo Mute
14	D-1	Surdo Open	Surdo Open	Surdo Open
15	D#-1	Hi Q	Hi Q	Hi Q
16	E-1	WhipSlap	WhipSlap	WhipSlap
17	F-1	Scratch High	Scratch High	Scratch High
18	F#-1	Scratch Low	House Kick V2	Scratch Low
19	G-1	FingerSnap 1	House Kick V1	FingerSnap 1
20	G#-1	Click Noise	Pop Kick V8	Click Noise
21	A-1	Metronome Click	Pop Kick V7	Metronome Click
22	A#-1	Metronome Bell	Pop Kick V6	Metronome Bell
23	B-1	Seq Click Low	Pop Kick V5	Seq Click Low
24	C0	Seq Click High	Pop Kick V4	Seq Click High
25	C#0	Brush SP Snare 1	Pop Snare V8	Brush SP Snare 1
26	D0	Brush SP Snare Swirl	Pop Snare V7	Brush SP Snare Swirl
27	D#0	Brush SP Snare 2	Pop Snare V6	Brush SP Snare 2
28	E0	Brush SP Snare Mute	Pop Snare V5	Brush SP Snare Mute
29	F0	Snare Roll	Snare Roll	Snare Roll
30	F#0	Castanet	Castanet	Castanet
31	G0	Snare Uni 3	Pop Snare V2	Brush Hit V1
32	G#0	CountIn Stick	CountIn Stick	CountIn Stick
33	A0	Pop Kick V7	Pop Kick V3	Jazz Kick V3
34	A#0	Funk Snare Rim	Pop Snare V4	Brush Rimshot V2
35	B0	Pop Kick V1	Pop Kick V2	Brush Kick V1
36	C1	Uni Kick 02	Pop Kick V1	Brush SP Kick
37	C#1	Tama Room CrossStick	Sonor SQ2 CrossStick	Jazz Snare CrossStick
38	D1	Snare Uni 5	Pop Snare V1	Brush SP Snare 1
39	D#1	Claps 2 Disco	Claps Hit	Brush SP Snare Mute
40	E1	Snare Sonor SQ2	Pop Snare V3	Brush SP Snare 2
41	F1	Hit Tom 1 Low <	Hit Tom 2 Low <	Brush SP Tom 4 <
42	F#1	Hihat Zildjian Cl	Hihat Heavy Cl	Hihat Brush SP CL
43	G1	Hit Tom 1 >	Hit Tom 2 Low >	Brush SP Tom 4 >
44	G#1	Hihat Foot	Hihat Heavy Foot	Hihat Brush SP Foot
45	A1	Hit Tom 1 Mid <	Hit Tom 2 Mid <	Brush SP Tom 3
46	A#1	Hihat Zildjian Open	Hihat Heavy Open	Hihat Brush SP Open
47	B1	Hit Tom 1 Mid >	Hit Tom 2 Mid >	Brush SP Tom 2
48	C2	Hit Tom1 High <	Hit Tom 2 High <	Brush SP Tom 1 <
49	C#2	Heavy Crash 1	Heavy Crash 1	Brush SP Crash 1
50	D2	Hit Tom 1 High >	Hit Tom 2 High >	Brush SP Tom 1 >
51	D#2	Ride Modern	Ride Modern	Jazz Ride 1
52	E2	Chinese Sabian	Chinese Sabian	Chinese Sabian
53	F2	Ride Bell Modern	Ride Bell Modern	Jazz Ride Bell
54	F#2	Tambo 2	Tambo 3	Tambo 2
55	G2	Splash 2	Splash 2	Brush SP Splash
56	G#2	Cow 3 Low Open	Cow 2 ChaCha	Cow 1 Open
57	A2	Rock Crash 1	Rock Crash 1	Brush SP Crash 2
58	A#2	Vibraslap	Vibraslap	Vibraslap
59	B2	Ride Beat	Ride Beat	Ride Brush
60	C3	Bongo High 1	Bongo H Open + Tip	Bongo High 1
61	C#3	Bongo Low 1	Bongo L Rim + Slap	Bongo Low 1
62	D3	Conga 2 High Mute	Conga AfroCuban High Mute	Conga High Mute
63	D#3	Conga 2 High Open	Conga AfroCuban High Open	Conga High Open
64	E3	Conga Low	Conga AfroCuban Low	Conga Low
65	F3	Timbales High	Timbales High	Timbales High
66	F#3	Timbales Low	Timbales Low	Timbales Low
67	G3	Agogo High 1	Agogo High 1	Agogo High 1
68	G#3	Agogo Low 1	Agogo Low 1	Agogo Low 1
69	A3	Cabasa 2	Cabasa Brazilian	Cabasa 1
70	A#3	Maracas 2	Maracas AfroCuban	Maracas 1
71	B3	Whistle High	Whistle High	Whistle High
72	C4	Whistle Low	Whistle Low	Whistle Low
73	C#4	Guiro Short	Guiro Short	Guiro Short
74	D4	Guiro Long	Guiro Long	Guiro Long
75	D#4	Clave High	Clave High	Clave High
76	E4	Wood Block High	Wood Block High	Wood Block High
77	F4	Wood Block Low	Wood Block Low	Wood Block Low
78	F#4	Cuica High	Cuica High	Cuica High
79	G4	Cuica Low	Cuica Low	Cuica Low
80	G#4	Triangle High Short	Triangle High Short	Triangle High Short
81	A4	Triangle High Long	Triangle High Long	Triangle High Long
82	A#4	Shaker 2	Shaker PopPerc	Shaker 1 Egg
83	B4	Sleighbells	Sleighbells	Sleighbells
84	C5	Wind Chimes	Wind Chimes	Wind Chimes
85	C#5			
86	D5			
87	D#5			
88	E5			
89	F5			
90	F#5			
91	G5			
92	G#5			
93	A5			
94	A#5			
95	B5			
96	C6			

MSB-LSB-PRG		94-000-045	94-000-046	94-000-047
Nr.	Note	Pop Latin Kit	Arabic Kit	Cuban Kit
13	C#-1	Cajon Low		
14	D-1	Cajon Slap		
15	D#-1	Cajon Tip		
16	E-1	Woodblock High		
17	F-1	Woodblock Low		
18	F#-1	Claps 1		Claps 1
19	G-1			
20	G#-1	Fingersnap 2		
21	A-1	Castanet		
22	A#-1	Conga H Tip		Conga H Tip
23	B-1	Conga H Heel		Conga H Heel
24	C0	Conga H Open	Nakarazan Dom	Conga H Open
25	C#0	Conga H Mute	Cabasa	Conga H Mute
26	D0	Conga H Slap Open	Nakarazan Edge	Conga H Slap Open
27	D#0	Conga H Slap	Hager Dom	Conga H Slap
28	E0	Conga H Slap Mute	Hager Edge	Conga H Slap Mute
29	F0	Conga L Tip	Bongo H	Conga L Tip
30	F#0	Conga L Heel	Bongo L	Conga L Heel
31	G0	Conga L Open	Conga H Mute	Conga L Open
32	G#0	Conga L Mute	Conga H Open	Conga L Mute
33	A0	Conga L Slap Open	Conga L	Conga L Slap Open
34	A#0	Conga L Slap	Zagrouda H	Conga L Slap
35	B0	Conga L Slide	Zagrouda L	Conga L Slide
36	C1	Bongo H Open 1F	Jazz Kick V1	Bongo H Open 1F
37	C#1	Bongo H Open 3F	Sonor SQ2 CrossStick	Bongo H Open 3F
38	D1	Bongo H Rim	Snare Sonor SQ2	Bongo H Rim
39	D#1	Bongo H Tip	Arabic Clap	Bongo H Tip
40	E1	Bongo H Heel	Snare Sonor SQ2 Rim	Bongo H Heel
41	F1	Bongo H Slap	DW16 Tom <	Bongo H Slap
42	F#1	Bongo L Open 1F	Hihat Zildjian CI	Bongo L Open 1F
43	G1	Bongo L Open 3F	DW16 Tom >	Bongo L Open 3F
44	G#1	Bongo L Rim	Hihat Foot	Bongo L Rim
45	A1	Bongo L Tip	DW14 Tom	Bongo L Tip
46	A#1	Bongo L Heel	Hihat Zildjian Open	Bongo L Heel
47	B1	Bongo L Slap	DW12 Tom	Bongo L Slap
48	C2	Timbales Low	DW10 Tom <	Timbales Low
49	C#2		Crash 1 Medium	
50	D2		DW10 Tom >	
51	D#2		Ride	
52	E2		Vintage Crash 1	
53	F2	Paila L	Duhulla Dom	Paila L
54	F#2	Timbales High	Tambo 1	Timbales High
55	G2		Duhulla Tak	
56	G#2		Cow 1 Open	
57	A2		Duhulla Sak	
58	A#2		Claves	
59	B2	Paila H	Doff Dom	Paila H
60	C3	Cowbell Top	Katem Dom	
61	C#3	Cowbell 1	Katem Tak	
62	D3	Cowbell 2	Katem Sak	
63	D#3	Cowbell 3	Katem Tak	
64	E3	Guira Short	Doff Tak	Guira Short
65	F3	Guira Long	Tabla Dom	Guira Long
66	F#3	Metal Guiro Short	Tabla Tak1	
67	G3	Metal Guiro Long	Tabla Tik	
68	G#3	Tambo 2	Tabla Tak2	Tambo 1
69	A3	Tambo Open	Tabla Sak	
70	A#3	Tambo Mute	Tabla Roll	
71	B3	Tambo Tip	Tabla Flam	
72	C4	Maracas 2	Sagat 1	Maracas 3
73	C#4	Shaker 1 Egg	Tabel Dom	Shaker 3
74	D4	Cabasa 1	Sagat 3	Cabasa 2
75	D#4	Guica Low	Tabel Tak	
76	E4	Guica High	Sagat 2	
77	F4	Cow 3 Low Open	Rik Dom	
78	F#4	Cow 1 Side	Rik Tak 2	
79	G4	Shekere	Rik Finger 1	Shekere
80	G#4	Shekere Tone	Rik Tak 1	
81	A4	Triangle Mute	Rik Finger 2	
82	A#4	Triangle Open	Rik Brass	
83	B4		Rik Sak	
84	C5	Wind Chimes	Rik Tik	
85	C#5			
86	D5			
87	D#5			
88	E5			
89	F5			
90	F#5			
91	G5			
92	G#5			
93	A5			
94	A#5			
95	B5			
96	C6			

MSB-LSB-PRG			104-000-001
Nr.	Note		Enter Standard
13	C#-1		Rimshot Reverb
14	D-1		Rimshot 2
15	D#-1		Tambo 2
16	E-1		Cave
17	F-1		Snare 6
18	F#-1		Salute
19	G-1		FingerSnap
20	G#-1		Spectra Snare
21	A-1		Castanet
22	A#-1		Wood Block High
23	B-1		Snare 1
24	C0		Snare Roll
25	C#0		Brush Hard
26	D0		Brush Hit
27	D#0		Brush Soft
28	E0		Brush Loop
29	F0		Snare 2
30	F#0		Clap Spain
31	G0		Conga Low
32	G#0		CountIn Stick
33	A0		Conga High
34	A#0		Hihat CL Bright
35	B0		Bassdrum 1
36	C1		DW Kick V1
37	C#1		Rimshot 1
38	D1		Snare 3
39	D#1		Claps
40	E1		Snare 4
41	F1		Tom Low <
42	F#1		Hihat Half Open
43	G1		Tom Low >-
44	G#1		Hihat Foot
45	A1		Tom Middle <
46	A#1		Hihat Open
47	B1		Tom Middle >
48	C2		Tom High <
49	C#2		Crash 2
50	D2		Tom High >
51	D#2		Ride 1
52	E2		Crash 3
53	F2		Ride 1 Bell
54	F#2		Tambo 1
55	G2		Crash 4
56	G#2		Cowbell
57	A2		Crash 1
58	A#2		Vibraslap
59	B2		Bassdrum 2
60	C3		Bongo H open
61	C#3		Bongo L Open
62	D3		Conga H Slap
63	D#3		Conga H Open
64	E3		Conga L Open
65	F3		Timbales High
66	F#3		Timbales Low
67	G3		Agogo High
68	G#3		Agogo Low
69	A3		Cabasa
70	A#3		Maracas
71	B3		Hai Hai
72	C4		Whistle Seq
73	C#4		Guiro Short
74	D4		Guiro Long
75	D#4		Arriva
76	E4		Wood Block High
77	F4		Wood Block Low
78	F#4		Cuica High
79	G4		Yeah
80	G#4		Triangle Long
81	A4		Triangle Short
82	A#4		Shaker 2
83	B4		Ride 1
84	C5		Chimes
85	C#5		
86	D5		
87	D#5		
88	E5		
89	F5		
90	F#5		
91	G5		
92	G#5		
93	A5		
94	A#5		
95	B5		
96	C6		

MSB-LSB-PRG	104-000-002	104-000-003	104-000-004
Nr.	Note	Enter Dance	Enter Live
13	C#-1	Rimshot Reverb	Surdo Open
14	D-1	Rimshot 2	Snare Power 3
15	D#-1	Tambo 2	Hi Q
16	E-1	Cave	WhipSlap
17	F-1	Snare 6	Scratch High
18	F#-1	Salute	Scratch Low
19	G-1	FingerSnap	FingerSnap 1
20	G#-1	Spectra Snare	Spectra Snare 2
21	A-1	Castanet	Castanet
22	A#-1	Wood Block High	Wood Block High
23	B-1	Snare 1	Seq Click Low
24	C0	Snare Roll	Seq Click High
25	C#0	Brush Hard	Brush Hard
26	D0	Brush Hit	Brush Hit
27	D#0	Brush Soft	Brush Soft
28	E0	Brush Loop	Brush Loop
29	F0	Snare 2	Snare Roll
30	F#0	Clap Spain	Spectra Snare
31	G0	808 Snare 2	Sonor SQ2 Room CrossStick
32	G#0	CountIn Stick	CountIn Stick
33	A0	Electro Kick 1	DW Kick V1
34	A#0	Hihat CL Bright	Funk Snare Rim
35	B0	Electro Kick 2	DM Kick V2
36	C1	Uni Kick 02	Uni Kick 02
37	C#1	Dance Eff 9	Sonor SQ2 Room CrossStick
38	D1	Spectra Snare	Snare Z-Noobley Cooley
39	D#1	Claps 2 Disco	Claps 2 Disco
40	E1	Snare 5	Snare Noobley Cooley
41	F1	Simmons Tom Low	Tom 6
42	F#1	Hihat Zildjian Cl	Hihat CL
43	G1	Simmons Tom Mid2 <	Tom 5
44	G#1	Hihat Foot	Hihat Foot
45	A1	Simmons Tom Mid2 >	Tom 4
46	A#1	Hihat Zildjian Open	Hihat Open
47	B1	Simmons Tom Mid1	Tom 3
48	C2	Simmons Tom High <	Tom 2
49	C#2	Crash 2	Crash 1
50	D2	Simmons Tom High >	Tom 1
51	D#2	Ride 1	Ride 1
52	E2	Crash 3	Crash 3
53	F2	Ride 1 Bell	Ride 1 Bell
54	F#2	Tambo 1	Tambo 1
55	G2	Crash 4	Crash 4
56	G#2	Cowbell	Cowbell
57	A2	Crash 1	Crash 1
58	A#2	Vibraslap	Vibraslap
59	B2	Bassdrum 2	Ride 2
60	C3	Bongo H open	Bongo H open
61	C#3	Bongo L Open	Bongo L Open
62	D3	Conga H Slap	Conga H Slap
63	D#3	Conga H Open	Conga H Open
64	E3	Conga L Open	Conga L Open
65	F3	Timbales High	Timbales High
66	F#3	Timbales Low	Timbales Low
67	G3	Agogo High	Agogo High
68	G#3	Agogo Low	Agogo Low
69	A3	Cabasa	Cabasa
70	A#3	Maracas	Maracas
71	B3	Ayombre	Ayombre
72	C4	Whistle Seq	Whistle Seq
73	C#4	Guiro Short	Guiro Short
74	D4	Guiro Long	Guiro Long
75	D#4	Cadera	Cadera
76	E4	Wood Block High	Wood Block High
77	F4	Wood Block Low	Wood Block Low
78	F#4	Cuica High	Cuica High
79	G4	Yeah	Yeah
80	G#4	Triangle Long	Triangle Long
81	A4	Triangle Short	Triangle Short
82	A#4	Shaker 2	Shaker 2
83	B4	Ride 1	Ride 1
84	C5	Chimes	Chimes
85	C#5		
86	D5		
87	D#5		
88	E5		
89	F5		
90	F#5		
91	G5		
92	G#5		
93	A5		
94	A#5		
95	B5		
96	C6		

MSB-LSB-PRG		104-000-005	104-000-006	104-000-007
Nr.	Note	Eco Normal Kit	Eco Dance Kit	Eco HipHop Kit
13	C#-1	Surdo Mute	Bendir Gum	Bendir Gum
14	D-1	Surdo Open	Bendir Tek 1	Bendir Tek 1
15	D#-1	Hi Q	Bendir Tek 2	Bendir Tek 2
16	E-1	WhipSlap	Bendir Tek 3	Bendir Tek 3
17	F-1	Scratch High	Yeni Zil 1	Yeni Zil 1
18	F#-1	Scratch Low	Yeni Zil 2	Yeni Zil 2
19	G-1	FingerSnap 2	Yeni Zil 3	Yeni Zil 3
20	G#-1	Click Noise	Djembe Slap	Djembe Slap
21	A-1	Metronome Click	Djembe Gum	Djembe Gum
22	A#-1	Metronome Bell	Djembe Tek 1	Djembe Tek 1
23	B-1	Seq Click Low	Djembe Tek 2	Djembe Tek 2
24	C0	Seq Click High	Djembe Tek 3	Djembe Tek 3
25	C#0	Brush Hard	BN Tek 08	BN Tek 08
26	D0	Brush Hit	BN Gum 01	BN Gum 01
27	D#0	Brush Soft	BN Tek 09	BN Tek 09
28	E0	Brush Loop	BN Tek 03	BN Tek 03
29	F0	Snare Roll	BN Tek 10	BN Tek 10
30	F#0	Castanet		
31	G0	Sonor SQ2 CrossStick	Claps 1	Sonor SQ2 CrossStick
32	G#0	CountIn Stick		
33	A0	Kick 3	Kick 3	Timber Kick 01
34	A#0	Funk Snare Rim	Beauty Snare	Funk Snare Rim
35	B0	Kick 2	Kick 2	Timber Kick 02
36	C1	Kick 1	Kick 1	Timber Kick 04
37	C#1	Rimshot	Rimshot	Finger Snap
38	D1	Snare 1	Snare 1	SD Snare 3
39	D#1	Claps	Claps	Claps
40	E1	Snare 2	Eco Snare 1	SD Snare 1
41	F1	Tom 6	Tom 6	Tom 6
42	F#1	Hihat CL	Hihat CL	Hihat CL
43	G1	Tom 5	Tom 5	Tom 5
44	G#1	Hihat Foot	Hihat Foot	Hihat Foot
45	A1	Tom 4	Tom 4	Tom 4
46	A#1	Hihat Open	Hihat Open	Hihat Open
47	B1	Tom 3	Tom 3	Tom 3
48	C2	Tom 2	Tom 2	Tom 2
49	C#2	Crash 1	Crash 1	Crash 1
50	D2	Tom 1	Tom 1	Tom 1
51	D#2	Ride 1	Ride 1	Ride 1
52	E2	Chinese Sabian	Chinese Sabian	Chinese Sabian
53	F2	Ride 1 Bell	Ride 1 Bell	Ride 1 Bell
54	F#2	Tambo 3	Tambo 3	Tambo 3
55	G2	Splash Sabian	Splash Sabian	Splash Sabian
56	G#2	Cow 2 ChaCha Open	Cow 2 ChaCha Open	Cow 2 ChaCha Open
57	A2	Crash 2 Extreme	Crash 2 Extreme	Crash 2 Extreme
58	A#2	Vibraslap	Vibraslap	Vibraslap
59	B2	Ride 2	Ride 2	Ride 2
60	C3	Bongo High	Bongo High	Quanto 1
61	C#3	Quento 5	Quento 5	Quano 2
62	D3	Quento 4	Quento 4	Quanto 3
63	D#3	Quento 1	Bong	Quento 1
64	E3	Quento 2	Quento 2	Quanto Roll
65	F3	Timbales High	Timbales High	Timbales High
66	F#3	Timbales Low	Timbales Low	Timbales Low
67	G3	Agogo High 1	Agogo High 1	Agogo High 1
68	G#3	Agogo Low 1	Agogo Low 1	Agogo Low 1
69	A3	Cabasa 1	Cabasa 1	Cabasa 1
70	A#3	Maracas 1	Maracas 1	Maracas 1
71	B3	Whistle High	Whistle High	Whistle High
72	C4	Whistle Low	Whistle Low	Whistle Low
73	C#4	Guiro Short	Guiro Short	Guiro Short
74	D4	Guiro Long	Guiro Long	Guiro Long
75	D#4	Clave High	Clave High	Clave High
76	E4	Wood Block High	Wood Block High	Wood Block High
77	F4	Wood Block Low	Wood Block Low	Wood Block Low
78	F#4	Cuica High	Cuica High	Cuica High
79	G4	Cuica Low	Cuica Low	Cuica Low
80	G#4	riangle High Short	riangle High Short	riangle High Short
81	A4	Triangle High Long	Triangle High Long	Triangle High Long
82	A#4	Shaker 1 Egg	Shaker 1 Egg	Shaker 1 Egg
83	B4	Tr Shaker 03	Tr Shaker 03	Tr Shaker 03
84	C5	Wind Chimes	Wind Chimes	Wind Chimes
85	C#5	Tumba Slap 01	Tumba Slap 01	Tumba Slap 01
86	D5	Tumba dum 01	Tumba dum 01	Tumba dum 01
87	D#5	Tumba tek 01	Tumba tek 01	Tumba tek 01
88	E5	Djembe gum	Djembe gum	Djembe gum
89	F5	Djembe slap	Djembe slap	Djembe slap
90	F#5	Djembe Tek 01	Djembe Tek 01	Djembe Tek 01
91	G5	Djembe Tek 0	Djembe Tek 0	Djembe Tek 0
92	G#5	Djembe Tek 02	Djembe Tek 02	Djembe Tek 02
93	A5	Djembe Tek 01	Djembe Tek 01	Djembe Tek 01
94	A#5	Djembe Roll	Djembe Roll	Djembe Roll
95	B5	Oleey 1	Oleey 1	Oleey 1
96	C6	Oleey 2	Oleey 2	Oleey 2

MSB-LSB-PRG	104-000-008	104-000-009	104-000-010
Nr.	Note	Eco Latin Kit	JL Standard
13	C#-1	Groove Element 1a	JL Rimshot Reverb
14	D-1	Groove Element 1b	JL March Cymbal
15	D#-1	Groove Element 1c	JL Tambo 2
16	E-1	Groove Element 1d	JL Cave
17	F-1	Groove Element 1e	JL Synthe Drum
18	F#-1	Groove Element 1f	JL WindChimes
19	G-1	Groove Element 1g	JL FingerSnap
20	G#-1	Groove Element 1h	JL M+ve
21	A-1	Groove Element 1i	Castanet
22	A#-1	Groove Element 1j	JL Bells
23	B-1	Noise 1	JL Snare 1
24	C0	Schlager Kick 1	JL Snare Roll
25	C#0	Groove Element 2a	JL Brush Hard
26	D0	Groove Element 2b	JL Cymbal Crescendo
27	D#0	Groove Element 2c	JL Brush Soft
28	E0	Groove Element 2d	JL Brush Loop
29	F0	Groove Element 2e	JL Snare 2
30	F#0	Groove Element 2f	JL Snare 3
31	G0	Schlager Snare 1a	JL March Snare
32	G#0	Schlager Snare 1b	Countln Stick
33	A0	Schlager Kick 1	Jazz Kick V2
34	A#0	Schlager Snare 2	Hihat CL Bright
35	B0	Schlager Kick 2	JL Kick 1
36	C1	Schlager Kick 3	Uni Kick 02
37	C#1	Schlager SideStick	DW Steel CrossStick
38	D1	Schlager Snare 3	Snare Uni 1
39	D#1	Schlager Snare 4	JL Clap Spain
40	E1	Schlager Snare 5	Snare Uni 2
41	F1	Schlager Tom Low 1	JL Tom 6
42	F#1	Schlager HH 1 Closed	JL Hihat CL
43	G1	Schlager Tom Low 2	JL Tom 5
44	G#1	Schlager HH 1 Pedal	JL Hihat Pedal
45	A1	Schlager Tom Mid 1	JL Tom 4
46	A#1	Schlager HH 1 Open	JL Hihat Open
47	B1	Schlager Tom Mid 2	JL Tom 3
48	C2	Schlager Tom High 1	JL Tom 2
49	C#2	Schlager Crash 1	JL Crash 2
50	D2	Schlager Tom High 2	JL Tom 1
51	D#2	Schlager Ride 1	Ride 1
52	E2	Schlager Impact 1	JL Crash 3
53	F2	Schlager Crash Impact	Ride 1 Bell
54	F#2	Tambo	JL Tambo 1
55	G2	Schlager Crash 2	JL Crash 4
56	G#2	Schlager Cowbell	JL Cowbell
57	A2	Schlager Crash 3	JL Crash 1
58	A#2	Schlager Snare 6	JL Vibraslap
59	B2	Schlager Snare 7	Ride 2
60	C3	Schlager Snare 8	Bongo H open
61	C#3	Schlager Snare 9	Bongo L Open
62	D3	Schlager Snare 10	Conga H Slap
63	D#3	Schlager Clap 1	Conga H Open
64	E3	Schlager Clap 2	Conga L Open
65	F3	Schlager Clap 3	Timbales High
66	F#3	Schlager Clap 4	Timbales Low
67	G3	Schlager Clap 5	Agogo High
68	G#3	Schlager Clap 6	Agogo Low
69	A3	Schlager Shaker 1	JL Cabasa 1
70	A#3	Schlager Shaker 2	JL Maracas
71	B3	Schlager Clap 7	Whistle High
72	C4	Schlager Shot 1	Whistle Low
73	C#4	Schlager Shot 2	JL Guiro Short
74	D4	Schlager Shot 3	JL Guiro Long
75	D#4	Schlager Shot 4	JL Power Snare
76	E4	Schlager HH 2a Closed	Wood Block High
77	F4	Schlager HH 2b Closed	Wood Block Low
78	F#4	Schlager HH 2c Closed	Cuica High
79	G4	Schlager HH 2 Open	JL Chimes Slow
80	G#4	Schlager Shaker 3	JL Triangle Short
81	A4	Schlager Shaker 4	JL Triangle Long
82	A#4	Schlager Shaker 5	JL Cabasa 1
83	B4	Schlager Shaker 6	Sleighbells
84	C5	Schlager Reverse 1	JL Chimes
85	C#5	Schlager Reverse 2	
86	D5	Schlager Reverse Snare	
87	D#5	Schlager Long Snare	
88	E5	Schlager Groove 2 Kick	
89	F5	Schlager Groove 2a HH	
90	F#5	Schlager Groove 2 Snare	
91	G5	Schlager Groove 2 HHb	
92	G#5	Djembe Tek 02	
93	A5	Djembe Tek 01	
94	A#5	Djembe Roll	
95	B5	Oleey 1	
96	C6	Oleey 2	

MSB-LSB-PRG	104-000-011	104-000-012	104-000-013
Nr.	Note		
13	C#-1	Groove Element 1a	Pop Kit
14	D-1	Groove Element 1b	Pop HH Tip a
15	D#-1	Groove Element 1c	Pop HH Edge a
16	E-1	Groove Element 1d	Pop HH Edge b
17	F-1	Groove Element 1e	Pop HH Edge c
18	F#-1	Groove Element 1f	Pop HH Edge d
19	G-1	Groove Element 1g	Pop HH Edge e
20	G#-1	Groove Element 1h	Pop HH Edge f
21	A-1	Groove Element 1i	Pop HH Pedal
22	A#-1	Groove Element 1j	Pop HH Pedal Splash
23	B-1	Noise 1	Seq Click L
24	C0	Schlager Kick 1	Seq Click H
25	C#0	Groove Element 2a	Pop Snare Brush
26	D0	Groove Element 2b	Pop Snare 1 noRim
27	D#0	Groove Element 2c	Pop Snare 2 noRim
28	E0	Groove Element 2d	Pop Snare 3 noRim
29	F0	Groove Element 2e	Pop Snare Roll
30	F#0	Groove Element 2f	Pop Snare 1
31	G0	Schlager Snare 1a	Pop Snare 2
32	G#0	Schlager Snare 1b	Countln Stick
33	A0	Schlager Kick 1	Pop Kick 1
34	A#0	Schlager Snare 2	Pop Snare 3 Rim
35	B0	Schlager Kick 2	Pop Kick 2
36	C1	Schlager Kick 3	Pop Kick 3
37	C#1	Schlager SideStick	Pop Snare 4 SideStick
38	D1	Schlager Snare 3	Pop Snare 4
39	D#1	Schlager Snare 4	Power Claps
40	E1	Schlager Snare 5	Pop Snare 3
41	F1	Schlager Tom Low 1	Pop Tom Low <
42	F#1	Schlager HH 1 Closed	Pop HH Edge a
43	G1	Schlager Tom Low 2	Pop Tom Low >
44	G#1	Schlager HH 1 Pedal	Pop HH Pedal
45	A1	Schlager Tom Mid 1	Pop Tom Mid <
46	A#1	Schlager HH 1 Open	Pop HH Edge e
47	B1	Schlager Tom Mid 2	Pop Tom Mid >
48	C2	Schlager Tom High 1	Pop Tom High <
49	C#2	Schlager Crash 1	Crash 1 Medium
50	D2	Schlager Tom High 2	Pop Tom High >
51	D#2	Schlager Ride 1	Ride 1
52	E2	Schlager Impact 1	Pop China Crash
53	F2	Schlager Crash Impact	Ride 1 Bell
54	F#2	Tambo	Tambo 2
55	G2	Schlager Crash 2	Splash Sabian
56	G#2	Schlager Cowbell	Cow 3 Low Open
57	A2	Schlager Crash 3	Rock Crash 1
58	A#2	Schlager Snare 6	Vibraslap
59	B2	Schlager Snare 7	Pop Ride
60	C3	Schlager Snare 8	Bongo Stick High
61	C#3	Schlager Snare 9	Bongo Stick Low
62	D3	Schlager Snare 10	Conga 2 High Mute
63	D#3	Schlager Clap 1	Conga 2 High Open
64	E3	Schlager Clap 2	Conga Low
65	F3	Schlager Clap 3	Timbales High
66	F#3	Schlager Clap 4	Timbales Low
67	G3	Schlager Clap 5	Agogo High 1
68	G#3	Schlager Clap 6	Agogo Low 1
69	A3	Schlager Shaker 1	Cabasa 3
70	A#3	Schlager Shaker 2	Maracas 2
71	B3	Schlager Clap 7	Whistle High
72	C4	Schlager Shot 1	Whistle Low
73	C#4	Schlager Shot 2	Guiro Short
74	D4	Schlager Shot 3	Guiro Long
75	D#4	Schlager Shot 4	Clave High
76	E4	Schlager HH 2a Closed	Wood Block High
77	F4	Schlager HH 2b Closed	Wood Block Low
78	F#4	Schlager HH 2c Closed	Cuica High
79	G4	Schlager HH 2 Open	Cuica Low
80	G#4	Schlager Shaker 3	Triangle High Short
81	A4	Schlager Shaker 4	Triangle High Long
82	A#4	Schlager Shaker 5	Shaker 2
83	B4	Schlager Shaker 6	Sleighbells
84	C5	Schlager Reverse 1	Wind Chimes
85	C#5	Schlager Reverse 2	
86	D5	Schlager Reverse Snare	
87	D#5	Sc+ager Long Snare	
88	E5	Schlager Groove 2 Kick	
89	F5	Schlager Groove 2 HH	
90	F#5	Schlager Groove 2 Snare	
91	G5	Schlager Groove 2 HHb	

MSB-LSB-PRG	104-000-014	104-000-015	104-000-016
Nr.	Note		
13	C#-1	Vintage 2 HH Tip a	80sPopKit 1
14	D-1	Vintage 2 HH Edge a	80sPop 1 HH a Closed
15	D#-1	Vintage 2 HH Tip b	80sPop 1 HH b Closed
16	E-1	Vintage 2 HH Edge b	80sPop 1 HH b Open
17	F-1	Vintage 2 HH Edge c	80sPop 1 HH c Closed
18	F#-1	Vintage 2 HH Edge d	80sPop 1 HH c Open
19	G-1	Vintage 2 HH Edge e	80sPop 1 Clap 1
20	G#-1	Vintage 2 HH Edge f	80sPop 1 Clap 2
21	A-1	Vintage 2 HH Pedal	Metronom 1
22	A#-1	Vintage 2 HH Pedal Splash	Metronom 2
23	B-1	Seq Click L	80sPop 1 SideStick 1
24	C0	Seq Click H	80sPop 1 Kick 1
25	C#0	Vintage 2 Tambo Stick	80sPop 1 SideStick 2
26	D0	Vintage 2 Snare 1 noRim	80sPop 1 Clap 3
27	D#0	Vintage 2 Snare 2 noRim	80sPop 1 Clap 4
28	E0	Vintage 2 Snare 3 noRim	80sPop 1 SideStick 3
29	F0	Pop Snare Roll	80sPop 1 SideStick 4
30	F#0	Vintage 2 Snare 2	80sPop 1 Snare 3
31	G0	Vintage 2 Snare 3	80sPop 1 Snare 2
32	G#0	Countin Stick	80sPop 1 Snare 1
33	A0	Vintage 2 Kick 1	80sPop 1 Kick 1
34	A#0	Vintage 2 Snare 3 Rim	80sPop 1 Snare 4
35	B0	Vintage 2 Kick 2	80sPop 1 Kick 2
36	C1	Vintage 2 Kick 3	80sPop 1 Kick 3
37	C#1	Vintage 2 Snare 4 SideStick	80sPop 1 SideStick 2
38	D1	Vintage 2 Snare 4	80sPop 1 Snare 5
39	D#1	Power Claps	80sPop 1 Clap 1
40	E1	Vintage 2 Snare 3	80sPop 1 Snare 6
41	F1	Vintage 2 Tom Low <	80sPop 1 Tom Low <
42	F#1	Vintage 2 HH Edge a	80sPop 1 HH c closed
43	G1	Vintage 2 Tom Low >	80sPop 1 Tom Low >
44	G#1	Vintage 2 HH Pedal	80sPop 1 HH Pedal
45	A1	Vintage 2 Tom Mid <	80sPop 1 Tom Mid <
46	A#1	Vintage 2 HH Edge e	80sPop 1 HH c Open
47	B1	Vintage 2 Tom Mid >	80sPop 1 Tom Mid >
48	C2	Vintage 2 Tom High <	80sPop 1 Tom High <
49	C#2	Vintage 2 Crash 1	80sPop 1 Crash 1
50	D2	Vintage 2 Tom High >	80sPop 1 Tom High >
51	D#2	Vintage 2 Ride 1	80sPop 1 Ride 1
52	E2	Vintage 2 China Crash	80sPop 1 China Crash
53	F2	Vintage 2 Ride 1 Bell	80sPop 1 Ride 1 Bell
54	F#2	Tambo 2	80sPop 1 Tambo
55	G2	Vintage 2 Splash	80sPop 1 Splash
56	G#2	Cow 3 Low Open	80sPop 1 Cowbell 1
57	A2	Vintage 2 Crash 2	80sPop Crash 2
58	A#2	Vibraslap	Vibraslap
59	B2	Vintage 2 Ride 2	80sPop Ride 2
60	C3	Bongo Stick High	80sPop 1 Bonga High
61	C#3	Bongo Stick Low	80sPop 1 Bongo Low
62	D3	Conga 2 High Mute	80sPop 1 Conga Mute
63	D#3	Conga 2 High Open	80sPop 1 Conga High
64	E3	Conga Low	80sPop 1 Conga Low
65	F3	Timbales High	Timbales High
66	F#3	Timbales Low	Timbales Low
67	G3	Agogo High 1	80sPop 1 Agogo High
68	G#3	Agogo Low 1	80sPop 1 Agogo low
69	A3	Cabasa 3	80sPop 1 Cabasa 1
70	A#3	Maracas 2	80sPop 1 Tom 2a
71	B3	Whistle High	80sPop 1 Tom 2b
72	C4	Whistle Low	80sPop 1 Tom 2c
73	C#4	Guiro Short	80sPop 1 Tom 2d
74	D4	Guiro Long	80sPop 1 Tom 2e
75	D#4	Clave High	80sPop Claves
76	E4	Wood Block High	80sPop 1 Tom 3a
77	F4	Wood Block Low	80sPop 1 Tom 3b
78	F#4	Cuica High	80sPop 1 Tom 3c
79	G4	Cuica Low	80sPop 1 Tom 3d
80	G#4	Triangle High Short	80sPop 1 Tom 3e
81	A4	Triangle High Long	80sPop 1 Tom 3e
82	A#4	Shaker 2	80sPop 1 Cabasa 2
83	B4	Sleighbells	Sleighbells
84	C5	Wind Chimes	Wind Chimes
85	C#5		80sPop 1 Tom 4a
86	D5		80sPop 1 Tom 4b
87	D#5		80sPop 1 Tom 4c
88	E5		80sPop 1 Tom 4d
89	F5		80sPop 1 Tom 4e
90	F#5		80sPop 1 Tom 4e
91	G5		80sPop 1 Tom 4e

MSB-LSB-PRG		104-000-017	104-000-018	104-000-019
Nr.	Note	Rock Kit 2	Rock Kit 3	RealDrum Kit
13	C#-1	Surdo Mute	Rock 3 HH Tip a	Surdo Mute
14	D-1	Surdo Open	Rock 3 HH Edge a	Surdo Open
15	D#-1	Hi Q	Rock 3 HH Tip b	Hi Q
16	E-1	WhipSlap	Rock 3 HH Edge b	WhipSlap
17	F-1	Scratch High	Rock 3 HH Edge c	Scratch High
18	F#-1	Scratch Low	Rock 3 HH Edge d	Scratch Low
19	G-1	FingerSnap 1	Rock 3 HH Edge e	FingerSnap 1
20	G#-1	Click Noise	Rock 3 HH Edge f	Click Noise
21	A-1	Metronome Click	Rock 3 HH Pedal	Metronom Click
22	A#-1	Metronome Bell	Rock 3 HH Pledal Splash	Metronom Bell
23	B-1	Seq Click Low	Seq Click Low	Seq Click Low
24	C0	Seq Click High	Seq Click High	Seq Click High
25	C#0	Brush SP Snare 1	Rock 3 Snare Brush	Brush SP Snare 1
26	D0	Brush SP Snare Swirl	Rock 3 Snare 1 noRim	Brush SP Snare Swirl
27	D#0	Brush SP Snare 2	Rock 3 Snare 2 noRim	Brush SP Snare 2
28	E0	Brush SP Snare Mute	Rock 3 Snare 3 noRim	Brush SP Snare Mute
29	F0	Snare Roll	Rock 3 Snare Roll	Snare Roll
30	F#0	Castanet	Rock 3 Snare 1	Castanet
31	G0	Snare Uni 3	Rock 3 Snare 2	Real Snare Tight
32	G#0	Countin Stick	Rock 3 Stick Count	Countin Stick
33	A0	Heavy Kick V1	Rock 3 Kick 1	Real Kick 1
34	A#0	Funk Snare Rim	Rock 3 Snare 3 openRim	Real Snare Rim
35	B0	Rock Kick V1	Rock 3 Kick 2	Real Kick 2
36	C1	Rock Kick V2	Rock 3 Kick 3	Real Kick 3
37	C#1	Rock Snare CrossStick	Rock 3 Snare 4	Real Snare CrossStick
38	D1	Rock Snare	Rock 3 Snare 4	Real Snare 1
39	D#1	Claps 1	Power Claps	Real Claps
40	E1	Snare Ludwig Beauty	Rock 3 Snare 3	Real Snare 2
41	F1	Rock16 Tom <	Rock 3 Tom Low <	Real Tom Low <
42	F#1	Hihat Heavy CL	Rock 3 HH Edge	Real HH Closed
43	G1	Rock16 Tom >	Rock 3 Tom Low >	Real Tom Low >
44	G#1	Hihat Heavy Pedal	Rock 3 HH Pedal	Real HH Pedal
45	A1	Rock14 Tom	Rock 3 Mid <	Real Tom Mid <
46	A#1	Hihat Heavy Open	Rock 3 HH Open	Real HH Open
47	B1	Rock12 Tom	Rock 3 Mid >	Real Tom Mid >
48	C2	Rock10 Tom <	Rock 3 High <	Real Rom High <
49	C#2	Rock Crash 1	Rock 3 Crash 1	Real Crash 1
50	D2	Rock10 Tom >	Rock 3 High >	Real Tom High >
51	D#2	Groove Ride	Rock 3 Ride 1	Real Ride 1
52	E2	Chinese Sabian	Rock 3 China Crash	Real China Crash
53	F2	Groove Ride Bell	Rock 3 Ride 1 Bell	Real Ride Bell
54	F#2	Tambo 3	Tambo 2	Tambo 3
55	G2	Rock Splash	Rock 3 Splash	Real Splash
56	G#2	Cow 3 Low Open	Cow 3 Low Open	Cowbell 1 Open
57	A2	Rock Crash 2	Rock 3 Crash 2	Real Crash 2
58	A#2	Vibraslap	Vibraslap	Vibraslap
59	B2	Ride Modern	Rock 3 Ride 2	Real Ride 2
60	C3	Bongo Stick High	Bongo Stick High	Bongo Stick High
61	C#3	Bongo Stick Low	Bongo Stick Low	Bongo Stick Low
62	D3	Conga 2 High Mute	Conga 2 High Mute	Conga 2 High Mute
63	D#3	Conga 2 High Open	Conga 2 High Open	Conga 2 High Open
64	E3	Conga Low	Conga Low	Conga Low
65	F3	Timbales High	Timbales High	Timbales High
66	F#3	Timbales Low	Timbales Low	Timbales Low
67	G3	Agogo High 1	Agogo High 1	Agogo High 1
68	G#3	Agogo Low 1	Agogo Low 1	Agogo Low 1
69	A3	Cabasa 3	Cabasa 3	Cabasa 3
70	A#3	Maracas 2	Maracas 2	Maracas 2
71	B3	Whistle High	Whistle High	Whistle High
72	C4	Whistle Low	Whistle Low	Whistle Low
73	C#4	Guiro Short	Guiro Short	Guiro Short
74	D4	Guiro Long	Guiro Long	Guiro Long
75	D#4	Clave High	Clave High	Clave High
76	E4	Wood Block High	Wood Block High	Wood Block High
77	F4	Wood Block Low	Wood Block Low	Wood Block Low
78	F#4	Cuica High	Cuica High	Cuica High
79	G4	Cuica Low	Cuica Low	Cuica Low
80	G#4	Triangle High Short	Triangle High Short	Triangle High Short
81	A4	Triangle High Long	Triangle High Long	Triangle High Long
82	A#4	Shaker 2	Shaker 2	Shaker 2
83	B4	Sleighbells	Sleighbells	Sleighbells
84	C5	Wind Chimes	Wind Chimes	Wind Chimes
85	C#5			
86	D5			
87	D#5			
88	E5			
89	F5			
90	F#5			
91	G5			

MSB-LSB-PRG	104-000-020	104-000-021	104-000-022
Nr.	Note	HipHop Kit 1	HipHop Kit 2
13	C#-1	Surdo Mute	Surdo Mute
14	D-1	Surdo Open	Surdo Open
15	D#-1	Hi Q	Hi Q
16	E-1	WhipSlap	WhipSlap
17	F-1	Scratch High	Scratch High
18	F#-1	Scratch Low	Scratch Low
19	G-1	T8 HH Closed 1	FingerSnap 1
20	G#-1	T8 Tom 3	Break Snare 1
21	A-1	T8 HH Open 1	Break Snare2
22	A#-1	T8 Tom 6	Break HH Closed 1
23	B-1	T8 Crash	Break HH Closed 2
24	C0	Triangle Mute	Break Deep Kick
25	C#0	Triangle Open	Hip Snare
26	D0	Wind Chime	LoFi Snare
27	D#0	Tambo Light 2	Clappy Snare
28	E0	Tambo Light 1	Mono Snare
29	F0	HipHop Kick 1	Snare Roll
30	F#0	Tek HH Closed	Gate Snare 1
31	G0	Gate Kick	Mid Snare
32	G#0	LoFi HH Open	Break Snare Rim
33	A0	GranCasa Kick	Break Kick Heavy
34	A#0	Drum&Bass HH Reverse	Hip Snare Rim 1
35	B0	HipHop Kick 2	Break Kick 1
36	C1	Analog CF Kick	Break Kick 2
37	C#1	Analog Snare Rim	Hip Snare Rim 2
38	D1	HipHop Snare 1	Break Snare 1
39	D#1	Clappy Snare	Break Snare 2
40	E1	HipHop Snare 2	Break Snare 3
41	F1	Floor Tom 1	Break Tom 1
42	F#1	HipHop HH closed	Rock HH Closed Soft
43	G1	Low Tom	Break Tom 2
44	G#1	HipHop HH Pedal	Rock HH Pedal
45	A1	Mid Tom <	Break Tom 3
46	A#1	HipHop HH open	Rock HH Open
47	B1	High Tom	Break Tom 4
48	C2	Ride Cymbal 1	Break Tom 5
49	C#2	Crash Cymbal 1	Break Tom 6
50	D2	Shaker 1	Break Tom 7
51	D#2	Scratch Forward	Ride Cymbal 1
52	E2	Scratch Reverse	Crash China
53	F2	HipHop Kick 3	Ride Cymbal 1 Cup
54	F#2	HipHop Snare Rim 1	Tambo Hit
55	G2	HipHop Clap 1	Splash Cymbal
56	G#2	HipHop Snap 1	Cowbell
57	A2	HipHop Snare 3	Crash Cymbal 2
58	A#2	Electric Clap 1	Cowbell RX
59	B2	Hi Deep Kock	Ride Cymbal 2
60	C3	HipHop Kick 4	Bongo 1 High
61	C#3	HipHop Snare Rim 2	Bongo 1 Low
62	D3	HipHop Snare 4	Conga High Tip
63	D#3	Electric Clap 2	Conga High Open Slap
64	E3	Handbell High	Conha High Open
65	F3	HipHop Kick 5	Bongo 2 High
66	F#3	HipHop Clap 2	Bongo 2 Low
67	G3	HipHop Snap 2	Conga Open
68	G#3	HipHop Snare Rim 3	Agogo Low
69	A3	HipHop Flex 1	Agogo High
70	A#3	HipHop Flex 2	Maracas Slur
71	B3	Shaker 2	Timbales High
72	C4	HipHop Kick 6	Timbales Low
73	C#4	HipHop Snare Rim 4	Scratch 1 High
74	D4	HipHop Snare 5	Scratch 1 Down
75	D#4	HipHop Snare 6	Claves
76	E4	HipHop Kick7	Woodblock High
77	F4	HipHop Snare 7	Woodblock Low
78	F#4	HipHop Clap 3	Scratch 2 High
79	G4	Conga High Tip	Scratch 2 Low
80	G#4	Conga High Heel	Triangle Mute
81	A4	Conga High Open	Triangle Open
82	A#4	Conga Low Open 1	Break Kick 3
83	B4	Conga Low Open 2	Break Kick 4
84	C5	HipHop Kick 8	Break Kick 5
85	C#5	HipHop Clap 4	Break Kick 6
86	D5	T8 Snare 1	Break Kick 7
87	D#5	T8 Snare 2	Break HH Closed 3
88	E5	HipHop Clap 4	Break Snare 4
89	F5	T8 Tom 1	Break Snare 5
90	F#5	T8 HH Closed 2	Break Snare 6
91	G5	T8 Tom 2	Break Snare 7

MSB-LSB-PRG		104-000-023	104-000-024	104-000-025
Nr.	Note	T9 Analog Kit	House Kit	Electro Machine Kit
13	C#-1	Surdo Mute	W Kick	Surdo Mute
14	D-1	Surdo Open	Disco FX	Surdo Open
15	D#-1	Hi Q	White Noise Down 1	Hi Q
16	E-1	WhipSlap	Pink Noise Down 1	WhipSlap
17	F-1	Scratch High	Wite Noise Down 2	Scratch High
18	F#-1	Scratch Low	Pink Noise Down 2	Scratch Low
19	G-1	Drum&Bass Snare 1	White Noise Up 1	Drum&Bass Snare 1
20	G#-1	Break Kick 1	White Noise Up 2	Break Kick 1
21	A-1	Distortion Snare	Pink Noise Up	Distortion Snare
22	A#-1	Tek Kick Power	White Noise up Release	Tek Kick Power
23	B-1	RM Distortion Kick	Pinkt Noise Up Release	RM Distortion Kick
24	C0	T9 Kick 1	T9 Kick 1	Kick Hard Long
25	C#0	Analog SR Snare	T8 Snare Rim	Tek Kick Power
26	D0	T9 Snare 2	T8 Snare 1	Distortion Kick 1
27	D#0	Analog Clap SM	Hand Clap	Distortion Kick 2
28	E0	T9 Snare Gate	Garg Snare Low	Distortion Kick 3
29	F0	Snare Roll	Snare Roll	Drum&Bass Kick
30	F#0	T9 Snare 3	T9 Snare 1	Blip Kick
31	G0	T9 Snare 4	T8 Snare 2	Analog Kick SM
32	G#0	T9 Snare Gate	T9 Snare 2	T8 Kick 1
33	A0	T9 Kick 2	T9 Kick 2	T8 Kick 2
34	A#0	T9 Snare 5	T9 Snare Gate	T9 Kick HD
35	B0	T9 Kick 3	T9 Kick 3	T9 Kick 1
36	C1	T9 Kick 4	T9 Kick 4	T9 Kick 2
37	C#1	T9 Snare Rim	T9 Snare Rim	T9 Snare Rim
38	D1	T9 Snare 6	T9 Snare 3	T9 Snare 1
39	D#1	T9 Clap	T9 Clap	T9 Clap
40	E1	T9 Snare 7	T9 Snare 4	T9 Snare 4
41	F1	T9 Tom 1	T9 Tom 1	T9 Tom 1
42	F#1	T9 HH Closed	T9 HH Closed	T9 HH Closed
43	G1	T9 Tom 2	T9 Tom 2	T9 Tom 2
44	G#1	T9 HH Pedal	T9 HH Pedal	T9 HH Pedal
45	A1	T9 Tom 3	T9 Tom 3	T9 Tom 3
46	A#1	T9 HH Open	T9 HH open	T9 HH open
47	B1	T9 Tom 4	T9 Tom 4	T9 Tom 4
48	C2	T9 Tom 5	T9 Tom 5	T9 Tom 5
49	C#2	T9 Crash Cymbal	T9 Crash Cymbal	T9 Crash Cymbal
50	D2	T9 Tom 6	T9 Tom 6	T8 Conga 2
51	D#2	T9 Ride Cymbal	T9 Ride Cymbal	T9 Ride Cymbal
52	E2	Crash China	Crash China	T8 Conga 2
53	F2	Ride Cymbal Cup	Ride Cymbal Cup	Analog Click
54	F#2	RX Tambo	Tambo Hit	T8 Claves 1
55	G2	Splash Cymbal	Splash Cymbal	T8 Maracas
56	G#2	Cowbell	Cowbell	Analog Tambo CR
57	A2	Crash Cymbal	Crash Cymbal	Analog Shaker
58	A#2	T8 Cowbell	T8 Cowbell	T8 Cowbell
59	B2	Ride Cymbal	Ride Cymbal	Analog Cowbell CR
60	C3	T8 Conga 1	Bongo High OneFinger	T8 Snare 1
61	C#3	T8 Conga 2	Bongo Low ThreeFinger	T8 Snare 2
62	D3	Conga Tip	Conga High Tip	T8 Snare 3
63	D#3	Conga Open Slap	Conga Open Slap	Analog Snare CR
64	E3	Conga Open	Conga 2 Open	Jungle Snare
65	F3	Timbales High	Timbales High	Drum&Bass Snare 2
66	F#3	Timbales Low	Timbales Low	Hip Snare
67	G3	Analog Click	Agogo High 1	R&B Snare 1
68	G#3	T8 Conga 3	Agogo Low 1	R&B Snare 2
69	A3	Cabasa	Cabasa	R&B Snare 3
70	A#3	Slur Maracas	Slur Maracas	Wood Snare
71	B3	FX Gun 1	Vox Drum Low	Timbre Snare
72	C4	FX Gun 2	Vox Drum High	T8 HH Closed 1
73	C#4	Scratch 1 High	Guiro Short	T8 HH Open 1
74	D4	Scratch 1 Down	Guiro Long	T8 HH Closed 2
75	D#4	Hi Q 1	Claves	T8 HH open 2
76	E4	Hi Q 2	Woodblock High	Acoustic HH Pedal
77	F4	Hi Q 3	Woodblock Low	Acoustic HH Closed
78	F#4	Scratch 2 High	Cuica High	Acoustik HH Open
79	G4	Scratch 2 Low	Cuica Low	LoFi HH Closed
80	G#4	Triangle Mute	Triangle Mute	LoFi HH Open
81	A4	Triangle Open	Triangle Open	Syn HH Closed
82	A#4	Analog Shaker	Analog Shaker	Syn HH Open
83	B4	Sleighbells	Sleighbells	Analog Shaker
84	C5	Wind Chimes	Wind Chimes	RX Tambo
85	C#5	Piccolo Snare	Break Snare Roll	Tambo Hit
86	D5	T8 Snare 8	Noise Burst	Electric Cowbell
87	D#5	Distortion Snare Roll	Vox Bell	T8 Conga 1
88	E5	Brush Snare Mute	R&B Snare	Electric Triangle
89	F5	Blip Kick Hard	Vox Alk	T8 Claves 2
90	F#5	Jungle Snare	Udu High	Analog Shaker
91	G5	Sustain Kick	Filter Kick	Electric Clap

MSB-LSB-PRG	104-000-026	104-000-027	104-000-028	
Nr.	Note	Electronic Dance 1	Electronic Dance Kit 2	Electronic Dance 3
13	C#-1	EK1 Kick 1	EK2 Kick 1	EK3 Kick 1
14	D-1	EK1 Kick 2	EK2 Kick 2	EK3 Kick 2
15	D#-1	EK1 Digital	EK2 Glitch 1	EK3 SFX 1
16	E-1	Pink Noise Down 1	EK2 Snare 1	EK3 SFX 2
17	F-1	White Noise Dwon	EK2 Snare 2	EK3 Kick 3
18	F#-1	Pink Noise Down 2	EK2 Snare 3	EK3 Kick 4
19	G-1	EK1 Boomer	White noise Up	EK SFX 3
20	G#-1	EK1 Synth Crash	EK2 Glitch 2	EK3 SFX 4
21	A-1	EK1 Bouncer	EK2 Bump	EK3 SF5 5
22	A#-1	EK1 Thin Cowbell	EK2 Reverse shot	EK3 SFX 6
23	B-1	EK1 Snare Flanger Rev	EK2 Glitch 3	EK3 SF7 7
24	C0	EK1 Kick 3	EK2 Kick 3	EK3 Kick 5
25	C#0	EK1 Snare 1	EK2 Snare 4	EK3 Snare 1
26	D0	EK1 Clap 1	EK2 Snare 5	EK3 Snare 2
27	D#0	EK1 Snare 2	EK2 Snare 6	EK3 Clap 1
28	E0	EK1 Snare 3	EK2 Snare 7	EK3 Snare 3
29	F0	EK1 Snare 4	EK2 Reverse Hit	EK3 Snare 4
30	F#0	T9 Snare	EK2 Snare 8	EK3 Snare 5
31	G0	EK1 Snare 5	EK2 Snare 9	EK3 Snare 6
32	G#0	EK1 Clap 2	EK2 Snare 10	EK3 Clap 2
33	A0	EK1 Kick 4	EK2 Kick 4	EK3 Kick 6
34	A#0	EK1 Clap 3	E Snare 11	EK3 Clap 3
35	B0	EK1 Kick 5	EK2 Kick 5	EK3 Kick 7
36	C1	EK1 Kick 6	EK2 Kick 6	EK3 Kick 8
37	C#1	EK1 Snare Rimshot	EK2 Thumb	EK3 Rimshot
38	D1	EK1 Snare 6	EK2 Snare 12	EK3 Snare 7
39	D#1	EK1 Clap 4	EK2 Clap 1	EK3 Claps 4
40	E1	EK1 Snare 7	EK2 Snare 13	EK3 Snare T9
41	F1	T9 Tom 1	EK2 Tom 3	EK3 Tom 1
42	F#1	EK1 HH Closed 1	EK2 HH Closed 1	EK3 HH Closed 1
43	G1	T9 Tom 2	EK2 Tom 3	EK3 Tom 2
44	G#1	EK1 HH Pedal	EK2 HH Shrank	EK4 HH Closed 2
45	A1	T9 Tom 3	EK2 Tom 3	EK3 Tom 3
46	A#1	EK1 HH open 1	EK2 HH Open 1	EK3 HH Open 1
47	B1	T9 Tom 4	EK2 Tom 4	EK3 Tom 4
48	C2	T9 Tom 5	EK2 Tom 5	EK3 Tom 5
49	C#2	T9 Crash Cymbal	T9 Crash Cymbal	T9 Crash Cymbal
50	D2	T9 Tom 6	EK2 Tom 6	EK Tom 5
51	D#2	T9 Ride Cymbal	EK2 Ride Shrank	T9 Ride Cymbal
52	E2	Crash Cymbal 1	Crash Cymbal 1	Crash Cymbal 1
53	F2	Ride Cymbal Cup	Ride Cymbal Cup	Ride Cymbal Cup
54	F#2	Tambo 82	Tambo Hit	Tambo 82
55	G2	Splash Cymbal	Splash Cymbal	Splash Cymbal
56	G#2	Cowbell 82	Cowbell	Cowbell 80
57	A2	Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2
58	A#2	T8 Cowbell	T8 Cowbell	T8 Cowbell
59	B2	Ride Cymbal	Ride Cymbal	Ride Cymbal
60	C3	Bongo High 82	Bongo High OneFinger	Bongo High 80
61	C#3	Bongo Low 82	Bongo Low ThreeFinger	Bongo Low 80
62	D3	Conga Mute 82	Conga High Tip	Conga Mute 80
63	D#3	Conga High 82	Conga Open Slap	Conga High 80
64	E3	Conga Low 82	Conga 2 Open	Conga Low 80
65	F3	Timbales High	Timbales High	Timbales High
66	F#3	Timbales Low	Timbales Low	Timbales Low
67	G3	Cowbell High Pitch 82	Agogo High 1	Agogo High 80
68	G#3	Cowbell Middle Pitch 82	Agogo Low 1	Agogo Low 80
69	A3	Cabasa 81	Cabasa	Cabasa 80
70	A#3	Slur Maracas	Slur Maracas	Cabasa 81
71	B3	Vox Low	Vox Low	Vox Low
72	C4	Vox High	Vox High	Vox High
73	C#4	Guiro Short	Guiro Short	EK3 SFX 8
74	D4	Guiro Long	Guiro Long	EK3 SFX 9
75	D#4	Claves 83	Claves	EK3 SFX 10
76	E4	Woodblock High	EK2 Clap 2	EK3 SFX 11
77	F4	Woodblock Low	EK2 Clap 3	EK3 SFX 12
78	F#4	EK1 HH Closed 2	EK2 HH Closed 2	EK3 Clap 5
79	G4	EK1 HH Closed 3	EK2 HH Open 2	EK3 Clap 6
80	G#4	Triangle Mute	EK2 HH Closed 3	EK3 HH Open 2
81	A4	Triangle Open	EK2 HH Open 3	EK3 HH Open 3
82	A#4	EK1 HH open 2	EK2 Kick 7	EK3 HH open 4
83	B4	EK1 Kick 7	EK2 Kick 8	EK3 Kick 9
84	C5	EK1 Kick 8	EK2 Kick 9	EK3 Kick 10
85	C#5	EK1 Kick 9	EK2 Kick 10	EK3 Kick 11
86	D5	EK1 Kick 10	EK2 Tom Fill	EK3 Kick 12
87	D#5	EK1 Snare 8	EK2 Snare Fill	EK3 Snare 8
88	E5	EK1 Snare 9	EK2 Snare 14	EK3 Snare 9
89	F5	EK1 Snare 10	EK2 Snare 15	EK3 Snare 10
90	F#5	EK1 Snare 11	EK2 Impact Low	EK3 Snare 11
91	G5	EK1 Filter Kick	EK2 Impact High	EK3 Kick Filter

MSB-LSB-PRG	104-000-029	104-000-030	104-000-031
Nr.	Note	Electronic Dance 4 Kit	Brush Kit 2
13	C#-1	EK4 Kick 1	Surdo Mute
14	D-1	EK4 Kick 2	Surdo Open
15	D#-1	White Noise Down 1	Hi Q
16	E-1	Pink Noise Down 1	WhipSlap
17	F-1	White Noise Down 2	Scratch High
18	F#-1	Pink Noise Down 2	Scratch Low
19	G-1	EK4 Finger Snap 1	FingerSnap 1
20	G#-1	EK4 Fingersnap 2	Click Noise
21	A-1	EK4 SFX 1	Metronome Click
22	A#-1	EK4 SFX 2	Metronome Bell
23	B-1	EK4 SFX 3	Brush 2 Snare Sweep Short 1
24	C0	EK4 Kick 2	Brush 2 Snare Sweep Short 2
25	C#0	EK4 Snare 1	Brush 2 Snare Snappy Off
26	D0	EK4 Clap 1	Brush 2 Snare Swirl Loop 1
27	D#0	EK4 Clap 83	Brush 2 Snare Pressed
28	E0	EK4 Snare 2	Brush 2 Snare Swirl Loop 2
29	F0	EK4 Snare 3	Brush 2 Snare Swirl Loop 3
30	F#0	EK4 T9	Brush 2 Snare Dynanik Sweep
31	G0	EK4 Snare 4	Brush 2 Snare Pressed Low
32	G#0	EK4 Clap 2	CountIn Stick
33	A0	EK4 Kick 3	Brush 2 Kick 1
34	A#0	EK4 Clap 3	Brush 2 Snare Mute
35	B0	EK4 Kick 4	Brush 2 Kick 2
36	C1	EK4 Kick 5	Brush 2 Kick 3
37	C#1	EK4 Rimshot	Brush 2 Snare Rimshot
38	D1	EK4 Snare 5	Brush 2 Snare Brush 1
39	D#1	EK4 Clap 4	Clap Power
40	E1	EK4 Snare 6	Brush 2 Snare 2
41	F1	EK4 Tom 1	Brush 2 Tom 1
42	F#1	EK4 HH Closed 1	Brush 2 HH Closed
43	G1	EK4 Tom 2	Brush 2 Tom 2
44	G#1	EK4 HH Closed 2	Brush 2 HH Pedal
45	A1	EK4 Tom 3	Brush 2 Tom 3
46	A#1	EK4 HH Open 1	Brush 2 HH Edge
47	B1	EK4 Tom 4	Brush 2 Tom 4
48	C2	EK4 Tom 5	Brush 2 Tom 5
49	C#2	T9 Crash Cymbal	Brush 2 Crash Cymbal 2
50	D2	EK4 Tom 6	Brush 2 Tom 6
51	D#2	T9 Ride Cymbal	Brush 2 Ride Tip
52	E2	Crash Cymbal 1	Brush 2 China Crash
53	F2	Ride Cymbal Cup	Brush 2 Ride Cup
54	F#2	Tambo Hit	Tambo
55	G2	Splash Cymbal	Splash Sabian
56	G#2	Cowbell	Brush 2 Cowbell
57	A2	Crash Cymbal 2	Crash Medium
58	A#2	T8 Cowbell	Vibraslap
59	B2	Ride Cymbal	Brush 2 Ride Backend
60	C3	Bongo High OneFinger	Bongo High 1
61	C#3	Bongo Low ThreeFinger	Bongo Low 1
62	D3	Conga High Tip	Conga High Mute
63	D#3	Conga Open Slap	Conga High Open
64	E3	Conga 2 Open	Conga Low
65	F3	Timbales High	Timbales High
66	F#3	Timbales Low	Timbales Low
67	G3	Agogo High 1	Agogo High 1
68	G#3	Agogo Low 1	Agogo Low 1
69	A3	Cabasa	Cabasa 1
70	A#3	Slur Maracas	Maracas 1
71	B3	Vox Low	Whistle High
72	C4	Vox High	Whistle Low
73	C#4	Guiro Short	Guiro Short
74	D4	Guiro Long	Guiro Long
75	D#4	Cowbell	Clave High
76	E4	Woodblock High	Wood Block High
77	F4	Woodblock Low	Wood Block Low
78	F#4	EK4 HH Closed 2	Cuica High
79	G4	EK4 HH Closed 3	Cuica Low
80	G#4	Triangle Mute	Triangle High Short
81	A4	Triangle Open	Triangle High Long
82	A#4	EK3 HH open 2	Shaker 1 Egg
83	B4	EK4 Kick 6	Sleighbells
84	C5	EK4 Kick 7	Wind Chimes
85	C#5	EK4 Kick 8	
86	D5	EK4 Kick 9	
87	D#5	EK4 Snare 7	
88	E5	EK4 Snare 8	
89	F5	EK4 Snare 9	
90	F#5	EK4 Snare 10	
91	G5	EK4 Kick Filter	Splash Cymbal

MSB-LSB-PRG		104-000-032	104-000-033
Nr.	Note	Jazz Kit	Brush Kit 4
13	C#-1	JazzStick HH Tip 1	Surdo Mute
14	D-1	JazzStick HH Edge 1	Surdo Open
15	D#-1	JazzStick HH Tip 2	Hi Q
16	E-1	JazzStick HH Edge 2	WhipSlap
17	F-1	JazzStick HH Edge 3	Scratch High
18	F#-1	JazzStick HH Edge 4	Scratch Low
19	G-1	JazzStick HH Edge 5	Finger Snap
20	G#-1	JazzStick HH Edge 6	Click Noise
21	A-1	JazzStick HH Pedal Closed	Metronom Click
22	A#-1	JazzStick HH Pedal Splash	Metronom Bell
23	B-1	Seq Click Low	Brush Vintage Tip
24	C0	Seq Click High	Brush Vintage Swirl 1
25	C#0	JazzStick SideStick Off	Brush Vintage Slap 1
26	D0	JazzStick Snare Snappy noRim	Brush Vintage Swirl 2
27	D#0	JazzStick Snare 1 noRim	Brush Vintage Slap 2
28	E0	JazzStick Snare 2 noRim	Brush Vintage Tap Swirl
29	F0	JazzStick Snare Roll	Brush Vintage Slap Swirl
30	F#0	JazzStick Snare 3	Brush Vintage Swirl 3
31	G0	JazzStick Snare 4	Brush Vintage Slap 3
32	G#0	CountIn Stick	CountIn Stick
33	A0	JazzStick Kick 1	BrushReal Kick Soft 1
34	A#0	JazzStick Snare 5 openRim	BrushReal Snare OpenRim
35	B0	JazzStick Kick 2	BrushReal Kick Soft 2
36	C1	JazzStick Kick 3	BrushReal Kick Ambience
37	C#1	JazzStick Snare 5 SideStick	BrushReal Brush SideStick
38	D1	JazzStick Snare 5 noRim	Brush Vintage Slap 4
39	D#1	Clap Power	Clap Power
40	E1	JazzStick Snare 5 Snappy Off	Brush Vintage Slap 5
41	F1	JazzStick Tom 1	RealBrush Tom 1
42	F#1	JazzStick HH Edge 1	RealBrush HH Closed
43	G1	JazzStick Tom 2	RealBrush Tom 2
44	G#1	JazzStick HH Pedal Closed	RealBrush HH Pedal
45	A1	JazzStick Tom 3	RealBrush Tom 3
46	A#1	JazzStick HH Edge 6	RealBrush HH Open
47	B1	JazzStick Tom 4	RealBrush Tom 4
48	C2	JazzStick Tom 5	RealBrush Tom 5
49	C#2	JazzStick Crash Cymbal	RealBrush Crash Cymbal 1
50	D2	JazzStick Tom 6	RealBrush Tom 6
51	D#2	JazzStick Ride Cymbal Tip	RealBrush Ride Cymbal
52	E2	Crash China	RealBrush China Cymbal
53	F2	JazzStick Ride Cup	RealBrush Ride 1 Cup
54	F#2	Tambo	Tambo
55	G2	JazzStick Splash	RealBrush Splash
56	G#2	Cowbell 1	Cowbell
57	A2	JazzStick Crash Cymbal	RealBrush Crash Cymbal 2
58	A#2	Vibraslap	Vibraslap
59	B2	Ride Cymbal	RealBrush Ride 2 Cup
60	C3	Bongo High 1	Bongo High 1
61	C#3	Bongo Low 1	Bongo Low 1
62	D3	Conga High Mute	Conga High Mute
63	D#3	Conga High Open	Conga High Open
64	E3	Conga Low	Conga Low
65	F3	Timbales High	Timbales High
66	F#3	Timbales Low	Timbales Low
67	G3	Cowbell 2	Cowbell 2
68	G#3	Cowbell 3	Cowbell 3
69	A3	Cabasa 1	Cabasa 1
70	A#3	Maracas 1	Maracas 1
71	B3	Whistle High	Whistle High
72	C4	Whistle Low	Whistle Low
73	C#4	Guiro Short	Guiro Short
74	D4	Guiro Long	Guiro Long
75	D#4	Clave High	Clave High
76	E4	Wood Block High	Wood Block High
77	F4	Wood Block Low	Wood Block Low
78	F#4	Cuica High	Cuica High
79	G4	Cuica Low	Cuica Low
80	G#4	Triangle High Short	Triangle High Short
81	A4	Triangle High Long	Triangle High Long
82	A#4	Shaker 1 Egg	Shaker 1 Egg
83	B4	Sleighbells	Sleighbells
84	C5	Wind Chimes	Wind Chimes
85	C#5		
86	D5		
87	D#5		
88	E5		
89	F5		
90	F#5		
91	G5		

MSB-LSB-PRG		104-000-041	104-000-042	104-000-043
Nr.	Note	Afro Cuban Kit	PopLatin Kit 2	PopLatin Kit 3
13	C#-1	Djembe Bass	Cajon Low	Cajon Low
14	D-1	Djembe Close	Cajon Slap	Cajon Slap
15	D#-1	Djembe Open	Cajon Tip	Cajon Tip
16	E-1	Djembe Slap	Woodblock High	Woodblock High
17	F-1	Cajon Bass	Woodblock Low	Woodblock Low
18	F#-1	Cajon Mid	Claps 1	Claps 1
19	G-1	Cajon High		
20	G#-1	Conga L Open	Fingersnap 2	Fingersnap 2
21	A-1	Conga L Close	Castanet	Castanet
22	A#-1	Conga L Slap Open	Conga H Tip	Conga H Tip
23	B-1	Conga L Slap Mute	Conga H Heel	Conga H Heel
24	C0	Conga H Bass	Conga H Open	Conga H Open
25	C#0	Conga H Heel	Conga H Mute	Conga H Mute
26	D0	Conga H Tip	Conga H Slap Open	Conga H Slap Open
27	D#0	Conga H Open	Conga H Slap	Conga H Slap
28	E0	Conga H Slap Close	Conga H Slap Mute	Conga H Slap Mute
29	F0	Conga H Slap Open	Conga L Tip	Conga L Tip
30	F#0	Conga H Slap Mute	Conga L Heel	Conga L Heel
31	G0	Bongo L Open 1	Conga L Open	Conga L Open
32	G#0	Bongo L Open 2	Conga L Mute	Conga L Mute
33	A0	Bongo L Close	Conga L Slap Open	Conga L Slap Open
34	A#0	Bongo L Slap	Conga L Slap	Conga L Slap
35	B0	Bongo H Heel	Conga L Slide	Conga L Slide
36	C1	Bongo H Tip	Bongo H Open 1F	Bongo H Open 1F
37	C#1	Bongo H Open 1	Bongo H Open 3F	Bongo H Open 3F
38	D1	Bongo H Open 2	Bongo H Rim	Bongo H Rim
39	D#1	Bongo H Mute	Bongo H Tip	Bongo H Tip
40	E1	Bongo H Slap	Bongo H Heel	Bongo H Heel
41	F1	Cowbell 1 Mouth	Bongo H Slap	Bongo H Slap
42	F#1	Cowbell 1 Top 1	Bongo L Open 1F	Bongo L Open 1F
43	G1	Cowbell 1 Top 2	Bongo L Open 3F	Bongo L Open 3F
44	G#1	Cowbell 1 Edge	Bongo L Rim	Bongo L Rim
45	A1	Cowbell 2 Mouth	Bongo L Tip	Bongo L Tip
46	A#1	Cowbell 2 Top 1	Bongo L Heel	Bongo L Heel
47	B1	Cowbell 2 Tip 2	Bongo L Slap	Bongo L Slap
48	C2	Cowbell 2 Edge	Timbales Low	Timbales Low
49	C#2	Crash Cymbal		
50	D2	Chabell Mute		
51	D#2	Chabell Open		
52	E2	Chabell Top		
53	F2	MamboBell Centre	Paila L	Paila L
54	F#2	MamboBell Edge	Timbales High	Timbales High
55	G2	Timbale L Mute	Claps Mute 1	Claps Mute 1
56	G#2	Timbale L Open	Claps Mute 2	Claps Mute 2
57	A2	Timbale L Cask Tip	Claps Open 1	Claps Open 1
58	A#2	Timbale H Cask Tip	Claps Open 2	Claps Open 2
59	B2	Timbale L Side Stick	Paila H	Paila H
60	C3	Timbale L Open	Cowbell Top	Cowbell Top
61	C#3	Timbale L Rim	Cowbell 1	Cowbell 1
62	D3	Timbale H Open	Cowbell 2	Cowbell 2
63	D#3	Timbale H Rim	Cowbell 3	Cowbell 3
64	E3	Plastic Wood Block	Guira Short	Guira Short
65	F3	African Clave	Guira Long	Guira Long
66	F#3	Wood Clave	Metal Guiro Short	Metal Guiro Short
67	G3	Maracas 1 Low	Metal Guiro Long	Metal Guiro Long
68	G#3	Maracas 1 High	Tambo 2	Tambo 2
69	A3	Maracas 2 Low	Tambo Open	Tambo Open
70	A#3	Maracas 2 High	Tambo Mute	Tambo Mute
71	B3	Shekere 1 Tone	Tambo Tip	Tambo Tip
72	C4	Shekere 1 Up	Maracas 2	Maracas 2
73	C#4	Shekere 1 Down	Shaker 1 Egg	Shaker 1 Egg
74	D4	Shekere 2 Tone	Cabasa 1	Cabasa 1
75	D#4	Shekere 2 Up	Guica Low	Guica Low
76	E4	Shekere Down	Guica High	Guica High
77	F4	Guiro Up	Cow 3 Low Open	Cow 3 Low Open
78	F#4	Guiro Down	Cow 1 Side	Cow 1 Side
79	G4	Guiro Up Slow	Shekere	Shekere
80	G#4	Guiro Up Fast	Shekere Tone	Shekere Tone
81	A4	Metal Guiro Up	Triangle Mute	Triangle Mute
82	A#4	Metal Guiro Down	Triangle Open	Triangle Open
83	B4	Metal Guiro Long		
84	C5	Palmas L Mute	Wind Chimes	Wind Chimes
85	C#5	Palmas C Mute		
86	D5	Palmas R Mute		
87	D#5	Palmas L Open		
88	E5	Palmas C Open		
89	F5	Palmas R Open		
90	F#5	Chimes Down		
91	G5	Chimes Up		

MSB-LSB-PRG		104-000-044	104-000-050
Nr.	Note	PopPerc Kit	Perc Brasil Kit
13	C#-1	Djembe Bass	Djembe Bass
14	D-1	Djembe Close	Djembe Close
15	D#-1	Djembe Open	Djembe Open
16	E-1	Djembe Slap	Djembe Slap
17	F-1	Cajon Bass	Cajon Bass
18	F#-1	Cajon Mid	Cajon Mid
19	G-1	Cajon High	Cajon High
20	G#-1	Conga L Open	Conga L Open
21	A-1	Conga L Close	Conga L Close
22	A#-1	Conga L Slap Open	Conga L Slap Open
23	B-1	Conga L Slap Mute	Conga L Slap Mute
24	C0	Conga H Bass	Conga H Bass
25	C#0	Conga H Heel	Conga H Heel
26	D0	Conga H Tip	Conga H Tip
27	D#0	Conga H Open	Conga H Open
28	E0	Conga H Slap Close	Conga H Slap Close
29	F0	Conga H Slap Open	Conga H Slap Open
30	F#0	Conga H Slap Mute	Conga H Slap Mute
31	G0	Bongo L Open 1	Bongo L Open 1
32	G#0	Bongo L Open 2	Bongo L Open 2
33	A0	Bongo L Close	Bongo L Close
34	A#0	Bongo L Slap	Bongo L Slap
35	B0	Bongo H Heel	Bongo H Heel
36	C1	Bongo H Tip	Bongo H Tip
37	C#1	Bongo H Open 1	Bongo H Open 1
38	D1	Bongo H Open 2	Bongo H Open 2
39	D#1	Bongo H Mute	Bongo H Mute
40	E1	Bongo H Slap	Bongo H Slap
41	F1	Cowbell 1 Mouth	Agogo 1 Close
42	F#1	Cowbell 2 Mouth	Agogo 1 Bell 1
43	G1	Chabell Open	Agogo 1 Bell 2
44	G#1	Cowbell	Agogo 2 Close
45	A1	Fibre Clave	Agogo 2 Bell 1
46	A#1	Plastic Woodblock	Agogo 2 Bell 2
47	B1	African Clave	Cabasa 1
48	C2	Wood Clave	Cabasa 2
49	C#2	Crash Cymbal	Crash Cymbal
50	D2	Temp Block 1	Tambo 1 Back
51	D#2	Temp Block 2	Tambo 1 Close
52	E2	Temp Block 3	Tambo 1 Open
53	F2	Tambo 1 Shake	Tambo 1 Rim
54	F#2	Tambo 1 Hit	Tambo 2 Up
55	G2	Tambo 2 Shake	Tambo 2 Down
56	G#2	Tambo 2 Hit	Pandeiro 2 Heel
57	A2	Tambo 3 Hit	Pandeiro 2 Open
58	A#2	Palmas L Mute	Pandeiro 2 Toe Open
59	B2	Palmas R Mute	Pandeiro 2 Thumb Close
60	C3	Palmas L Open	Pandeiro 2 Toe Close
61	C#3	Palmas R Open	Pandeiro 2 Slap
62	D3	Claps Low	Padeiro 1 Heel
63	D#3	Claps High	Pandeiro 1 Thumb Open
64	E3	Cabasa 1	Pandeiro 1 Toe Open
65	F3	Cabasa 2	Pandeiro 1 Thumb Close
66	F#3	Shaker 1 Up	Pandeiro 1 Toe Close
67	G3	Shaker 1 Down	Pandeiro 1Slap
68	G#3	Shaker 1 Long	Shaker 1 Up
69	A3	Shaker 2 Up	Shaker 1 Down
70	A#3	Shaker 2 Down	Shaker 1 Long
71	B3	Shaker 2 Long	Shaker 2 Up
72	C4	Shaker 3 Up	Shaker 2 Down
73	C#4	Shaker 3 Down	Shaker 2 Long
74	D4	Shaker 3 Long	Shaker 3 Up
75	D#4	Shaker 4 Up	Shaker 3 Down
76	E4	Shaker 4 Down	Shaker 3 Long
77	F4	Shaker 4 Long	Shaker 4 Up
78	F#4	Shaker 5 Up	Shaker 4 Down
79	G4	Shaker 5 Down	Shaker 4 Long
80	G#4	Udu Bass Open	Shekere 1 Tone
81	A4	Udu Bass	Shekere 1 Up
82	A#4	Udu Heel	Shekere 1 Down
83	B4	Udu Tip	RecoReco Scrape
84	C5	Udu Body	RecoReco Short
85	C#5	Udu Top	RecoReco Long
86	D5	Triangle open Up	Triangle open Up
87	D#5	Triangle Open Down	Triangle Open Down
88	E5	Triangle Close Up	Triangle Close Up
89	F5	Triangle Close Down	Triangle Close Down
90	F#5	Chimes Down	Chimes Down
91	G5	Chimes Up	Chimes Up



Brand Owner and Development
MUSIC STORE
professional

MUSIC STORE professional GmbH
Istanbulstraße 22-26
51103 Cologne - Germany

E-Mail: info@wersi.net

Website: www.wersi.net